



# Pulse Motion Controller


## ZMC412




Vision Motion Controller




Motion Controller



Motion Control Card



Expansion Module



HMI



## Foreword



The motion controller provides rich interface, and it has excellent motion control performance, which can meet the expansion requirements of various projects.

This manual is copyrighted by Shenzhen Technology Co., Ltd., without the written permission of the Zmotion Technology, no person shall reproduce, translate and copy any content in this manual. The above-mentioned actions will constitute an infringement of the copyright of the company's manual, and Zmotion will investigate legal responsibility according to law.

For details about the ZMC controller software and the introduction and routine of each command, please refer to the ZBASIC software manual.

Information contained in this manual is only for reference. Due to improvements in design and functions and other aspects, Zmotion Technology reserves the final interpretation! Subject to change without notice!

**Pay attention to safety when debugging the machine!**

**Please be sure to design an effective safety protection device in the machine, and add an error handling program in the software, otherwise Zmotion has no obligation or responsibility for the loss caused.**

In order to ensure the safe, normal and effective use of the product, please be sure to read this product manual carefully before installing and using the product.

# Content

Chapter I Production Information.....	3
1.1. Product Information.....	3
1.2. Function Features.....	3
1.3. System Frame .....	4
1.4. Hardware Installment.....	5
Chapter II Product Specification .....	7
2.1. Basic Specification.....	7
2.2. Order Information .....	8
2.3. Interface Definition.....	8
2.4. Work Environment .....	10
Chapter III Wiring, Communication Configuration .....	11
3.1. Power Input .....	11
3.1.1. Power Specification.....	11
3.2. RS485, CAN Communication Interface .....	12
3.2.1. RS485, CAN Communication Specification & Wiring.....	12
3.2.2. Basic Usage Method .....	15
3.3. RS232 Serial Port .....	16
3.3.1. RS232 Communication Interface Specification & Wiring .....	17
3.3.2. Basic Usage Method .....	18
3.4. IN Digital Input & High-Speed Latch Port.....	19
3.4.1. Digital Input Specification & Wiring .....	20
3.4.2. Basic Usage Method .....	21
3.5. OUT: Digital Output, PWM Terminal, Hardware Comparison Output, Single- ended Pulse.....	22
3.5.1. Digital Output Specification & Wiring.....	23
3.5.2. Basic Usage Method .....	25

3.6.	Analog Output (DA)	25
3.6.1.	Analog Output Specification & Wiring	26
3.6.2.	Basic Usage	27
3.7.	U Disk	27
3.8.	ETHERNET	28
3.9.	AXIS Differential Pulse Axis Interface	30
3.9.1.	AXIS Interface Signal Specification & Wiring	32
3.9.2.	Basic Usage Method	34
Chapter IV Expansion Module		36
4.1.	CAN Bus Expansion	36
4.2.	CAN Bus Expansion Wiring	36
4.3.	CAN Bus Expansion Resource Mapping	38
Chapter V Program & Applications		43
5.1.	ZDevelop Software Usage	43
5.2.	PC Upper-Computer Program Application	48
Chapter VI Run and Maintain		51
6.1.	Regular Inspection and Maintenance	51
6.2.	Common Problems	52

# Chapter I Production Information

## 1.1. Product Information

ZMC is the abbreviation of the motion controller model launched by Zmotion Technology.

ZMC4 series supports Zmotion XPLC function, and can be configured and displayed through the network.

ZMC412 high-performance multi-axis motion controller belongs to pulse type standalone pulse type. The controller itself supports 12 axes at most, but it can be expanded to 32 axes to achieve complex continuous trajectory control requirements.


ZMC4 series high-performance multi-axis motion controller can be applied in robots (SCARA, Delta, 6 joints), electronic semiconductor equipment (testing equipment, assembly equipment, locking equipment, soldering machine), dispensing equipment, non-standard equipment, printing and packaging equipment, textile and garment equipment, stage entertainment equipment, medical equipment, assembly line, etc.

## 1.2. Function Features

- ◆ Motion control of up to 12 axes.
- ◆ Pulse output mode: pulse / direction or dual pulses or quadrature pulse.
- ◆ Maximum pulse frequency output of each axis: 10MHZ.
- ◆ IO can be expanded through CAN, and 4096 isolation inputs and 4096 isolation outputs can be extended at most.
- ◆ Axis position limit signal / origin signal port can be configured as any input at will.
- ◆ The maximum output current of general digital outputs can reach 300mA, which can directly drive some kinds of solenoid valves.


- ◆ Interfaces: RS232, RS485, U Disk, Ethernet.
- ◆ Support linear interpolation, any circular interpolation, helical interpolation and spline interpolation of 12 axes at most.
- ◆ Support electronic cam, electronic gear, position latch, synchronous follow, virtual axis, etc.
- ◆ Support hardware comparison output (HW\_PSWITCH2), hardware timer, precision output in motion.
- ◆ Support pulse closed loop, pitch compensation and other functions.
- ◆ Multi-file and multi-task programming in ZBasic.
- ◆ A variety of program encryption methods to protect the intellectual property rights of customers.
- ◆ Support power failure detection and power failure storage. (It can detect and save when power-off)

### 1.3. System Frame



## 1.4. Hardware Installment

The ZMC412 motion controller adopts the horizontal installation method of screw fixing, and each controller should be installed with 4 screws for fastening.



→ Unit: mm

→ Installment Hole Diameter: 4.5mm



**Installation  
attention**

- Non-professionals are strictly prohibited to operate. Specifically, professionals who had been trained related electrical equipment, or who master electrical knowledge.
- Please be sure to read the product instruction manual and safety precautions carefully before installation.
- Before installation, please ensure that the product is powered off.
- Do not disassemble the module, otherwise the machine may be damaged.
- Avoid direct sunlight installation.
- In order to facilitate ventilation and controller replacement, 2-3cm should be left between the upper and lower parts of the controller and the installation environment and surrounding components.

	<ul style="list-style-type: none"><li>● Considering the convenient operation and maintenance of the controller, please do not install the controller in the following places:<ul style="list-style-type: none"><li>a) places where the surrounding ambient temperature exceeds the range of -10°C-55°C</li><li>b) places where the ambient humidity exceeds the range of 10%-95% (non-condensing)</li><li>c) places with corrosive gases and flammable gases</li><li>d) places with many conductive powders such as dust and iron powder, oil mist, salt, and organic solvents</li></ul></li></ul>
--	--



## Chapter II Product Specification


### 2.1. Basic Specification

Item	Description	
Model	ZMC412	ZMC412-14
Basic Axes	12	14
Max Extended Axes	32	32
Type of Basic Axes	Local pulse axes	
Digital IO	General IO: 24 inputs, 12 outputs IO inside the axis interface: there are 12 inputs and 12 outputs for these 12 pulse axes interfaces.	
Max Extended IO	4096 inputs, 4096 outputs	
PWM	2	
AD/DA	2 general DAs, 0-10V	
Max Extended AD/DA	520 ADs, 520 DAs	
Pulse Bit	64	
Encoder Bit	64	
Speed and Acceleration Bit	64	
Highest Pulse Frequency	10MHz	
Motion Buffer of Each Axis	4096	
Array Space	320000	
Program Space	32MByte	
Flash Space	20480KByte	
Power Supply Input	24V DC input	
Communication Interfaces	RS232, RS485, Ethernet, U disk, CAN	
Dimensions	250mm*164mm	

## 2.2. Order Information

Model	Description
ZMC412	12 axes, point to point, linear, circular, electronic cam, continuous trajectory motion, robotic car instructions.
ZMC412-14	14 axes, point to point, linear, circular, electronic cam, continuous trajectory motion, robotic car instructions.
ZMC412R	Functions of ZMC412 + Delta + 6-joint robotic arm instructions.

## 2.3. Interface Definition



## → Interface Description

Mark	Interface	Number	Description
POW	Status Indication Light	1	Power indicator: it lights when power is conducted.
RUN		1	Run indicator: it lights when runs normally
ALM		1	Error indicator: it lights when runs abnormally
RS232	RS232 serial port (port0)	1	Use MODBUS_RTU protocol
RS485	RS485 serial port (port1)	1	Use MODBUS_RTU protocol
RS485	RS485 serial port (port2)	1	Use MODBUS_RTU protocol
ETHERNET	Ethernet	1	Use MODBUS_TCP protocol, expand Ethernet through interchanger, the number of net port channels can be checked through "?*port", default IP address id 192.168.0.11
UDISK	U disk interface	1	Insert U disk equipment
E+24V	Main power	1	24V DC power supplies for controller
CAN	CAN bus interface	1	Connect CAN expansion module and CAN equipment of other standards
IN	Digital IO input	24	Leakage type, internal 24V supply power, 8 high-speed inputs, and IN0-7 have latch function.
OUT	Digital IO output	12	Leakage type, internal 24V supply power, 4 high-speed outputs, OUT0-1 have PWM, OUT0-3 have hardware

			comparison output function
DA	Analog output	2	Resolution: 12 bits, 0-10V
AXIS	Pulse axis	6	It includes differential pulse output and differential encoder input

## 2.4. Work Environment


Item		Parameters
Work Temperature		-10℃-55℃
Work relative Humidity		10%-95% non-condensing
Storage Temperature		-40℃ ~ 80℃ (not frozen)
Storage Humidity		Below 90%RH (no frost)
vibration	Frequency	5-150Hz
	Displacement	3.5mm(directly install)(<9Hz)
	Acceleration	1g(directly install)(>9Hz)
	Direction	3 axial direction
Shock (collide)		15g, 11ms, half sinusoid, 3 axial direction
Degree of Protection		IP20

# Chapter III Wiring, Communication Configuration

## 3.1. Power Input

The power supply input adopts a 3Pin (there are all 3 terminals, E+24V, EGND and FG) screw-type pluggable wiring terminal, and the interval (means the gap distance between two ports, namely, between E+24V and EGND) should be 3.81mm. This 3Pin terminal is the power supply of the controller.

### → Terminal Definition:

Terminal	Name	Type	Function
FG EGND E+24V 	FG	Grounding	Protect
	EGND	Input	Positive (+) terminal of DC power input
	E+24V	Input	Negative (-) terminal of power input

### 3.1.1. Power Specification


#### → Specification

Item	Description
Voltage	DC24V(-10%~10%)
The current to open	≤0.5A
The current to work	≤0.4A
Anti-reverse connection	Valid
Overcurrent Protection	Valid

## 3.2. RS485, CAN Communication Interface

The communication interface adopts an 8Pin screw-type pluggable wiring terminal and the gap spacing between 2 terminals should be 3.81mm. ZMC412 has 2 RS485 communication interfaces and 1 CAN communication interface, and for both RS485 communication and CAN communication, they can be used by connecting the corresponding interface.

### → Terminal Definition:

Terminal	Name	Function
	485-2B	485-2-
	485-2A	485-2+
	EGND	External power supply ground
	485B	485-
	485A	485+
	EGND	External power supply ground
	CANL	CAN differential data -
	CANH	CAN differential data +

### 3.2.1. RS485, CAN Communication Specification & Wiring

The RS485 serial port supports the MODBUS\_RTU protocol and custom communication, mainly including 485A, 485B, 485-2A, 485-2B and common ports.

The CAN interface of the controller adopts the standard CAN communication protocol, which mainly includes three ports, CANL, CANH and the common port. And it supports connecting CAN expansion modules and other standard CAN devices.


### → Specification

Item	RS485	CAN
------	-------	-----


Max Communication Rate (bps)	115200	1M
Terminal Resistor	No	120Ω
Topology	Daisy chain connection structure	
Nodes can be extended	Up to 127	Up to 16
Communication Distance	Longer communication distance, lower communication rate, max 100m is recommended.	

### → Wiring Reference

Connect 485A and 485B of RS485 to 485A and 485B of the controller correspondingly, and connect the common terminal EGND of both parties of RS485 communication together. 485-2A and 485-2B is same as this.



Connect the CANL and CANH of the standard CAN module to the CANL and CANH of the other side correspondingly. And public ends of the CAN bus communication both parties are connected together. In CAN bus left and right sides, connect a 120Ω resistor respectively (please see below graphic).




### → Wiring Notes:

- As above, the daisy chain topology is used for wiring (the star topology structure cannot be used). When the use environment is ideal and there are no many nodes, the branch structure also can be used.
- Please connect a 120Ω terminal resistor in parallel to each end of the CAN bus for matching the circuit impedance and ensuring communication stability.
- Please be sure to connect the public ends of each node on the CAN bus to prevent the CAN chip from burning out.
- Please use STP (Shielded Twisted Pair), especially in bad environments, and make sure the shielding layer is fully grounded.
- When on-site wiring, pay attention to make the distance between strong current and weak current, it is recommended for the distance to be more than 20cm.
- It should be noted that the equipment grounding (chassis) on the entire line must be good, and the grounding of the chassis should be connected to the standard factory ground pile.

### → Cable Requirements:

Shielded Twisted Pair, and the shielded cable is grounded.





### 3.2.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232, and RS485 to connect to ZDevelop.
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configuration parameters, see "ZBasic Programming Manual" for details.
- (4) Please use the "CANIO\_ADDRESS" command to set the master's "address" and "speed" according to the needs, and use the "CANIO\_ENABLE" command to enable or disable the internal CAN master function, or through "ZDevelop/Controller/State the Controller/Communication Info" to view the CAN status intuitively, and refer to the "ZBasic Programming Manual" for details.

```
CANIO_ADDRESS = 32, CANIO_ENABLE = 1
ZCAN Master
CAN baud: 500KBPS
CAN enable: ON

Serial port configuration:
Port0:(RS232) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0
Port1:(RS485) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0
Port2:(RS485) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0
```


- (5) Correctly set the relevant parameters of the third-party equipment according to their respective instructions to match the parameters of each node.
- (6) Correctly set the "address" and "speed" of the slave expansion module according to the manual of the slave.
- (7) After all the settings are completed, restart the power supply of all stations to establish communication.
- (8) Note that the "speed" settings of each node on the CAN bus must be consistent, and the "address" settings cannot cause conflicts, otherwise the "ALM" alarm light will be on, and the communication establishment will fail or the communication will be disordered.

### 3.3. RS232 Serial Port

RS232 is in a standard DB9 (male) socket and supports MODBUS\_RTU protocol and custom communication.

#### → Interface Definition:

Terminal	PIN	Name	Type	Function
----------	-----	------	------	----------


	1、4、 6、7、8	NC	Spare	Reserved
	2	RXD	Input	RS232 signal receive
	3	TXD	Output	RS232 signal send
	5	EGND	Output	5V power supply outputs negative pole and this communication common terminal
	9	E5V	Output	5V power supply outputs positive pole, max is 300mA

### 3.3.1. RS232 Communication Interface Specification & Wiring

#### → Specification:

Item	RS232
Max Communication Rate (bps)	115200
Terminal Resistor	No
Topology	Connect correspondingly (1 to 1)
Nodes can be extended	1
Communication Distance	Longer communication distance, lower communication rate, max 10m is recommended.

#### → Wiring Reference:




### → Wiring Notes:

- The wiring of RS232 is as above, the sending and receiving signals need to be cross-connected, and it is recommended to use a double-female cross line when connecting to a computer.
- Please be sure to connect the common terminal of each communication node to prevent the communication chip from burning out.
- Please use twisted-pair shielded cables, especially in harsh environments, and make sure the shielding layer is fully grounded.

### → Cable Requirements:

Shielded Twisted Pair, and the shielded cable is grounded.



## 3.3.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 (default parameter, it can be connected directly) and RS485 (default parameters, it can be connected directly, for hardware, adapter is needed) to connect to ZDevelop.
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configuration parameters, see "ZBasic Programming Manual" for details.

- (4) Correctly set the relevant parameters of the third-party equipment according to their respective instructions to match the parameters of each node.
- (5) When all is configured, it can start to do communicating.
- (6) Communication data of RS232 / RS485 can be directly viewed through "ZDevelop / Controller / State the Controller / CommunicationInfo".

```

CANIO_ADDRESS = 32, CANIO_ENABLE = 1
ZCAN Master
CAN baud: 500KBPS
CAN enable: ON


Serial port configuration:
Port0:(RS232) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0
Port1:(RS485) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0
Port2:(RS485) is ModbusSlave Mode.
Address: 1, variable: 2
Baud: 38400
DataBits: 8
StopBits: 1
Parity: 0



```

### 3.4. IN Digital Input & High-Speed Latch Port

The digital input adopts 3 groups of 10Pin screw-type pluggable terminals with a pitch of 3.81mm, and the digital input signals integrate the high-speed latch function.

#### → Wiring Definition

Terminal	Name	Type	Function 1	Function 2
	EGND	/	External power ground	/
	EGND	/		/
	IN0	NPN leakage type, high-speed input	Input 0	High Speed Latch
	IN1		Input 1	
	IN2		Input 2	
	IN3		Input 3	
	IN4		Input 4	
	IN5		Input 5	
	IN6		Input 6	
	IN7		Input 7	

	EGND	EGND	/	External power ground	/
	EGND	EGND	/		/
	IN8	IN8	NPN leakage type, low-speed input	Input 8	/
	IN9	IN9		Input 9	/
	IN10	IN10		Input 10	/
	IN11	IN11		Input 11	/
	IN12	IN12		Input 12	/
	IN13	IN13		Input 13	/
	IN14	IN14		Input 14	/
	IN15	IN15		Input 15	/
	EGND	EGND	/	External power ground	/
	EGND	EGND	/		/
	IN16	IN16	NPN leakage type, low-speed input	Input 16	/
	IN17	IN17		Input 17	/
	IN18	IN18		Input 18	/
	IN19	IN19		Input 19	/
	IN20	IN20		Input 20	/
	IN21	IN21		Input 21	/
	IN22	IN22		Input 22	/
	IN23	IN23		Input 23	/

Note: ZMC412 has 8 latch inputs (for general firmware, there are 4 latch inputs, for special firmware, there are 8 latch inputs)


### 3.4.1. Digital Input Specification & Wiring

#### → Specification

Item	High-Speed Input (IN0-7)	Low-Speed Input (IN8-23)
Input mode	NPN leakage type, the input is triggered when there is low-electric level	
Frequency	< 100kHz	< 5kHz
Impedance	3.3KΩ	4.7KΩ
Voltage level	DC24V	DC24V
The voltage to open	<15V	<14.5V
The voltage to close	>15.1V	>14.7V
Minimal current	-2.3mA (negative)	-1.8mA (negative)
Max current	-7.5mA (negative)	-6mA (negative)

Isolation mode	optoelectronic isolation	optoelectronic isolation
<b>Note:</b> the above parameters are standard values when the controller power supply voltage (E+24V port) is 24V.		

### → Wiring Reference



### → Wiring Note:

- The wiring principle of high-speed digital input IN (0-7) and low-speed digital input IN (8-23) are shown in the figure above. The external signal source can be an optocoupler or a key switch or sensor, etc., all can be connected as long as the output level meets the requirements.
- For the common terminal, please select the "EGND" port on the power supply terminal to connect to the "COM" terminal of the external input device. If the power supply of the signal area of the external device and the power supply of the controller are in the same power supply system, this connection can also be omitted.

## 3.4.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to ZDevelop.
- (3) State values of relative inputs can be read directly through "IN" command, also, it can be read through "ZDevelop/View/In". Please refer to "ZBasic" for details.

0	●	●	rev_in(0)
1	●	●	rev_in(1)
2	●	●	rev_in(2)
3	●	●	fwd_in(0)
4	●	●	fwd_in(1)
5	●	●	fwd_in(2)
6	●	●	alm_in(0)
7	●	●	alm_in(1)
8	●	●	alm_in(2)
9	●	●	
10	●	●	
11	●	●	
12	●	●	

- (4) Latch function can be set and opened through "REGIST" instruction, in software, use REG\_INPUTS to configure. Please refer to "ZBasic" for details.


### 3.5. OUT: Digital Output, PWM Terminal, Hardware Comparison Output, Single-ended Pulse

The digital output adopts 2 sets of screw-type pluggable terminals with a spacing of 3.81mm, and the digital output signals integrate with PWM and hardware comparison output functions.

#### → Wiring Definition

Terminal	Name	Type	Function			
			1	2	3	4
EGND	EGND	/	External power ground	/	/	/
E5V	E5V	/	5V power output, max 300mA	/	/	/
OUT0	OUT0	NPN Leakage type, high-	Output 0	PWM Output 0	Hardware Comparison Output	PUL12
OUT1			Output 1	PWM Output 1		DIR12
OUT2						
OUT3						
OUT4						
OUT5						
OUT6						
OUT7						



	OUT2	speed	Output 2	/		PUL13
	OUT3	output	Output 3	/		DIR13
	OUT4	NPN	Output 4	/	/	/
	OUT5	Leakage	Output 5	/	/	/
	OUT6	type,	Output 6	/	/	/
	OUT7	low-speed output	Output 7	/	/	/
EGND OUT8 OUT9 OUT10 OUT11 	EGND	/	External power ground	/	/	/
	OUT8	NPN	Output 8	/	/	/
	OUT9	Leakage	Output 9	/	/	/
	OUT10	type,	Output 10	/	/	/
	OUT11	low-speed output	Output 11	/	/	/
<b>Note:</b> <ul style="list-style-type: none"> <li>✧ The E5V power output port is used for PWM or single-ended axis common anode wiring. It is not recommended for other purposes due to lower power.</li> <li>✧ OUT0-1 have the functions of PWM, OUT0-3 have hardware comparison output function and single-ended pulse function, when ATYPE=0, they are general outputs.</li> <li>✧ For single-end pulse axis function is only valid in ZMC412-14, which means ordinary ZMC412 controller doesn't support single-ended pulse function.</li> </ul>						

### 3.5.1. Digital Output Specification & Wiring


#### → Specification

Item	High Speed Output (OUT0-3)	Low Speed Output (OUT4-11)
Output mode	NPN leakage type, it is 0V when outputs	
Frequency	< 400kHz	< 8kHz
Voltage level	DC24V	DC24V
Max output current	+300mA	+300mA
Max leakage current when off	25μA	25μA

Respond time to conduct	1 $\mu$ s (resistive load typical value)	12 $\mu$ s
Respond time to close	3 $\mu$ s	80 $\mu$ s
Overcurrent protection	Support	Support
Isolation method	optoelectronic isolation	

**Note:**

- ✧ The times in the form are typical based on the resistive load, and may change when the load circuit changes.
- ✧ Due to the leak-type output, the shutdown of the output will be obviously affected by the external load circuit, and the output frequency should not be set too high in the application.

**→ Wiring Reference****→ Wiring Note:**


- The wiring principle of high-speed digital outputs OUT (0-3) and low-speed digital outputs OUT (4-11) are shown in the figure above. The external signal receiving end can be an optocoupler or a relay or solenoid valve, all can be connected as long as the input current does not exceed 300mA.
- For the connection of the common terminal, please select the "EGND" port on the power terminal to connect to the negative pole of the DC power supply of the external

input device. If the DC power supply of the external device and the controller power supply are in the same power supply system, this connection can also be omitted.

- The E5V port is a 5V power output port, which can be used when some loads need to provide an external 5V power input, the maximum current is 300mA.

### 3.5.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to ZDevelop.
- (3) Terminal can be operated to ON or OFF directly through "OP" command, also, it can be opened or closed through "ZDevelop/View/Op". Please refer to "ZBasic" for details.




- (4) PWM function can be used to set frequency and duty cycle through "PWM\_FREQ" and "PWM\_DUTY". Please refer to ZBasic for details.
- (5) Hardware comparison output can be set and opened through "HW\_PSWITCH2". Please refer to ZBasic for details.

### 3.6. Analog Output (DA)

The analog port adopts a set of 5Pin screw-type pluggable terminals with a spacing

of 3.81mm.

### → Wiring Definition


Terminal	Name	Type	Function
 DA0 DA1 DAGND	DA0	Output	Analog output terminal AOUT(0)
	DA1		Analog output terminal AOUT(1)
	DAGND	Public end	Analog public end

## 3.6.1. Analog Output Specification & Wiring

### → Specification

Item	DA (0-1)
Resolution	12-bit
Data range	0-4095
Signal range	0-10V output
Data refresh ratio	1KHz
Voltage output load	$\geq 1K\Omega$

### → Wiring Reference




### → Wiring Note:

- The analog input/output wiring method is as shown in the figure above, and the external load signal range must match it.

- Please use twisted-pair shielded cables, especially in harsh environments, and make sure the shielding layer is fully grounded.

### → Cable Requirements:

Twisted pair shielded wire, and shielded cable grounded.




## 3.6.2. Basic Usage

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to ZDevelop.
- (3) Analog input voltage can be read through "AIN" command and corresponding analog voltage can be output through "AOUT" command, also, data of each channel can be checked through "ZDevelop/View/AD/DA". Please refer to "ZBasic" for details.

DA:					
Channel number	Size	Scale value	V or mA value	Maximum scale	V or mA Range
0	0%	0	0.000	4095	0~10V
1	0%	0	0.000	4095	0~10V

## 3.7. U Disk

The ZMC412 motion controller provides a USB communication interface to insert a U disk device, which is used for ZAR program upgrade, controller data import and export, and 3 file executions. Its schematic diagram is shown in the figure below:




### → Specification


Item	USB2.0
Max Communication Ratio	12Mbps
Max Output Current of 5V	500mA
Whether Isolates	No

## 3.8. ETHERNET


ZMC412 motion controller has a 100M network port, supports MODBUS\_TCP protocol and custom communication, and the default IP address is 192.168.0.11. The pin definition diagram is as follows:



The Ethernet port of the controller can be connected point-to-point with a computer, HMI, etc. through an Ethernet cable. The schematic diagram is as follows:




The controller can also be connected to the interchanger through an Ethernet cable, and connected to other devices through the interchanger to realize multi-point connection. The schematic diagram is as follows:



## → Communication Cable Requirements

ETHERNET communication interface adopts standard Ethernet RJ45 interface.

The network cable adopts Category 5e shielded twisted pair, and the crystal head has a metal shell to reduce interference and prevent information from being eavesdropped. As shown below:



Item	Specification
Cable type	Flexible crossover cable, Cat 5e
Cable type	twisted pair
Cable pair	4
Isolation	cross skeleton
Connector	Crystal head with iron shell
Cable material	PVC
Cable length	Less than 100m

#### Use RJ45 network cable connection method:

- When installing, hold the crystal head with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.
- When disassembling, press the tail mechanism of the crystal head and pull out the connector and the module in a horizontal direction.

Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.


## 3.9. AXIS Differential Pulse Axis Interface

This product provides 12 local differential pulse axis interfaces, each interface is a standard DB26 female socket. Each terminal provides 0V and +5V output, which can provide 5V power for the encoder.

Before the axis is used, the use mode of the axis must be configured through the ATYPE parameter.



## → Interface Definition

Interface	Pin	Signal	Description
	1	EGND	Negative pole of IO 24V power
	2	IN24-35/ALM	Digital input, it is recommended to do drive alarm
	3	OUT12-13ENABLE	Digital output, it is recommended to do drive enable
	4	EA-	Encoder differential input signal A-
	5	EB-	Encoder differential input signal B-
	6	EZ-	Encoder differential input signal Z-
	7	+5V	Positive pole of 5V power of pulse/encoder signal
	8	Reserved	Reserved
	9	DIR+	Servo or step direction output +
	10	GND	Negative pole of 5V power of pulse/encoder signal
	11	PUL-	Servo or step pulse output -
	12	Reserved	Reserved
	13	GND	Negative pole of 5V power of pulse/encoder signal
	14	OVCC	Positive pole of IO 24V power
	15	Reserved	Reserved
	16	Reserved	Reserved
	17	EA+	Encoder differential input signal A+
	18	EB+	Encoder differential input signal B+
	19	EZ+	Encoder differential input signal Z+
	20	GND	Negative pole of 5V power of pulse/encoder signal
	21	GND	
	22	DIR-	Servo or step direction output -
	23	PUL+	Servo or step pulse output +
	24	GND	Negative pole of 5V power of pulse/encoder signal
	25	Reserved	Reserved
	26	Reserved	Reserved

**Note:**

- ✧ ALM and ENABLE are recommended to be used as axis IO, because the drive capacity is small.
- ✧ OVCC, +5V are only used for communication between the controller and the servo driver, please do not use it as power supply for other places.

### 3.9.1. AXIS Interface Signal Specification & Wiring


→ **Specification:**

Signal	Item	Description
PUL/DIR	Signal type	Differential output signal
	Voltage range	0-5V
	Maximum frequency	10MHz
EA/EB/EZ	Signal type	Differential input signal
	Voltage range	0-5V
	Maximum frequency	5MHz
IN24-35	Input method	NPN leak type, it is triggered when low electric level is input.
	Frequency	< 5kHz
	Impedance	6.8KΩ
	Voltage level	DC24V
	The voltage to open	<10.5V
	The voltage to close	>10.7V
	Minimal current	-1.8mA (negative)
	Maximum current	-4mA (negative)
	Isolation	optoelectronic isolation
OUT12-23	Output method	NPN leak type, it is 0V when outputs
	Frequency	< 8kHz
	Voltage level	DC24V
	Maximum current	+50mA
	Overcurrent protection	No
	Isolation	optoelectronic isolation
+5V, GND	Maximum output current for 5V	50mA

EGND	Maximum output current for 24V	50mA
------	--------------------------------	------

## → Wiring Reference:

Reference example of wiring with Panasonic A5/A6 servo drive:



### → Wiring Note:

- ✧ The wiring principle of the differential pulse axis interface is shown in the figure above, and the wiring methods of different types of drivers are different, please connect carefully.
- ✧ Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.

## 3.9.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 (default parameter, it can be connected directly) and RS485 (default parameters, it can be connected directly, for hardware, adapter is needed) to connect to ZDevelop.
- (3) Set axis parameters, such as, ATYPE, UNITS, SPEED, ACCEL, FWD\_IN, REV\_IN, etc.
- (4) There are many parameters related to pulse axis, they can be set and checked through relative instructions, please see "axis parameter and axis status" of "ZBasic", or see "ZDevelop/View/Axis parameter".

Axis Parameters				
Axis select	Parameter select			
	Axis0	Axis1	Axis2	Axis3
COMMENT				
ATYPE	0	0	0	0
UNITS	1	1	1	1
ACCEL	10000	10000	10000	10000
DECEL	0	0	0	0
SPEED	1000	1000	1000	1000
CREEP	100	100	100	100
LSPEED	0	0	0	0
MERGE	0	0	0	0
SRAMP	0	0	0	0
DPOS	0	0	0	0
MPOS	0	0	0	0
ENDMOVE	0	0	0	0
FS_LIMIT	200000000	200000000	200000000	200000000
RS_LIMIT	-200000000	-200000000	-200000000	-200000000

(5) Control corresponding motion through “View – Manual”.

Axis	ATYPE	UNITS	ACCEL	DECEL	SPEED	DPOS	Left/Move	Right/Move	Distance	Absolute	Move	MPOS	IDLE	AXISSTATUS
0	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop
1	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop
2	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop
3	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop
4	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop
5	0	1.000	10000.0	0.000	1000.00	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h Stop

### Refer to BASIC Routine:

BASE(0,1)	'select axis 0 and axis 1
ATYPE = 1,1	'set axis 0 and axis as pulse axes
UNITS = 1000,1000	'set pulse amount as 1000 pulses
SPEED = 10,10	'set axis speed as 10*1000 pulse/s
ACCEL = 1000,1000	'set axis acceleration as 1000*1000 pulse/s/s
FWD_IN = -1,-1	'prohibit using axis positive hardware position limit
REV_IN = -1,-1	'prohibit using axis negative hardware position limit
MOVE(10) AXIS(0)	'axis 0 moves distance of 10*1000 pulses in positive
MOVE(-20) AXIS(0)	'axis 0 moves distance of 20*1000 pulses in negative

## Chapter IV Expansion Module

The controller can expand digital IO, analog IO, pulse axis and other resources through CAN bus (ZIO series expansion modules). For details, please refer to "ZIO Expansion Card Hardware Manual". Also, through EtherCAT bus (EIO series expansion cards) expansion of these resources also can be achieved, please refer to each EIO hardware manual for details.

### 4.1. CAN Bus Expansion

ZIO series expansion modules or ZMIO310-CAN coupler with sub modules can be used.

Connect control card to CAN bus expansion modules, when the eighth bit of the DIP switch of the expansion module is turned to ON, which indicates that a 120 ohm resistor has been connected, but needs to connect one 120 ohm resistor externally. When connecting multiple CAN expansion modules, you only need to dial ON for the eighth digit of the last expansion module, which means please do not dial bit-8 of other modules.


### 4.2. CAN Bus Expansion Wiring

The ZIO expansion module is powered by the dual power supply. Except the main power supply, an additional IO power supply is required to supply independent power for IO. Both the main power supply and the IO power supply use 24V DC power supply. For ZAI0, it only needs to connect to the main power supply.

To prevent interference, separate the IO power supply from the main power supply.

Please select the expansion module according to the requirements, and select IO mapping or axis mapping according to the resources of the expansion module.

Wiring reference of connection between ZIO expansion module and control card and standard wiring of CAN bus are shown as below:



### → Wiring Note:

- ✧ ZMC412 controller uses the single power, and ZIO expansion module uses dual-power. When using, main power supply of expansion module and main power supply of controller can share one power. When they use different power supplies, controller power EGND needs to connect to expansion module power GND, otherwise CAN may be burnt out.
- ✧ When connecting multiple ZIO expansion modules on the CAN bus, a 120-ohm resistor needs to be connected in parallel between the CANL and CANH terminals, for the ZIO expansion module that is with 8-digit dialing codes, the terminal resistor can be realized by dialing the code (DIP).

### 4.3. CAN Bus Expansion Resource Mapping



The ZCAN expansion module generally has an 8-bit DIP switch, dial ON to take effect, and the meaning of the DIP is as follows:

1-4: they are used for ZCAN expansion module IO address mapping, the corresponding value is 0-15.

5-6: CAN communication speed, corresponding value is 0-3, four different speeds are optional.

7: reserved.

8: 120 ohm resistor, dial ON means a 120 ohm resistor is connected between CANL and CANH.

The IO numbers of the entire control system cannot be repeated, and existed numbers must be avoided when mapping resources. And the DIP switch must be dialed before power-on, if re-dial after power-on, it is invalid. It needs to be powered on again to take effect.

Dial 1-4 to select the CAN address, and the controller sets the IO number range of the corresponding expansion module according to the CAN DIP address. When each is dialed as OFF, the corresponding value is 0, when it is ON, it corresponds to a value of 1, and the address combination value = dial 4  $\times$  8 + dial code 3  $\times$  4 + dial code 2  $\times$  2 + dial code 1.

Dial code 5-6 to select CAN bus communication speed, speed combination value = dial code 6  $\times$  2 + dial code 5  $\times$  1, the combined value range is 0-3.

The corresponding speeds are as follows:

DIP 5-6 combination value	CANIO_ADDRESS high 8-bit value	CAN communication speed
0	0 (corresponds to decimal 128)	500KBPS (default value)
1	1 (corresponds to decimal 256)	250KBPS
2	2 (corresponding to decimal 512)	125KBPS
3	3 (corresponding to decimal 768)	1MBPS

The controller side sets the CAN communication speed through the CANIO\_ADDRESS



command. There are also four speed parameters that can be selected. The communication speed must be consistent with the communication speed of the expansion module that corresponds to the combination value, then they can communicate with each other.

The factory default communication speed is 500 KBPS on both sides, there is no need to set this, unless you need to change the speed.

The CANIO\_ADDRESS command is a system parameter, and it can set the master-slave end of CAN communication. The default value of the controller is 32, that is, CANIO\_ADDRESS=32 is the master end, and the slave end is set between 0-31.

The CAN communication configuration can be viewed in the "State the Controller" window.

### → IO Mapping:

the CAN expansion module uses bit1-4 of the DIP switch. According to the number of currently included IO points(the largest number in IN and OP must include IO point in the axis interface), use the bit 1-4 to set the ID, so as to determine the number range of IO to be expanded.

If the controller itself contains 28 INs and 16 OPs, then the starting address set by the first extended board should exceed the maximum value of 28. According to below rule, the dial code should be set to the combination value 1 (binary combination value 0001, from right to left, dial code 1-4, at this time dial 1 is set to ON, and the others are set to OFF), the IO number on the expansion board = the expansion board number value + the initial IO number value, among them, the IOs that are vacant from 29-31 Numbers are not used. Subsequent extended boards continue to confirm the dial settings according to the IO points in turn.

The initial digital IO mapping number starts from 16 and increases in multiples of 16. The distribution of digital IO numbers corresponding to different dial IDs is as follows (ZMC412 motion controller expansion board DIP ID starts from 2 at least, therefore, starting IO number should start from 48 at least):

DIP 1-4 combination value	Starting IO number	Ending IO number
0	16	31
1	32	47
2	48	63
3	64	79
4	80	95

5	96	111
6	112	127
7	128	143
8	144	159
9	160	175
10	176	191
11	192	207
12	208	223
13	224	239
14	240	255
15	256	271

The initial IO mapping number of the analog AD starts from 8 and increases in multiples of 8. The initial IO mapping number of the analog DA starts from 4 and increases in multiples of 4. The allocation of digital IO numbers corresponding to different dial code IDs is as follows:

DIP 1-4 combination value	Starting AD number	End AD number	Starting DA number	End DA number
0	8	15	4	7
1	16	23	8	11
2	24	31	12	15
3	32	39	16	19
4	40	47	20	23
5	48	55	24	27
6	56	63	28	31
7	64	71	32	35
8	72	79	36	39
9	80	87	40	43
10	88	95	44	47
11	96	103	48	51
12	104	111	52	55
13	112	119	56	59
14	120	127	60	63
15	128	135	64	67

→ **Axis Mapping:**

When the CAN bus expansion mode is used to expand the pulse axis, ZIO16082M can be selected to expand two pulse axes. These two pulse axes need to be mapped and bound with the axis No., then access.

Extended axes need to perform axis mapping operations, using the AXIS\_ADDRESS command to map, and the mapping rules are as follows:

AXIS\_ADDRESS(axis No.)=(32\*0)+ID

'the local axis interface of the expansion module AXIS 0

AXIS\_ADDRESS(axis No.)=(32\*1)+ID

'the local axis interface of the expansion module AXIS 1

The ID is the combined value of the DIP bit1-4 of the expansion module. After the mapping is completed and the axis parameters such as ATYPE are set, the expansion axis can be used.

#### Example:

ATYPE(6)=0 'set as virtual axis

AXIS\_ADDRESS(6)=1+(32\*0)

'ZCAN expansion module ID 1 axis 0 is mapped to axis 6

ATYPE(6)=8 'ZCAN extended axis type, pulse direction stepping or servo

UNITS(6)=1000 'pulse equivalent 1000

SPEED(6)=100 'speed 100units/s

ACCEL(6)=1000 'acceleration 1000units/s<sup>2</sup>

MOVE(100) AXIS(6) 'extended axis movement 100units

#### Extended resource viewing:

According to the CAN connection, after the power is turned on, and the wiring resistance dial code is set correctly, the power indication led (POWER) and the running indication led (RUN), the IO power indication led (IO POWER) are on, and the alarm indication led (ALM) is off. At the same time, the "Controller" - "State the controller" - "ZCanNodes" in the ZDevelop software displays the expansion module information and the extended IO number range.

The dial ID and the corresponding resource number when connecting multiple expansion modules are as follows:

Local	432-0(ZMC432)	32	30(0-29)	18(0-17)	0	2(0-1)	
1	48(ZIO1632)	0	16(32-47)	32(32-63)	0	0	
3	26(ZIO16082)	2	16(64-79)	8(64-71)	0	0	
4	10(ZAIO0802)	0	0	0	8(40-47)	2(20-21)	


ALMRM indicator light is on, please check whether the wiring, resistor and dial setting are correct, and whether the CANIO\_ADDRESS command of the controller is set as the master end (32), and whether the CAN communication speed is consistent.



# Chapter V Program & Applications




## 5.1. ZDevelop Software Usage



ZDevelop is a PC-side program development, debugging and diagnostic software for the ZMoiton series motion controllers of Zmotion Technology. Through it, users can easily edit and configure the controller program, quickly develop applications, diagnose system operating parameters in real time, and watch the motion controller. The running program is debugged in real time and supports Chinese and English bilingual environments.

ZBasic, ZPLC and ZHMI can run multi-tasks, and ZBasic can run multi-tasks, and can be mixed with ZPLC and ZHMI.



Step	Operations	Display Interface
1	Open ZDevelop, click "File" – "New Project", Save as window will pop up, then enter file name, save the project file with suffix "zpj".	

2	Click “File” – “New File”, select file type to build, here select Basic, click “OK”.	 <p>The screenshot shows the ZDevelop V3.10.10 application window. The 'File' menu is open, and 'New File' is selected. The 'NewFile' dialog box is displayed, showing 'Basic' as the selected file type. The 'Filename' field contains 'Basic'. The 'OK' button is highlighted.</p>						
3	Double click “AutoRun”, enter task number 0.	 <p>The screenshot shows the 'FileView' window. It contains a table with two columns: 'FileName' and 'AutoRun'. The 'AutoRun' column has a value of 0.</p> <table><thead><tr><th>FileName</th><th>AutoRun</th></tr></thead><tbody><tr><td>Basic1.bas</td><td>0</td></tr><tr><td>Plc1.plc</td><td></td></tr></tbody></table>	FileName	AutoRun	Basic1.bas	0	Plc1.plc	
FileName	AutoRun							
Basic1.bas	0							
Plc1.plc								

4	<p>Edit the program in program editing window, click "save", new built basic file will be saved under "zpj." project automatically. "Save all" means all files under this project will be saved.</p>	
5	<p>Click "controller – connect", if no controller, select connect to simulator.</p>	
	<p>Then, "connect to controller" window will pop up, you can select serial port or net port to connect, select matched serial port</p>	

	parameters or net port IP address, then click "connect".	
6	<p>Click "Ram/Rom" – "download RAM / download ROM", if it is successful, there is print indication, at the same time, program is downloaded into controller and runs automatically.</p> <p>RAM: it will not save when power off. ROM: it will save data when power off, and when the program is connected to controller again, running according to task number.</p>	 



7	Click "Debug" – "Start/Stop Debug" to call "Task" and "Watch" window, because it was downloaded before, here select "Attach the current".	 <p>The screenshot shows the 'Debug' menu of the Zmotion software. The menu items are: Compile All, Start/Stop Debug (highlighted with a blue bar and Ctrl+F5), Go (F5), Step Into (F11), Step Over (F10), Step Out (Shift+F11), Run to Cursor (Ctrl+F10), Toggle Breakpoint (F9), Kill All Breakpoints, Edit Breakpoints, Troubleshooting, and Bus state diagnosis. Below the menu is the 'Enter Debug' dialog box. It has a title bar 'Enter Debug' and a close button 'X'. Inside, it says 'Select enter mode' and has four radio button options: 'Down ram again', 'Down rom again', 'No download, Reset', and 'Attach to current' (which is selected and has a dashed border around it). At the bottom are 'OK' and 'Cancel' buttons.</p>
8	Click "View" – "Scope" to open oscilloscope.	 <p>The screenshot shows the 'Scope' window. It has a title bar 'Scope' and a close button 'X'. Inside, there are several controls: 'Config', 'Start Scope', and 'Stop' buttons at the top. Below them are 'XScale: 1000' and 'YT mode' dropdown. There are checkboxes for 'Continuous acquisition' (unchecked), 'Follow' (checked), and 'Show cursor' (unchecked). Below these are 'Trigger', 'Import', and 'Export' buttons. A table-like structure shows 'show Index Source Offset YScale' with two rows: the first row has '0' in Index, 'MSPEED' in Source, '0' in Offset, and '50' in YScale; the second row has '0' in Index, 'DPOS' in Source, '0' in Offset, and '500' in YScale. On the right is a large oscilloscope display area with a grid. The top right corner of the display shows 'Min:0.00 Max:0.00' in red and 'Min:0.00 Max:0.00' in purple. A vertical dashed line is at the center of the grid, and a horizontal dashed line is at the bottom. The number '1000' is visible in the center of the grid.</p>
<p>Note:</p> <ul style="list-style-type: none"> <li>● When opening an project, choose to open the zpj file of the project. If only the Bas file is opened, the program cannot be downloaded to the controller.</li> <li>● When the project is not created, only the Bas file cannot be downloaded to the controller.</li> <li>● The number 0 in automatic operation represents the task number, and the program</li> </ul>		

runs with task 0, and the task number has no priority.

- If no task number is set for the files in the entire project, when downloading to the controller, the system prompts the following message WARN: no program set autorun

## 5.2. PC Upper-Computer Program Application





The controller supports development under various operating systems such as windows, linux, Mac, Android, and wince, and provides dll libraries in various environments such as vc, c#, vb.net, and labview, as shown in the figure below. PC software programming refers to "ZMotion PC Function Library Programming Manual".





The program developed using the PC software cannot be downloaded to the controller, and it is connected to the controller through the dll dynamic library. The dll library needs to be added to the header file and declared during development.

The c++ project development process in VS is as follows:

Step	Operations	Display Interface
1	Open VS, click "File" – "New" – "Project".	

2	Select development language as "Visual C++" and the select program type as "MFC application type".		
3	Select "Based on basic box", click "next" or "finish"		
4	Find C++ function library provided by manufacturer. Routine is below (64-bit library)		
5	Copy all DLL related library files under the above path to the newly created project.		
6	Add a static library and related header files to the project. Static library: zauxdll.lib,	1) Right-click the header file first, and then select: "Add" → "Existing Item".	

	<p>zmotion.lib</p> <p>Related header files: zauxdll2.h, zmotion.h</p>	<p>2) Add static libraries and related header files in sequence in the pop-up window.</p>	
7	<p>Declare the relevant header files and define the controller connection handle, so far the project is newly created.</p>		 <pre> // single_moveDlg.cpp : implementation file // #include "stdafx.h" #include "single_move.h" #include "single_moveDlg.h" #include "zauxdll2.h"  #ifdef _DEBUG #define new DEBUG_NEW #undef THIS_FILE static char THIS_FILE[] = __FILE__; #endif  // CSingle_moveDlg dialog  ZMC_HANDLE g_handle = NULL; //控制器链接句柄 </pre>

## Chapter VI Run and Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce the probability of equipment failure.

### 6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
power supply	Check whether the voltage is rated	DC 24 V ( -10%~10% )
surroundings	Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature)	-10 °C -55 °C
	Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity)	10 %-95 % non-condensing
	Is there direct sunlight	No
	With or without droplets of water, oil, chemicals, etc.	No
	Whether there is dust, salt, iron filings, dirt	No
	Whether there is corrosive gas	No
	Whether there are flammable and explosive gases or articles	No

	Whether the device is subjected to vibration or shock	Should be within the range of vibration resistance and impact resistance
	Is the heat dissipation good	Keep good ventilation and heat dissipation
Installation and Wiring Status	Whether the basic unit and the expansion unit are installed firmly	The mounting screws should be tightened without loosening
	Whether the connecting cables of the basic unit and the expansion unit are fully inserted	The connection cable cannot be loosened
	Are the screws of the external wiring loose	Screws should be tightened without loosening
	Whether the cable is damaged, aged, cracked	The cable must not have any abnormal appearance

## 6.2. Common Problems

Problems	Suggestions
Motor does not rotate.	<ol style="list-style-type: none"> <li>1. Check whether the ATYPE of the controller is correct.</li> <li>2. Check whether hardware position limit, software position limit, alarm signal work, and whether axis states are normal.</li> <li>3. Check whether motor is enabled successfully.</li> <li>4. Confirm whether pulse amount UNITS and speed values are suitable. If there is the encoder feedback, check whether MPOS changes.</li> <li>5. Check whether pulse mode and pulse mode of drive are matched.</li> <li>6. Check whether alarm is produced on motion controller station or drive station.</li> <li>7. Check whether the wiring is correct.</li> <li>8. Confirm whether controller sends pulses normally.</li> </ol>
The position limit signal is	<ol style="list-style-type: none"> <li>1. Check whether the limit sensor is working normally,</li> </ol>

invalid.	<p>and whether the "input" view can watch the signal change of the limit sensor.</p> <ol style="list-style-type: none"> <li>2. Check whether the mapping of the limit switch is correct.</li> <li>3. Check whether the limit sensor is connected to the common terminal of the controller.</li> </ol>
No signal comes to the input.	<ol style="list-style-type: none"> <li>1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor.</li> <li>2. Check whether the mapping of the limit switch is correct.</li> <li>3. Check whether the limit sensor is connected to the common terminal of the controller.</li> </ol>
The output does not work.	<ol style="list-style-type: none"> <li>1. Check whether IO power is needed.</li> <li>2. Check whether the output number matches the ID of the IO board.</li> </ol>
POWER led is ON, RUN led is OFF.	<ol style="list-style-type: none"> <li>1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the controller alone, and restart the controller after adjustment.</li> <li>2. Check whether the ALM light flickers regularly (hardware problem).</li> </ol>
RUN led is ON, ALM led is ON.	<ol style="list-style-type: none"> <li>1. Program running error, please check ZDevelop error code, and check application program.</li> </ol>
Fail to connect controller to PC through serial port.	<ol style="list-style-type: none"> <li>1. Check whether the serial port parameters are modified by the running program, you can check all the current serial port configurations through ?*SETCOM.</li> <li>2. Check whether the serial port parameters of the PC match the controller.</li> <li>3. Open the device manager and check whether the serial driver of the PC is normal.</li> </ol>
CAN expansion module cannot be connected.	<ol style="list-style-type: none"> <li>1. Check the CAN wiring and power supply circuit, whether the 120 ohm resistor is installed at both ends.</li> </ol>

	<ol style="list-style-type: none"><li>2. Check the master-slave configuration, communication speed configuration, etc.</li><li>3. Check the DIP switch to see if there are multiple expansion modules with the same ID.</li><li>4. Use twisted-pair cables, ground the shielding layer, and use dual power supplies for severe interference (the main power supply of the expansion module and the IO power supply are separately powered)</li></ol>
Fail to connect controller to PC through net port.	<ol style="list-style-type: none"><li>1. Check IP address of PC, it needs to be at the same segment with controller IP address.</li><li>2. Check controller IP address, it can be checked and captured after connection through serial port.</li><li>3. When net port led is off, please check wiring.</li><li>4. Check whether controller power led POWER and running indicator led RUN are ON normally.</li><li>5. Check whether the cable is good quality, change one better cable to try again.</li><li>6. Check whether controller IP conflicts with other devices.</li><li>7. Check whether controller net port channel ETH are all occupied by other devices, disconnect to other devices, then try again.</li><li>8. When there are multiple net cards, don't use other net cards, or change one computer to connect again.</li><li>9. Check PC firewall setting.</li><li>10. Use "Packet Internet Groper" tool (Ping), check whether controller can be Ping, if it can't, please check physical interface or net cable.</li><li>11. Check IP address and MAC address through arp-a.</li></ol>





## Safety Statement



- This chapter describes the safety precautions required for the correct use of this product. Before using this product, please read the instructions for use and correctly understand the relevant information on safety precautions.
- This product should be used in an environment that meets the design specifications, otherwise it may cause equipment damage or personal injury, and malfunctions or component damage caused by failure to comply with relevant regulations are not within the scope of product quality assurance.
- Zmotion will not take any legal responsibility for personal safety accidents and property losses caused by failure to comply with the contents of this manual or illegal operation of products.

## Safety Level Definition

According to the level, it can be divided into " **Danger** " and " **Caution** ". Failure to operate as required may result in moderate injury, minor injury or equipment damage.

Please keep this guide in a safe place for reading when needed, and be sure to hand this manual to the end user.

Install	
 Danger	<ul style="list-style-type: none"><li>◆ When the controller is disassembled, all external power supplies used by the system should be disconnected before operation, otherwise it may cause misoperation or damage to the equipment.</li><li>◆ It is forbidden to use in the following places: places with dust, oil fume, conductive dust, corrosive gas and flammable gas; places exposed to high temperature, condensation, wind and rain; places with vibration and shock. Electric shock, fire and misuse can cause product damage and deterioration.</li></ul>
 Notice	<ul style="list-style-type: none"><li>◆ Avoid metal shavings and wire ends falling into the hardware circuit board during installation.</li><li>◆ After installation, ensure that there are no foreign objects on the hardware circuit board.</li><li>◆ When installing, make it tightly and firmly with the mounting frame.</li></ul>

	<ul style="list-style-type: none"> <li>◆ Improper installation of the controller may result in misoperation, failure and fire.</li> </ul>
<b>Wiring</b>	
 <p><b>Danger</b></p>	<ul style="list-style-type: none"> <li>◆ The specifications and installation methods of the external wiring of the equipment shall comply with the requirements of local power distribution regulations.</li> <li>◆ When wiring, all external power supplies used by the system should be disconnected before operation.</li> <li>◆ When powering on and running after the wiring work is completed, the terminals attached to the product must be installed.</li> <li>◆ Cable terminals should be well insulated to ensure that the insulation distance between cables will not be reduced after the cables are installed on the terminal block.</li> </ul>
 <p><b>Notice</b></p>	<ul style="list-style-type: none"> <li>◆ Avoid metal shavings and wire ends falling into the hardware circuit board during installation.</li> <li>◆ The cable connection should be carried out correctly on the basis of confirming the type of the connected interface.</li> <li>◆ It should be confirmed that the cables pressed into the terminals are in good contact.</li> <li>◆ Do not bundle the control wires and communication cables with the main circuit or power supply wires, etc., and the distance between the wires should be more than 100 mm, otherwise noise may cause malfunction.</li> <li>◆ If the controller is not installed properly, it may cause electric shock or equipment failure or malfunction.</li> </ul>