



Network Motion Control Card


ECI3828




This manual is mainly for ECI3628, ECI3828.




Vision Motion
Controller



Motion
Controller



Motion
Control Card



IO Expansion
Module



HMI

Statement

Thank you for choosing our Zmotion products. Please be sure to read this manual carefully before use so that you can use this product correctly and safely. Zmotion is not responsible for any direct or indirect losses caused by the use of this product.

The copyright of this manual belongs to Shenzhen Zmotion Technology Co., Ltd. And reproduction, translation, and plagiarism of any content in this manual in any form is strictly prohibited without the written permission of Zmotion.

The information in this manual is for reference only. Due to design improvements and other reasons, Zmotion reserves the right of final interpretation of this information! Contents are subject to change without prior notice!

➤ Notes

In order to prevent possible harm and damage caused by incorrect use of this product, the following instructions are given on matters that must be observed.

■ Danger

Do not use it in places with water, corrosive or flammable gases, or near flammable substances.	May cause electric shock, fire, damage, etc.
When installing or disassembling, make sure the product is powered off.	
Cables should be connected securely, and exposed parts that are energized must be insulated by insulators.	
Wiring work must be performed by professionals.	

■ Notes

It should be installed within the specified environmental range.	May cause damage, mis-operation, etc.
Make sure there are no foreign objects on the product hardware circuit board.	
After installation, the product and the mounting bracket should be tight and firm.	
After installation, at least 2-3cm should be left between the product and surrounding components for ventilation and replacement.	
Never disassemble, modify, or repair it by yourself.	

Content

Chapter I Production Information.....	5
1.1. Product Information	5
1.2. Function Features.....	5
1.3. System Frame.....	6
1.4. Hardware Installment.....	7
Chapter II Product Specification	9
2.1. Basic Specification.....	9
2.2. Nameplate & Models	10
2.3. Interface Definition.....	11
2.4. Work Environment	12
Chapter III Wiring & Communication	13
3.1. Power Input Interface.....	13
3.1.1. Power Supply Specification	13
3.2. RS485 / CAN Interface.....	14
3.2.1. RS485/CAN Communication Specification & Wiring.....	14
3.2.2. Basic Usage Method	16
3.3. RS232/RS422 Serial Port	18
3.3.1. RS232/RS422 Interface Specification & Wiring.....	19
3.3.2. Basic Usage Method	20
3.4. IN Digital Input & High-Speed Latch Port	21
3.4.1. Digital Input Specification & Wiring	22
3.4.2. Basic Usage Method	23
3.5. OUT: Digital Output & PWM & Hardware Comparison Output & Single-Ended Pulse Axis	24
3.5.1. Digital Output Specification & Wiring	25
3.5.2. Basic Usage Method	27
3.6. AD/DA: Analog Input / Output	27
3.6.1. Analog Input / Output Specification & Wiring.....	28
3.6.2. Basic Usage Method	28
3.7. ETHERNET	29
3.8. EtherCAT Bus Interface	30

3.9. Axis Interface.....	32
3.9.1. AXIS Interface Signal Specification & Wiring.....	33
3.9.2. Basic Usage Method	36
Chapter IV Expansion Module	38
4.1. CAN Bus Expansion.....	38
4.1.1. CAN Bus Wiring.....	38
4.1.2. CAN Bus Expansion Resource Mapping.....	40
4.2. EtherCAT Bus Expansion	44
4.1.1. EtherCAT Bus Expansion Wiring	44
4.1.2. EtherCAT Bus Expansion Resource Mapping	46
Chapter V Programming.....	48
5.1. Program in RTSys Software	48
5.2. Upgrade Controller Firmware	53
5.3. Program in Host-Computer by PC Languages	54
Chapter VI Operation and Maintain.....	57
6.1. Regular Inspection and Maintenance	57
6.2. Common Problems & Solutions	58

Chapter I Production Information

1.1. Product Information

ECI3828 supports up to 16 axes of linear interpolation, any circular interpolation, space arc, helical interpolation, electronic cam, electronic gear, synchronization follow, virtual axes setting, etc.


ECI3000 series economical multi-axis motion control card can be used in those pulse applications within 16 pulse axes, such as, electronic semiconductor equipment (testing equipment, assembly equipment, locking equipment, soldering machine), dispensing equipment, assembly line, etc.

1.2. Function Features

- ◆ Support 8 real pulse axes.
- ◆ Pulse output mode: pulse / direction or dual pulses.
- ◆ The refresh cycle of EtherCAT bus is 1ms.
- ◆ AXIS interface supports encoder position measurement, which can be configured as handwheel input mode.
- ◆ Maximum pulse frequency output of each axis: 10MHZ.
- ◆ 256 isolation inputs and 256 isolation outputs can be extended at most by EtherCAT.
- ◆ Axis position limit signal / origin signal port can be configured as any input at will.
- ◆ The maximum output current of general digital outputs can reach 300mA, which can directly drive some kinds of solenoid valves.
- ◆ Interfaces: RS232, RS422, RS485, Ethernet, EtherCAT


- ◆ Support linear interpolation, any circular interpolation, helical interpolation of 12 axes at most.
- ◆ Support electronic cam, electronic gear, **position latch**, synchronization follow, virtual axis setting, etc.
- ◆ Support **hardware comparison output (HW_PSWITCH2)**, **hardware timer** and **precision output when in motion**.
- ◆ A variety of program encryption methods to protect the intellectual property rights of customers.

1.3. System Frame



1.4. Hardware Installment

ECI3828 motion control card adopts the horizontal installation method of screw fixing, and each controller should be installed with 4 screws for fastening.



→ Unit: mm

→ Installation Hole Diameter: 4.5mm

 Installation attention	<ul style="list-style-type: none"> Non-professionals are strictly prohibited to operate. Specifically, professionals who had been trained related electrical equipment, or who master electrical knowledge. Please be sure to read the product instruction manual and safety precautions carefully before installation. Before installation, please ensure that the product is powered off. Do not disassemble the module, otherwise the machine may be damaged. Avoid direct sunlight installation.
--	---

	<ul style="list-style-type: none">● In order to facilitate ventilation and controller replacement, 2-3cm should be left between the upper and lower parts of the controller and the installation environment and surrounding components.● Considering the convenient operation and maintenance of the controller, please do not install the controller in the following places:<ol style="list-style-type: none">a) places where the surrounding ambient temperature exceeds the range of -10°C-55°Cb) places where the ambient humidity exceeds the range of 10%-95% (non-condensing)c) places with corrosive gases and flammable gasesd) places with many conductive powders such as dust and iron powder, oil mist, salt, and organic solvents
--	--

Chapter II Product Specification


2.1. Basic Specification

Item	Description
Model	ECI3828
Basic Axes	8
Max Extended Axes	16
Basic Axes Type	EtherCAT, pulse outputs, encoder inputs
Digital IO	There are 26 inputs and 18 outputs (the former 16 channels are with overcurrent protection)
Max Extended IO	256 inputs and 256 outputs
AD/DA	2 general ADs and 2 general DAs (0-10V)
Max Extended AD/DA	256 ADs and 128 DAs
Pulse Bit	32
Encoder Bit	32
Speed Acceleration Bit	32
Pulse Max Frequency	10MHz
Motion Axis Buffer	512
Array Space	15000
Program Space	128KByte
Flash Space	8MByte
Power Supply Input	24V DC input
Communication Interfaces	RS232, RS422, RS485, EtherNet, CAN, EtherCAT
Dimensions	205mm*135.25mm

2.2. Nameplate & Models

ECI3828-XXX	
Mark	Product
ECI3828	Motion Control Card
Mark	Other Function
XXX	Customized Function
Mark	Axis
6	6 Pulse Axes
8	8 Pulse Axes
Mark	Functions
8	Point, Line, Arc, Electronic Cam, Continuous Motion
Model	Description
ECI3628	6 axes, point to point, electronic cam, linear interpolation, circular interpolation, continuous interpolation, robotic arm.
ECI3828	8 axes, point to point, electronic cam, linear interpolation, circular interpolation, continuous interpolation, robotic arm.

2.3. Interface Definition



→ Interface Description

Mark	Interface	Number	Description
POWER	Status Indication Led	1	Power indicator: it lights when power is conducted.
RUN		1	Run indicator: it lights when runs normally
ALM		1	Error indicator: it lights when runs abnormally
RS232	RS232 serial port	1	Use MODBUS_RTU protocol
RS422	RS422 serial port	1	Use MODBUS_RTU protocol
RS485	RS485 serial port	1	Use MODBUS_RTU protocol
EtherCAT	EtherCAT Bus interface	1	EtherCAT bus interface, connect to EtherCAT bus drive and EtherCAT bus expansion module.
ETHERNET	Net port	1	Use MODBUS_TCP protocol, expand Ethernet through interchanger, the number of net port

			channels can be checked through "?*port", default IP address id 192.168.0.11
E+24V	Main power	1	24V DC power supplies for controller
CAN	CAN bus interface	1	Connect to CAN expansion module and CAN equipment of other standards
IN	Digital IO input	24	NPN type, IN0-3 support latch function, IN-2, 21-32 support encoder function.
OUT	Digital IO output	16	NPN type, OUT0-1 support PWM function, OUT0-3 support hardware comparison output function.
AD	Analog input	2	Resolution: 12 bits, 0-10V
DA	Analog output	2	Resolution: 12 bits, 0-10V
AXIS	Pulse axis	2	It includes differential pulse output and differential encoder input

2.4. Work Environment

Item	Parameters	
Work Temperature	-10°C-55°C	
Work relative Humidity	10%-95% non-condensing	
Storage Temperature	-40°C ~ 80°C (not frozen)	
Storage Humidity	Below 90%RH (no frost)	
vibration	Frequency	5-150Hz
	Displacement	3.5mm(directly install)(<9Hz)
	Acceleration	1g(directly install)(>9Hz)
	Direction	3 axial direction
Shock (collide)	15g, 11ms, half sinusoid, 3 axial direction	
Degree of Protection	IP20	

Chapter III Wiring & Communication

3.1. Power Input Interface

→ Terminal Definition:

Terminal	Name	Type	Function
	E+24V	Input	Input for power supply 24V
	EGND	Input	Power ground
	FG	Grounding	Shield/Protection

Note:

1. ECI3828 controller is supplied by single-power, please make sure the quality of power supply.
2. Controller 5V pulse axis and encoder interface use internal power supply, and IO uses external power. Axes and encoder expanded by ZIO expansion module use external power supply.

3.1.1. Power Supply Specification

→ Specification

Item	Description
Voltage	DC24V (-5%~5%)
Current to open	≤0.5A
Current to work	≤0.4A
Anti-reverse connection	Yes
Overcurrent Protection	Yes

3.2. RS485 / CAN Interface

This interface adopts 5Pin screw-type pluggable terminal with a spacing of 5.08mm. This terminal is shared by RS485 serial communication and CAN communication.

→ Terminal Definition

Terminal	Name	Function
485B	485B	485-
485A	485A	485+
EGND	EGND	External power ground
CANL	CANL	CAN differential data -
CANH	CANH	CAN differential data +

3.2.1. RS485/CAN Communication Specification & Wiring


The CAN interface of the controller adopts the standard CAN communication protocol, which mainly includes three ports, CANL, CANH and the public end. And it supports connecting CAN expansion modules and other standard CAN devices.

→ Specification


Item	CAN	RS485 (port1)
Max Communication Rate (bps)	1M	115200
Terminal Resistor	120Ω	No
Topology	Daisy chain connection structure	
The number of nodes can be extended	Up to 16	Up to 127
Communication Distance	Longer communication distance, lower communication rate, max 30m is recommended.	

→ Wiring Reference

Connect the CANH and CANL of the standard CAN module to the CANL and CANH of the other side correspondingly. And public ends of the CAN bus communication both parties are connected together. In CAN bus left and right sides, connect a 120Ω resistor respectively (please see below graphic).



Connect 485A and 485B of RS485 to corresponding 485A and 485B of controller, and connect public end EGND of RS485 communication both sides together.



→ Wiring Notes:


- As above, the daisy chain topology is used for wiring (the star topology structure cannot be used). When the use environment is ideal and there are no many nodes, the branch structure also can be used.
- The communication interface of ECI3828 adopts external 24V power supply, please

pay attention to connect other controllers or HMI.

- Please connect a 120Ω terminal resistor in parallel to each end of the CAN bus for matching the circuit impedance and ensuring communication stability.
- Please be sure to connect the public ends of each node on the CAN bus to prevent the CAN chip from burning out.
- Please use STP (Shielded Twisted Pair), especially in bad environments, and make sure the shielding layer is fully grounded.
- When on-site wiring, pay attention to make the distance between strong current and weak current, it is recommended for the distance to be more than 20cm.
- It should be noted that the equipment grounding (chassis) on the entire line must be good, and the grounding of the chassis should be connected to the standard factory ground pile.

→ **Cable Requirements:**

Shielded Twisted Pair, and the shielded cable is grounded.



3.2.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use ETHERNET, RS232 (default parameter, which can be

connected directly) or RS485 (default parameter, which can be connected directly, for hardware, an adapter is needed) to connect to [RTSys](#).

- (3) Please use "ADDRESS" and "SETCOM" command to set and view protocol station No. and configuration parameters. Please refer to the "[Basic Programming Manual](#)" for details.
- (4) Please use the "CANIO_ADDRESS" command to set the master's "address" and "speed" according to the needs, and use the "CANIO_ENABLE" command to enable or disable the internal CAN master function, or through "RTSys/Controller/State the Controller/Communication Info" to view the CAN status intuitively, and refer to the "Basic Programming Manual" for details.

```
CAN communication settings:  
CANIO_ADDRESS = 32, CANIO_ENABLE = 1  
ZCAN Master  
CAN baud: 500KBPS  
CAN enable: ON  
  
Serial port configuration:  
Port0:(RS232) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0  
Port1:(RS485) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0  
Port2:(RS422) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0
```

- (5) According to description, set parameters related to the third party equipment correctly to match each nodes.
- (6) Correctly set the "address" and "speed" of the slave station expansion module according to the manual of the slave station.
- (7) After all the settings are completed, restart the power supply of all stations to establish communication.

(8) Note that the "speed" settings of each node on the CAN bus must be consistent, and the "address" settings cannot cause conflicts, otherwise the "ALM" alarm light will be on, and the communication establishment will fail or the communication will be disordered.

3.3. RS232/RS422 Serial Port

RS232/RS422 is in one standard DB9 male socket and supports MODBUS_RTU protocol and custom communication.

→ **Interface Definition**

Terminal	PIN	Name	Function
	1	422TX+	RS422 Send +
	2	232RXD	RS232 signal, receive data
	3	232TXD	RS232 signal, send data
	4	422RX+	RS422 Receive +
	5	GND	5V power supply ground / communication public end
	6	422TX-	RS422 Send -
	7	422RX-	RS422 Receive-
	8	NC	Reserved
	9	+5V	5V power supply output (+), max is 300mA

Note:


1. RS232 is Port 0, RS485 is Port 1 and RS422 is Port 2.
2. The latest version supports RS422 interface.

3.3.1. RS232/RS422 Interface Specification & Wiring


→ Specification:

Item	RS232	RS422
Max Communication Rate (bps)	115200	115200
Terminal Resistor	No	No
Topology Structure	Connect correspondingly (1 to 1)	One point is connected to multiple
The number of nodes can be extended	1	10
Communication Distance	The Longer communication distance is, the lower communication rate is, maximum 5m is recommended.	The Longer communication distance is, the lower communication rate is, maximum 30m is recommended.

→ Wiring Reference: (RS232)



→ Wiring Reference: (RS422)



→ **Wiring Notes:**

- The wiring of RS232 and RS422 are as above, it needs to cross-wiring for sending and receiving signals, and it is recommended to use a double-female head cross line when connecting to a computer.
- Please be sure to connect the public ends of each communication node to prevent the communication chip from burning out.
- Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.

3.3.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any ETHERNET or RS232 (there is default parameter, which can be connected directly) to connect to [RTSys](#).
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configured parameters, see "Basic Programming Manual" for details.
- (4) According to their respectively instructions, correctly set the relevant parameters of the third-party equipment to match the parameters of each node.
- (5) When all is configured, it can start to do communicating.
- (6) Communication data of RS232 can be directly viewed through "RTSys / Controller / State the Controller / CommunicationInfo".

3.4. IN Digital Input & High-Speed Latch Port

The digital input adopts 3 groups of 10Pin screw-type pluggable terminals, and the gap distance between terminals should be 5.08mm. In addition, the **high-speed latch function and encoder functions** are integrated in digital input signal.

→ Wiring Definition

Terminal	Name	Type	Function 1	Function 2	Function 3
EGND	EGND	/	IO Public End	/	/
	EGND	/		/	/
IN0	IN0	NPN type, high-speed input	Input 0	Latch A	Encoder EA2
	IN1		Input 1	Latch B	Encoder EB2
	IN2		Input 2	Latch C	Encoder EZ2
	IN3		Input 3	Latch D	/
	IN4		Input 4	/	/
	IN5		Input 5	/	/
	IN6		Input 6	/	/
	IN7		Input 7	/	/
EGND	EGND	/	IO Public End	/	/
	EGND	/		/	/
IN8	IN8	NPN type, low-speed input	Input 8	/	/
	IN9		Input 9	/	/
	IN10		Input 10	/	/
	IN11		Input 11	/	/
	IN12		Input 12	/	/
	IN13		Input 13	/	/
	IN14		Input 14	/	/
	IN15		Input 15	/	/
EGND	EGND	/	IO Public End	/	/
	EGND	/		/	/
IN16	IN16	NPN type, low-speed input	Input 16	/	/
	IN17		Input 17	/	/
	IN18		Input 18	/	/
	IN19		Input 19	/	/
	IN20		Input 20	/	/
	IN21		Input 21	/	Encoder EZ3
	IN22		Input 22	/	Encoder EB3

	IN23		Input 23	/	Encoder EA3
Note:					
1.	Input 0 and input 1 both have latch input A and latch input B function.				
2.	ECI3828 supports 4-channel latch, it can use REG_INPUTS to configure in the software.				
3.	IN0-2 have 24V high-speed encoder function, as encoder 2 to input. IN21-23 have low-speed encoder function, as encoder 3 to input.				

3.4.1. Digital Input Specification & Wiring


→ Specification

Item	High-Speed Input (IN0-3)	Low-Speed Input (IN4-23)
Input mode	NPN type, the input is triggered when by low-electric level	
Frequency	<100kHz	<5kHz
Impedance	3.3KΩ	4.7KΩ
Voltage level	DC24V	DC24V
The voltage to open	<15V	<14.5V
The voltage to close	>15.1V	>14.7V
Minimal current	-2.3mA (negative)	-1.8mA (negative)
Max current	-7.5mA (negative)	-6mA (negative)
Isolation mode	optoelectronic isolation	optoelectronic isolation


Note: the above parameters are standard values when the voltage of controller power supply (E+24V port) is 24V.

→ Wiring Reference

➤ General Wiring



➤ Single-Ended Encoder Wiring



→ Wiring Note:

- For the public end, please connect the "EGND" port on the IO to the "COM" terminal of the external input device. If the signal area power supply of the external device and the power supply of the controller are in the same power supply system, this connection also can be omitted.

3.4.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please select ETHERNET, RS232 (default parameter, which can be connected directly) and RS485 (default parameter, which can be connected directly, for hardware, an adapter is needed) to connect to [RTSys](#).
- (3) State values of relative input ports can be read directly through "IN" command, also, it can be read through "RTSys/Tool/In". Please refer to "Basic" for details.
- (4) Latch function can be set and triggered through "REGIST" instruction, in software, use REG_INPUTS to configure. Please refer to "ZBasic" for details.

3.5.OUT: Digital Output & PWM & Hardware Comparison

Output & Single-Ended Pulse Axis

The digital output adopts 2 sets of 10Pin screw-type pluggable terminals with a spacing of 5.08mm, and the PWM, hardware comparison output, single-ended pulse axis functions are integrated in digital output signal.

→ Wiring Definition

Terminal	Name	Type	Function 1	Function2	Function3	Function4
EGND E5V OUT0 OUT1 OUT2 OUT3 OUT4 OUT5 OUT6 OUT7	EGND	/	IO Public End	/	/	/
	E5V	/	5V power output generated from 24V	/	/	/
	OUT0	NPN, high- speed output	Output 0	PWM Out 0	PUL2	Hardware comparison output
	OUT1		Output 1	PWM Out 1	DIR2	
	OUT2		Output 2	/	PUL3	
	OUT3		Output 3	/	DIR3	
	OUT4	NPN, low- speed output	Output 4	/	/	/
	OUT5		Output 5	/	/	/
	OUT6		Output 6	/	/	/
	OUT7		Output 7	/	/	/
EGND EGND OUT8 OUT9 OUT10 OUT11 OUT12 OUT13 OUT14 OUT15	EGND	/	IO Public End	/	/	
	EGND			/	/	
	OUT8	NPN type, low- speed output	Output 8	/	/	
	OUT9		Output 9	/	/	
	OUT10		Output 10	/	/	
	OUT11		Output 11	/	/	
	OUT12		Output 12	/	/	
	OUT13		Output 13	/	/	
	OUT14		Output 14	/	/	
	OUT15		Output 15	/	/	

Note:

- Each axis signal has one additional general output without current amplification, please refer to

axis interface.

- ✧ OUT0-1 have PWM function, when PWM is shutdown, they are general outputs.
- ✧ OUT0-3 support single-ended axis 2-3 function and hardware comparison output function.

3.5.1. Digital Output Specification & Wiring

→ Specification


Item	High Speed Output (OUT0-3)	Low Speed Output (OUT4-15)
Output mode	NPN type, it is 0V when there is output.	
Frequency	< 400kHz	< 8kHz
Voltage level	DC24V	DC24V
Max output current	+300mA	+300mA
Max leakage current when off	25µA	25µA
Respond time to conduct	1µs (resistive load typical value)	12µs
Respond time to close	3µs	80µs
Overcurrent protection	Support	Support
Isolation method	optoelectronic isolation	optoelectronic isolation

Note:


- ✧ The times in the form are typical based on the resistive load, and may change when the load circuit changes.
- ✧ Due to the leak-type output, the shutdown of the output will be obviously affected by the external load circuit, and the output frequency should not be set too high in the application. For high-speed output, it is recommended to be lower than 400KHz, for low-speed output, it is recommended to be lower than 8KHz. If there needs higher speed, please contact us to adjust parameter or custom hardware.

→ Wiring Reference

➤ General Wiring



➤ Single-Ended Encoder Wiring



[1] for 5V pulse directional interface, please connect PUL+ and DIR+ to E5V.

→ Wiring Note:

- For the connection of the public end, please connect the "EGND" port on IO to the negative pole of the DC power supply of the external input device. If the DC power

supply of the external device and the controller power supply are in the same power supply system, this connection can also be omitted.

- E5V port is the output terminal of 5V power supply, this power terminal can be used when input load of external 5V power supply needs to be provided, the maximum current is 300mA.


3.5.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use ETHERNET, RS232 or RS485 to connect to [RTSys](#).
- (3) Open or close output port directly through "OP" command, also, it can be opened or closed through "RTSys/Tool/Op". Please refer to "Basic" for details.
- (4) The PWM function, set the frequency and duty cycle through "PWM_FREQ" and "PWM_DUTY". Please refer to Basic for details.
- (5) The hardware comparison output function can be set through "HW_PSWITCH2" instruction. Please refer to Basic for details.

3.6. AD/DA: Analog Input / Output

The analog port adopts a set of 5Pin screw-type pluggable terminals with a spacing of 5.08mm.

→ [Wiring Definition](#)

Terminal	Name	Type	Function
	DA0	Output	Analog output terminal AOUT(0)
	DA1		Analog output terminal AOUT(1)
	AGND	Public end	analog public end
	ADD	Input	Analog input terminal AIN(0)
	AD1		Analog input terminal AIN(1)


Note: ECI3828 inner AD and DA use internal power supply.

3.6.1. Analog Input / Output Specification & Wiring

→ Specification

Item	AD (0-1)	DA (0-1)
Resolution	12-bit	12-bit
Data range	0-4095	0-4095
Signal range	0-10V input	0-10V output
Data refresh ratio	1KHz	1KHz
Voltage input impedance / output load	>300KΩ (voltage input impedance)	>10KΩ (voltage output load)

→ Wiring Reference



→ Wiring Note:

- The analog input/output wiring method is as shown in the figure above, and the external load signal range must match with this signal range.
- Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.


3.6.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use ETHERNET or RS232 to connect to [RTSys](#).

(3) Analog input voltage can be read through "AIN" command and corresponding analog voltage can be output through "AOUT" command, also, data of each channel can be checked through "RTSys/Tool/AD/DA". Please refer to "Basic" for details.

3.7.ETHERNET

ECI3828 motion controller has an Ethernet port, and it supports MODBUS_TCP protocol and custom communication, and the default IP address is 192.168.0.11. The pin definition is as follows:




PIN	Signal	Description
1	TX+	Send signal (+)
2	TX-	Send signal (-)
3	RX+	Receive signal (+)
4	NC	Reserved
5	NC	Reserved
6	RX-	Receive signal (-)
7	NC	Reserved
8	NC	Reserved

The Ethernet port of the controller can be connected to a computer, HMI, etc. through an Ethernet cable, and using point to point connection method. The schematic diagram is as follows:



The controller can also be connected to the interchanger through an Ethernet cable, and then use interchanger to connect to other devices, then multi-point connection can be achieved. The schematic diagram is as follows:



3.8. EtherCAT Bus Interface

ECI3828 network motion control card has a 100M EtherCAT communication interface, and it supports EtherCAT protocol. In addition, EtherCAT driver or EtherCAT expansion module can be connected. The pin definition is as follows:

The diagram shows the EtherCAT interface port on the ECI3828 card, with 8 pins labeled 1 through 8. Lines connect these pins to the corresponding columns in the pin definition table.

PIN	Signal	Description
1	TX+	Send signal (+)
2	TX-	Send signal (-)
3	RX+	Receive signal (+)
4	NC	Reserved
5	NC	Reserved
6	RX-	Receive signal (-)
7	NC	Reserved
8	NC	Reserved

→ Specification


Item	Specification
Communication protocol	EtherCAT protocol
Valid service	CoE(PDO, SDO), FoE
Synchronization method	IO adopts input and output synchronization / DC-distributed clock
Physical level	100BASE-TX
Duplex mode	Full duplex

Topology	linear topology
Transfer media	Cable
Transfer distance	It is less than 100M between 2 nodes
Process data	Maximum 1486 bytes of one single frame
Synchronization shaking of two slave stations	<1us
Refresh	1000 digital input and output about is 30us, 16 servo axes is about 100us

→ Communication Cable Requirements

ETHERNET communication interface adopts standard Ethernet RJ45 interface.

The network cable adopts Category 5e STP, and the crystal head has a metal shell to reduce interference and to prevent information from being eavesdropped. As shown below:



Item	Specification
Cable type	Flexible crossover cable, Category 5e
traverse	twisted pair
Line pairs	4
Isolation	cross skeleton
Connector	Crystal head with iron shell
Cable material	PVC
Cable length	Less than 100m

Use RJ45 network cable connection method:

- When installing, hold the crystal head that is with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.

- When disassembling, press the tail mechanism of the crystal head, and pull out the connector and the module in a horizontal direction.


Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.

3.9. Axis Interface

This product provides 2 local differential pulse axis interfaces, each interface is a standard DB26 female socket. Each terminal provides 0V and +5V output, which can provide 5V power for the encoder.

Before the axis is used, the use mode of the axis must be configured through the ATYPE parameter.

→ Interface Definition

Interface	Pin	Signal	Description
	1	EGND	Negative pole of 24V digital IO power
	2	IN24-25/ALM	General input (recommended as driver alarm)
	3	OUT16-17/ENBALE	General output (recommended as driver enable)
	4	EA-	Encoder differential input signal A-
	5	EB-	Encoder differential input signal B-
	6	EZ-	Encoder differential input signal Z-
	7	+5V	5V power (+) of pulse/encoder signal
	8	Reserved	Reserved
	9	DIR+	Servo or step direction output +
	10	GND	5V power (-) of pulse/encoder signal
	11	PUL-	Servo or step pulse output -
	12	Reserved	Reserved
	13	GND	5V power (-) of pulse/encoder signal
	14	OVCC	Positive pole of IO 24V power
	15	Reserved	Reserved
	16	Reserved	Reserved
	17	EA+	Encoder differential input signal A+

	18	EB+	Encoder differential input signal B+
	19	EZ+	Encoder differential input signal Z+
	20	GND	5V power (-) of pulse/encoder signal
	21	GND	
	22	DIR-	Servo or step direction output -
	23	PUL+	Servo or step pulse output +
	24	GND	5V power (-) of pulse/encoder signal
	25	Reserved	Reserved
	26	Reserved	Reserved

Note:

- ◊ Alarm input and axis enable output are used as general input and output at the same time, when it is output, output small current.
- ◊ ECI3828 differential pulse axis and differential encoder input are only for axis 0 and axis 1.
- ◊ Axis 2 and axis 3 are low-speed single-ended pulse interface OUT2-3, which can be modified to take effect through ATYPE.
- ◊ High-speed single-end encoder input of axis 2 is IN0-2, low-speed single-end encoder input of axis 3 is IN21-IN23.

➤ **Pulse-Axis PIN No. & IO Relation:**

Pulse Axis No.	IN (PIN2)	OUT (PIN3)
AXIS0	IN24	OUT16
AXIS1	IN25	OUT17

3.9.1. AXIS Interface Signal Specification & Wiring


→ **Specification:**

Signal	Item	Description
PUL/DIR	Signal type	Differential output signal
	Voltage range	0-5V
	Maximum frequency	10MHz
EA/EB/EZ	Signal type	Differential input signal
	Voltage range	0-5V
	Maximum frequency	5MHz


IN24-25	Input method	NPN type, it is triggered when low electric level is input.
	Frequency	< 5kHz
	Impedance	6.8KΩ
	Voltage level	DC24V
	The voltage to open	<10.5V
	The voltage to close	>10.7V
	Minimal current	-1.8mA (negative)
	Maximum current	-4mA (negative)
	Isolation	optoelectronic isolation
OUT16-17	Output method	NPN leak type, it is 0V when outputs
	Frequency	< 8kHz
	Voltage level	DC24V
	Maximum current	+50mA
	Overcurrent protection	No
	Isolation	optoelectronic isolation
+5V, GND	Maximum output current for 5V	50mA
OVCC, EGND	Maximum output current for 24V	50mA

→ **Wiring Reference:**


➤ Reference example of wiring with Panasonic A5/A6 servo driver.



➤ Single-Ended Pulse Axis Wiring:



➤ **Single-Ended Encoder Wiring:**




→ **Wiring Note:**

- ✧ The wiring principle of the differential pulse axis interface is shown in the figure above, and the wiring methods of different types of drivers are different, please connect carefully.
- ✧ If the speed can meet the requirements, use low-speed differential pulse port preferentially. When high-speed differential pulse interface is used, controller internal digital ground must be connected to drive high-speed pulse reference ground.
- ✧ Please use STP, especially there is bad environment, make sure shield layer is fully grounded.
- ✧ Some servo drives are not isolated by optocoupler. At this time, the GND must be connected to the GND of the driver. Most of the drive encoders are not isolated by optocoupler. When connecting the encoder, GND must be connected.

3.9.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After power on, please use ETHERNET or RS232 (default parameter, it can be connected directly) to connect to RTSys.

- (3) Set axis parameters, such as, ATYPE, UNITS, SPEED, ACCEL, FWD_IN, REV_IN, etc.
- (4) There are many parameters related to pulse axis, they can be set and checked through relative instructions, please see "axis parameter and axis status" of "Basic", or see "RTSys/Tool/Axis parameter".
- (5) Control corresponding motion through "View – Manual".



Refer to BASIC Routine:

BASE(0,1)	'select axis 0 and axis 1
ATYPE = 1,1	'set axis 0 and axis 1 as pulse axes
UNITS = 1000,1000	'set pulse amount as 1000 pulses
SPEED = 10,10	'set axis speed as 100*1000 pulse/s
ACCEL = 1000,1000	'set axis acceleration as 1000*1000 pulse/s/s
FWD_IN = -1,-1	'prohibit using axis positive hardware position limit
REV_IN = -1,-1	'prohibit using axis negative hardware position limit
MOVE(10) AXIS(0)	'axis 0 moves distance of 10*1000 pulses in positive
MOVE(-20) AXIS(0)	'axis 0 moves distance of 20*1000 pulses in negative

Chapter IV Expansion Module

CAN expansion modules ([ZIO series expansion modules](#) or [ZMIO310-CAN coupler with sub modules](#)) and EtherCAT expansion modules ([EIO series expansion modules](#) or [ZMIO310-ECAT coupler with sub modules](#)) can be used.

Connect control card to CAN bus expansion modules, when the eighth bit of the DIP switch of the expansion module is turned to ON, which indicates that a 120-ohm resistor has been connected, but needs to connect one 120-ohm resistor externally. When connecting multiple CAN expansion modules, you only need to dial ON for the eighth digit of the last expansion module, which means please do not dial bit-8 of other modules.

4.1. CAN Bus Expansion

controller + ZIO expansion module, when the eighth bit of the DIP switch of the expansion module is turned to ON, which indicates that a 120-ohm resistor has been connected, but needs to connect one 120-ohm resistor externally. When connecting multiple CAN expansion modules, you only need to dial ON for the eighth digit of the last expansion module, which means please do not dial bit-8 of other modules.


4.1.1. CAN Bus Wiring

The ZIO expansion module is powered by the dual power supply. Except the main power supply, an additional IO power supply is required to supply independent power for IO. Both the main power supply and the IO power supply use 24V DC power supply. For ZAIO, it only needs to connect to the main power supply.

To prevent interference, separate the IO power supply from the main power supply.

Please select the expansion module according to the requirements, and select IO mapping or axis mapping according to the resources of the expansion module.


Wiring reference of connection between ZIO expansion module and control card and standard wiring of CAN bus are shown as below:



→ Wiring Note:

- ✧ ECI3828 control card uses the single power, and ZIO expansion module uses dual-power. When using, main power supply of expansion module and main power supply of controller can share one power. When they use different power supplies, controller power EGND needs to connect to expansion module power GND, otherwise CAN may be burnt out.
- ✧ When connecting multiple ZIO expansion modules on the CAN bus, a 120-ohm resistor needs to be connected in parallel between the CANL and CANH terminals, for the ZIO expansion module that is with 8-digit dialing codes, the terminal resistor can be realized by dialing the code (DIP).

4.1.2. CAN Bus Expansion Resource Mapping



The ZCAN expansion module generally has an 8-bit DIP switch, dial ON to take effect, and the meaning of the DIP is as follows:

1-4: they are used for ZCAN expansion module IO address mapping, the corresponding value is 0-15.

5-6: CAN communication speed, corresponding value is 0-3, four different speeds are optional.

7: reserved.

8: 120-ohm resistor, dial ON means a 120-ohm resistor is connected between CANL and CANH.

The IO numbers of the entire control system cannot be repeated, and existed numbers must be avoided when mapping resources. And the DIP switch must be dialed before power-on, if re-dial after power-on, it is invalid. It needs to be powered on again to take effect.

Dial 1-4 to select the CAN address, and the controller sets the IO number range of the corresponding expansion module according to the CAN DIP address. When each is dialed as OFF, the corresponding value is 0, when it is ON, it corresponds to a value of 1, and the address combination value = dial 4 × 8 + dial code 3 × 4 + dial code 2 × 2 + dial code 1.

Dial code 5-6 to select CAN bus communication speed, speed combination value=dial code 6 × 2 + dial code 5×1, the combined value range is 0-3.

The corresponding speeds are as follows:

DIP 5-6 combination value	CANIO_ADDRESS high 8-bit value	CAN communication speed
0	0 (corresponds to decimal 128)	500KBPS (default value)
1	1 (corresponds to decimal 256)	250KBPS

2	2 (corresponding to decimal 512)	125KBPS
3	3 (corresponding to decimal 768)	1MBPS

The controller side sets the CAN communication speed through the CANIO_ADDRESS command. There are also four speed parameters that can be selected. The communication speed must be consistent with the communication speed of the expansion module that corresponds to the combination value, then they can communicate with each other.

The factory default communication speed is 500 KBPS on both sides, there is no need to set this, unless you need to change the speed.

The CANIO_ADDRESS command is a system parameter, and it can set the master-slave end of CAN communication. The default value of the controller is 32, that is, CANIO_ADDRESS=32 is the master end, and the slave end is set between 0-31.

The CAN communication configuration can be viewed in the "State the Controller" window.

→ IO Mapping:

the CAN expansion module uses bit1-4 of the DIP switch. According to the number of currently included IO points (the largest number in IN and OP must include IO point in the axis interface), use the bit 1-4 to set the ID, so as to determine the number range of IO to be expanded.

If the controller itself contains 28 INs and 16 OPs, then the starting address set by the first extended board should exceed the maximum value of 28. According to below rule, the dial code should be set to the combination value 1 (binary combination value 0001, from right to left, dial code 1-4, at this time dial 1 is set to ON, and the others are set to OFF), the IO number on the expansion board = the expansion board number value + the initial IO number value, among them, the IOs that are vacant from 29-31 Numbers are not used. Subsequent extended boards continue to confirm the dial settings according to the IO points in turn.

The initial digital IO mapping number starts from 16 and increases in multiples of 16. The distribution of digital IO numbers corresponding to different dial IDs is as follows.

DIP 1-4 combination value	Starting IO number	End IO number
0	16	31
1	32	47
2	48	63
3	64	79
4	80	95
5	96	111
6	112	127
7	128	143
8	144	159
9	160	175
10	176	191
11	192	207
12	208	223
13	224	239
14	240	255
15	256	271

The initial IO mapping number of the analog AD starts from 8 and increases in multiples of 8. The initial IO mapping number of the analog DA starts from 4 and increases in multiples of 4. The allocation of digital IO numbers corresponding to different dial code IDs is as follows:

DIP 1-4 combination value	Starting AD number	End AD number	Starting DA number	End DA number
0	8	15	4	7
1	16	23	8	11
2	24	31	12	15
3	32	39	16	19
4	40	47	20	23
5	48	55	24	27
6	56	63	28	31
7	64	71	32	35
8	72	79	36	39
9	80	87	40	43
10	88	95	44	47

11	96	103	48	51
12	104	111	52	55
13	112	119	56	59
14	120	127	60	63
15	128	135	64	67

→ Axis Mapping:

When the CAN bus expansion mode is used to expand the pulse axis, 2 pulses axes are extended. These two pulse axes need to be mapped and bound with the axis No., then access.

Extended axes need to perform axis mapping operations, using the AXIS_ADDRESS command to map, and the mapping rules are as follows:

AXIS_ADDRESS(axis No.)=(32*0)+ID

'the local axis interface of the expansion module AXIS 0

AXIS_ADDRESS(axis No.)=(32*1)+ID

'the local axis interface of the expansion module AXIS 1

The ID is the combined value of the DIP bit1-4 of the expansion module. After the mapping is completed and the axis parameters such as ATYPE are set, the expansion axis can be used.

Example:

ATYPE(6)=0 'set as virtual axis

AXIS_ADDRESS(6)=1+(32*0)

'ZCAN expansion module ID 1 axis 0 is mapped to axis 6

ATYPE(6)=8 'ZCAN extended axis type, pulse direction stepping or servo

UNITS(6)=100 0 'pulse equivalent 1000

SPEED(6)=100 'speed 100units/s

ACCEL(6)=1000 'acceleration 1000units/s^2

MOVE(100) AXIS(6) 'extended axis movement 100units

Extended resource viewing:

According to the CAN connection, after the power is turned on, and the wiring resistance dial code is set correctly, the power indication led (POWER) and the running indication led (RUN), the IO power indication led (IO POWER) are on, and the alarm indication led (ALM) is off. At the same time, the "Controller" - "State the controller" - "ZCanNodes" in the RTSys software displays the expansion module information and the extended IO number range.

The dial ID and the corresponding resource number when connecting multiple expansion modules are as follows:

Local	432-0(ZMC432)	32	30(0-29)	18(0-17)	0	2(0-1)
1	48(ZIO1632)	0	16(32-47)	32(32-63)	0	0
3	26(ZIO16082)	2	16(64-79)	8(64-71)	0	0
4	10(ZAIO0802)	0	0	0	8(40-47)	2(20-21)

ALM indicator light is on, please check whether the wiring, resistor and dial setting are correct, and whether the CANIO_ADDRESS command of the controller is set as the master end (32), and whether the CAN communication speed is consistent.

4.2. EtherCAT Bus Expansion

The EIO expansion module is an expansion module used by the EtherCAT bus controller. It can expand the resources of digital IO and pulse axis. When the resources of the controller are insufficient, the EtherCAT bus controller can be connected to multiple EIO expansion modules for expansion, you can view the maximum number of IO expansion points and the maximum number of expansion axes of the controller, and in this way, it supports IO remote expansion.


4.1.1. EtherCAT Bus Expansion Wiring

After the expansion wiring is completed, each EIO expansion module does not need to develop again. It only needs to manually configure the unique IO address and axis address in the EtherCAT master controller, and it can be accessed after the configuration is completed. The IO address number is set through the bus command NODE_IO, and the program on the controller can access the resources on the expansion module only

through the IO number. The configuration of the axis address uses the AXIS_ADDRESS command to map axis number, and when the binding is completed, specify the axis number through the BASE or AXIS command.

When wiring, pay attention that EtherCAT IN is connected to the upper-level module, and EtherCAT OUT is connected to the lower-level module. The IN and OUT ports cannot be mixed.

EIO expansion module wiring reference example:



Involved number concepts in above figure are as follows: the bus-related command parameters will use the following numbers:

Slot number (slot):

The slot number refers to the number of the bus interface on the controller, and the slot number of the EtherCAT bus is 0.

Device number (node):

The device number refers to the number of all devices connected to a slot. It starts from 0 and is automatically numbered according to the connection sequence of the devices on the bus. You can view the total number of devices connected to the bus through the NODE_COUNT(slot) command.

Drive number:

The controller will automatically identify the drive on the slot, and the number starts

from 0, and the number is automatically numbered according to the connection sequence of the drive on the bus.

The drive number is different from the device number. Only the drive device number on the slot is assigned, and other devices are ignored. The drive number will be used when mapping the axis number.

4.1.2. EtherCAT Bus Expansion Resource Mapping

→ IO Mapping:

The program on the controller can access the resources on the expansion module only through the IO number. The IO number of the EtherCAT bus expansion module is set through the bus command NODE_IO, and the input and output are configured at the same time.

When IO mapping, first check the maximum IO number of the controller itself (including the external IO interface and the interface in the pulse axis), and then use the command to set.

If the extended IO coincides with the IO number of the controller itself, the two will work at the same time, so the mapped number of the IO mapping must not be repeated in the entire control system.

IO mapping syntax:

NODE_IO(slot, node) = iobase

slot: slot number, 0-default

node: device number, starting from 0

iobase : mapping the IO start number, the setting result will only be a multiple of 8

Example:

NODE_IO(0,0)=32 'set the IO start number of slot 0 interface device 0 to 32

If device 0 is EIO16084, after configuration according to the above syntax, the IO numbers corresponding to input IN0-15 are 32-47 in turn, the general input port numbers in the axis interface are 48-55, and the drive alarm inputs of axes AXIS 0-3 are 48-51

respectively. The IO numbers corresponding to the output OUT0-7 are 32-39 in sequence, the general output port numbers in the axis interface are 40-47, and the drive enable outputs of the axes AXIS 0-3 are 40-43 respectively.

0	41bh	1918h	0	4	24(32-55)	16(32-47)	0

→ AXIS Mapping:

Before using the axis of the expansion module, you need to use the AXIS_ADDRESS command to map the axis number, and the axis mapping also needs to pay attention to the axis number of the entire system cannot be repeated. The mapping syntax of the EIO series extended axis is the same as that of the bus driver.

Axis mapping syntax:

AXIS_ADDRESS(axis number)=(slot number<<16) + driver number+1

Example:

AXIS_ADDRESS(0)=(0<<16)+0+1

'the first drive on the EtherCAT bus, drive number 0, bound as axis 0

AXIS_ADDRESS(1)=(0<<16)+1+1

'the second drive on the EtherCAT bus, drive number 1, bound as axis 1

If the first node is EIO16084, and EIO16084 is connected to drive, then driver 0 here is the first pulse driver connected to EIO16084, otherwise it is the EtherCAT driver.

Chapter V Programming

5.1. Program in RTSys Software


RTSys is a PC-side program development, debugging and diagnostic software for the Zmotion motion controllers. Through it, users can easily edit and configure the controller program, quickly develop applications, diagnose system operating parameters in real time, and debug the running program in real time. What's more, it supports Chinese and English bilingual environments.

In RTSys, there are 4 programming languages for motion control development, Basic, PLC, HMI and C language, they can run multi-tasks among them, especially for Basic, multi-task running can be achieved separately, hybrid programming is also OK with PLC, HMI and C language.



RTSys Downloading Address: https://www.zmotionglobal.com/pro_info_282.html




And related manuals can be found in “Download”:






Features	Parameters	System Architecture	Download	
Name	Version No	Format	Size	Download
RTSys Development Software	V1.2.02	RAR	148MB	Download
RTSys User Manual V1.2.0	V1.2.0	PDF	5.33MB	Download
RTBasic Programming Manual	V1.1.0	PDF	18.3MB	Download
RTHMI Programming Manual	V1.2.0	PDF	7.23MB	Download
Quick Start	VQuick Start	ZIP	16.1MB	Download
ZVision Basic Programming Manual V1.3.0	V1.3.0	PDF	10.6MB	Download
ZPLC	V1.0	PDF	1.7M	Download

Step	Operations	Display Interface
1	Switch the Language: “Language” – “English”, then there will pop	

	up one window, click OK, and restart it.	<p>Language Switch Video Showing:</p> <p>E. How to Switch the Language</p> <p>Find "视图" (the fourth one in the above menu), then find the "语言", choose English, restart RTSys. English RTSys will take effect when opened again.</p>
2	<p>New Project:</p> <p>"File" – "New Project", Save as window will pop up, then enter file name, save the project file with suffix ".zpj".</p>	

3	<p>New File: "File"</p> <ul style="list-style-type: none"> – "New File", select file type to build, here select Basic, click "OK". 	
4	<p>Set Auto Run</p> <p>No.: right click the file, open task number setting window, enter task No., which can be any + value, no priority, but not the same.</p>	

5	<p>Save File: edit the program in program editing window, click "save", new built file will be saved under "zpj." project automatically.</p> <p>"Save all" means all files under this project will be saved.</p>	
6	<p>Connection: Click "controller – connect", if no controller, select connect to simulator.</p>	
6	<p>Then, "connect to controller" window will pop up, you can select serial port or net port to connect, select matched serial port parameters or net port IP address, then click "connect".</p>	
7	<p>Download Program into</p>	<ul style="list-style-type: none"> ● RAM: it will not save when power off. ● ROM: it will save data when power off, and when the program

	<p>Controller: "Ram/Rom" – "download RAM / download ROM", if it is successful, there is print indication, at the same time, program is downloaded into controller and runs automatically.</p>	is connected to controller again, running according to task No.
		  
8	<p>Debug: "Debug" – "Start/Stop Debug" to call "Task" and "Watch" window, because it was downloaded before, here select "Attach the current".</p>	 
9	<p>Scope function: Click "View" – "Scope" to open oscilloscope. It can capture needed data, for debugging.</p>	

Notes:

- When opening an project, choose to open the zpj file of the project. **If only the Bas file is opened, the program cannot be downloaded to the controller.**
- When the project is not created, only the Bas file **cannot be** downloaded to the controller.
- The number 0 in automatic operation represents the task number, and the program runs with task 0, and the task number has no priority.
- If no task number is set for the files in the entire project, when downloading to the controller, the system prompts the following message **WARN: no program set autorun**

5.2. Upgrade Controller Firmware

Firmware upgrade can be achieved by downloading zfm firmware package in RTSys. zfm file is the firmware upgrade package of controller, please select corresponding firmware because different models are with different packages, please contact manufacturer).

How to update:

- a. Open [ZDevelop](#) / [RTSys](#) software, then click "controller – connect", find PCI/LOCAL method, click "connect". If connected, there will be "Connected to Controller: PCIE464 Version: 4.93 – 20231220." In "output" window.
- b. Click "controller – state the controller", find basic info, then current software version can be checked.
- c. Click "controller – update firmware", current controller model and software version can be viewed.
- d. Click "browse", and select saved firmware file, click "update", then one window will pop up, please click "ok".
- e. After that, "connect to controller" window appears again, and please select "PCI/Local" again, and click "connect".
- f. When connection is successful, "firmware update" interface is shown. Now

system enters ZBIOS state, please click "update" again.

- g. When it is loaded, "firmware update" window disappears, now in output window, it shows "Update firmware to Controller Success".
- h. Do step a and step b again, check whether the firmware is updated or not.

5.3. Program in Host-Computer by PC Languages

The controller supports development under various operating systems such as windows, linux, Mac, Android, and wince, and provides dll libraries in various environments such as vc, c#, vb.net, and labview, as shown in the figure below. PC software programming refers to ["Zmotion PC Function Library Programming Manual"](#).








The program developed using the PC software cannot be downloaded to the controller, and it is connected to the controller through the dll dynamic library. The dll library needs to be added to the header file and declared during development.

- Get PC library file, example: https://www.zmotionglobal.com/download_list_17.html

A screenshot of a website page showing a list of development examples. The top navigation bar includes links for Hardware Manuals, Software Manuals (with a red arrow pointing to it), Tool Software, Products Catalogs, Development Examples (highlighted with a red border and a red arrow pointing to it), PC Library Files, and Product 3D Model. Below the navigation bar is a table with rows for Quick Start, Bus INIT BASIC, C Sharp, C PLUS PLUS, LABVIEW, Python, and Linux C Sharp 64 Bit. Each row has a 'Download' button on the right. The 'Software Manuals' and 'Development Examples' links are highlighted with red arrows.

The c++ project development process in VS is as follows:

Step	Operations	Display Interface
1	Open VS, click "File" – "New" – "Project".	
2	Select development language as "Visual C++" and the select program type as "MFC application type".	
3	Select "Based on basic box", click "next" or "finish"	
4	Find C++ function library provided by manufacturer. Routine is below (64-bit library)	
5	Copy all DLL related library files under the above path to the newly created project.	

6	<p>Add a static library and related header files to the project. Static library: zauxdll.lib, zmotion.lib</p> <p>Related header files: zauxdll2.h, zmotion.h</p>	<p>1) Right-click the header file first, and then select: "Add" → "Existing Item".</p>	 
7	<p>Declare the relevant header files and define the controller connection handle, so far the project is newly created.</p>		

Chapter VI Operation and Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce the probability of equipment failure.

6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
power supply	Check whether the voltage is rated	DC 24V (-5%~5%)
surroundings	Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature)	-10°C - 55°C
	Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity)	10%-95% non-condensing
	Is there direct sunlight	No
	With or without droplets of water, oil, chemicals, etc.	No
	Whether there is dust, salt, iron filings, dirt	No
	Whether there is corrosive gas	No
	Whether there are flammable and	No

	explosive gases or articles	
	Whether the device is subjected to vibration or shock	Should be within the range of vibration resistance and impact resistance
	Is the heat dissipation good	Keep good ventilation and heat dissipation
Installation and Wiring Status	Whether the basic unit and the expansion unit are installed firmly	The mounting screws should be tightened without loosening
	Whether the connecting cables of the basic unit and the expansion unit are fully inserted	The connection cable cannot be loosened
	Are the screws of the external wiring loose	Screws should be tightened without loosening
	Whether the cable is damaged, aged, cracked	The cable must not have any abnormal appearance

6.2. Common Problems & Solutions

Problems	Suggestions
Motor does not rotate.	<ol style="list-style-type: none"> 3. Check whether the ATYPE of the controller is correct. 4. Check whether hardware position limit, software position limit, alarm signal work, and whether axis states are normal. 5. Check whether motor is enabled successfully. 6. Confirm whether pulse amount UNITS and speed values are suitable. If there is the encoder feedback, check whether MPOS changes. 7. Check whether pulse mode and pulse mode of drive are matched. 8. Check whether alarm is produced on motion controller station or drive station. 9. Check whether the wiring is correct. 10. Confirm whether controller sends pulses normally.

The position limit signal is invalid.	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
No signal comes to the input.	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
The output does not work.	<ol style="list-style-type: none"> 1. Check whether IO power is needed. 2. Check whether the output number matches the ID of the IO board.
POWER led is ON, RUN led is OFF.	<ol style="list-style-type: none"> 1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the controller alone, and restart the controller after adjustment. 2. Check whether the ALM light flickers regularly (hardware problem).
RUN led is ON, ALM led is ON.	<ol style="list-style-type: none"> 1. Program running error, please check RTSys error code, and check application program.
Fail to connect controller to PC through serial port.	<ol style="list-style-type: none"> 1. Check whether the serial port parameters are modified by the running program, you can check all the current serial port configurations through ?*SETCOM. 2. Check whether the serial port parameters of the PC match the controller. 3. Open the device manager and check whether the serial driver of the PC is normal.
CAN expansion module cannot be connected.	<ol style="list-style-type: none"> 1. Check the CAN wiring and power supply circuit, whether the 120 ohm resistor is installed at both

	<p>ends.</p> <ol style="list-style-type: none">2. Check the master-slave configuration, communication speed configuration, etc.3. Check the DIP switch to see if there are multiple expansion modules with the same ID.4. Use twisted-pair cables, ground the shielding layer, and use dual power supplies for severe interference (the main power supply of the expansion module and the IO power supply are separately powered)
Fail to connect controller to PC through net port.	<ol style="list-style-type: none">1. Check IP address of PC, it needs to be at the same segment with controller IP address.2. Check controller IP address, it can be checked and captured after connection through serial port.3. When net port led is off, please check wiring.4. Check whether controller power led POWER and running indicator led RUN are ON normally.5. Check whether the cable is good quality, change one better cable to try again.6. Check whether controller IP conflicts with other devices.7. Check whether controller net port channel ETH are all occupied by other devices, disconnect to other devices, then try again.8. When there are multiple net cards, don't use other net cards, or change one computer to connect again.9. Check PC firewall setting.10. Use "Packet Internet Groper" tool (Ping), check whether controller can be Ping, if it can't, please check physical interface or net cable.11. Check IP address and MAC address through arp-a.