



EtherCAT IO & Pulse Axis Module


EI016084




Vision Motion
Controller



Motion
Controller



Motion
Control Card



IO Expansion
Module



HMI

Statement

Thank you for choosing our Zmotion products. Please be sure to read this manual carefully before use so that you can use this product correctly and safely. Zmotion is not responsible for any direct or indirect losses caused by the use of this product.

The copyright of this manual belongs to Shenzhen Zmotion Technology Co., Ltd. And reproduction, translation, and plagiarism of any content in this manual in any form is strictly prohibited without the written permission of Zmotion.

The information in this manual is for reference only. Due to design improvements and other reasons, Zmotion reserves the right of final interpretation of this information! Contents are subject to change without prior notice!

➤ Notes

In order to prevent possible harm and damage caused by incorrect use of this product, the following instructions are given on matters that must be observed.

■ Danger

Do not use it in places with water, corrosive or flammable gases, or near flammable substances.	May cause electric shock, fire, damage, etc.
When installing or disassembling, make sure the product is powered off.	
Cables should be connected securely, and exposed parts that are energized must be insulated by insulators.	
Wiring work must be performed by professionals.	

■ Notes

It should be installed within the specified environmental range.	May cause damage, mis-operation, etc.
Make sure there are no foreign objects on the product hardware circuit board.	
After installation, the product and the mounting bracket should be tight and firm.	
After installation, at least 2-3cm should be left between the product and surrounding components for ventilation and replacement.	
Never disassemble, modify, or repair it by yourself.	

Content

Chapter I Production Information.....	4
1.1. Product Information	4
1.2. Function Features.....	4
1.3. System Frame	4
1.4. Hardware Installment.....	5
Chapter II Product Specification	7
2.1. Interface Definition.....	7
2.2. Order Information	8
2.3. Work Environment	8
Chapter III Wiring, Communication Configuration	9
3.1. Power Input	9
3.2. Power Specification	9
3.3. IN Digital Input.....	10
3.3.1. Digital Input Specification.....	10
3.3.2. Digital Input Wiring	11
3.4. OUT Digital Output	11
3.4.1. Digital Output Specification	12
3.4.2. Digital Output Wiring	13
3.5. EtherCAT Bus Interface	13
3.6. AXIS Differential Pulse Axis Interface.....	15
3.6.1. AXIS Interface Signal Specification & Wiring	17
Chapter IV Expansion Module	20
4.1. EtherCAT Expansion Wiring Reference.....	20
4.2. EtherCAT Expansion Module Usage.....	21
4.3. EtherCAT Bus Expansion Resource Mapping	23
Chapter V Data Dictionary	25
5.1. Input & Output	25
5.2. The First Drive on The First Expansion Module	25
Chapter VI Run and Maintain	28
6.1. Regular Inspection and Maintenance	28
6.2. Common Problems.....	29

Chapter I Production Information


1.1. Product Information

EIO16084 bus expansion module is used for EtherCAT bus controller, when IO and other resources are not enough, an expansion module is needed. And controller can link with multiple EtherCAT expansion modules through EtherCAT bus at the same time. And IO and axis resources of EIO16084 can be accessed by mapping Number.

1.2. Function Features


- ◆ Axis expansion: 4-axis pulse-axis expansion.
- ◆ Digital expansion: there are 16 inputs and 8 outputs, each pulse axis has 2 additional inputs and 2 additional outputs that can be configured.
- ◆ Pulse output mode: pulse / direction or dual pulses.
- ◆ Maximum pulse output frequency of each axis is 10MHZ.
- ◆ The maximum output current of outputs (except pulse-axis) can reach 300mA, which can directly drive some kinds of solenoid valves.

1.3. System Frame



1.4. Hardware Installment

EIO16084 bus expansion module is installed horizontally with screws, and each controller should be fastened with 4 screws.



→ Unit: mm


→ Mounting Hole Diameter 4.5mm

 Installation attention	<ul style="list-style-type: none">Non-professionals are strictly prohibited to operate. Specifically, professionals who had been trained related electrical equipment, or who master electrical knowledge.Please be sure to read the product instruction manual and safety precautions carefully before installation.Before installation, please ensure that the product is powered off.Do not disassemble the module, otherwise the machine may be damaged.Avoid direct sunlight installation.
--	---

	<ul style="list-style-type: none">● In order to facilitate ventilation and controller replacement, 2-3cm should be left between the upper and lower parts of the controller and the installation environment and surrounding components.● Considering the convenient operation and maintenance of the controller, please do not install the controller in the following places:<ol style="list-style-type: none">a) places where the surrounding ambient temperature exceeds the range of -10°C-55°Cb) places where the ambient humidity exceeds the range of 10%-95% (non-condensing)c) places with corrosive gases and flammable gasesd) places with many conductive powders such as dust and iron powder, oil mist, salt, and organic solvents
--	---

Chapter II Product Specification

2.1. Interface Definition



Mark	Interface	Number	Description
POW	The led that indicates the current state.	1	Power state: it lights when power is conducted.
RUN		1	Run state: it lights when runs normally
ALM		1	Error state: it lights when runs incorrectly
EtherCAT IN	EtherCAT bus interface	1	Connect to main controller or former level expansion module.
EtherCAT OUT		1	Connect to drive equipment or behind level expansion module.
Digital input		16	NPN type, main power 24V.
Digital output		8	NPN type, main power 24V.

Main power	1	24V DC power supplies for main control area of expansion module.
Pulse axis	4	Each can be configured as differential pulse output and differential encoder input.

2.2. Order Information

Model	Axes	Encoder	Inner IN	Inner OUT	ECAT IN / EACT OUT	Functions
EIO1616	-	-	16	16	1/1	Module: EIO1616M Module + cover: EIO1616MT
EIO16084	4	4	16	8	1/1	4-axis expansion
EIO24088	8	8	24	8	1/1	8-axis expansion

2.3. Work Environment


Item		Parameters
Work Temperature		-10°C-55°C
Work relative Humidity		10%-95% non-condensing
Storage Temperature		-40°C ~ 80°C (not frozen)
Storage Humidity		Below 90%RH (no frost)
vibration	Frequency	5-150Hz
	Displacement	3.5mm(directly install)(<9Hz)
	Acceleration	1g(directly install)(>9Hz)
	Direction	3 axial direction
Shock (collide)		15g, 11ms, half sinusoid, 3 axial direction
Degree of Protection		IP20

Chapter III Wiring & Communication

3.1. Power Input

The power supply input adopts a 3Pin (there are all 3 terminals) screw-type pluggable wiring terminal. And it is 24V DC power.

→ Terminal Definition:

Terminal	Name	Type	Function
	E+24V	Input	Positive (+) terminal of DC power input (connect positive of power to positive of controller)
	EGND	Input	Negative (-) terminal of power input
	FG	Earthing (Grounding)	Protect

3.2. Power Specification

→ Specification

Item	Description
Voltage	DC24V (-5%~5%)
The current to open	≤0.5A
The current to work	≤0.4A
Anti-reverse connection	Yes
Overcurrent Protection	Yes

3.3. IN Digital Input

→ Terminal Definition


Terminal	Name	Type	Function 1
EGND	EGND	/	External power ground
EGND	EGND	/	External power ground
IN0	IN0		Input 0
IN1	IN1		Input 1
IN2	IN2		Input 2
IN3	IN3		Input 3
IN4	IN4		Input 4
IN5	IN5		Input 5
IN6	IN6		Input 6
IN7	IN7		Input 7
EGND	EGND	/	External power ground
EGND	EGND	/	External power ground
IN8	IN8		Input 8
IN9	IN9		Input 9
IN10	IN10		Input 10
IN11	IN11		Input 11
IN12	IN12		Input 12
IN13	IN13		Input 13
IN14	IN14		Input 14
IN15	IN15		Input 15

3.3.1. Digital Input Specification

Item	Digital input (IN0-15)
Input mode	NPN type, input is triggered when in low-electric level
Frequency	<5kHz
Impedance	4.7KΩ
Voltage level	DC24V
The voltage to open	<14.5V
The voltage to close	>14.7V
Minimal current	-1.8mA (negative)
Max current	-6mA (negative)

Isolation mode	optoelectronic isolation
Note: the above parameters are standard values when the voltage of expansion module power supply (E+24V port) is 24V.	

3.3.2. Digital Input Wiring



→ Wiring Note:

- The wiring principle of digital inputs IN (0-15) is shown in the figure above. The external signal source can be an optocoupler, a key switch or a sensor, etc., all can be connected as long as the requirements on output of electric level can be achieved.
- For the public end, please connect the "EGND" port on the power supply to the "COM" terminal of the external input device. If the signal area power supply of the external device and the power supply of the expansion module are in the same power supply system, this connection also can be omitted.

3.4. OUT Digital Output

→ Terminal Definition

Terminal	Name	Type	Function
	EGND	/	External power ground
	NC	/	Spare
	OUT0	NPN, digital	Output 0

EGND	OUT1	outputs	Output 1	
NC	OUT2		Output 2	
OUT0	OUT3		Output 3	
OUT1	OUT4		Output 4	
OUT2	OUT5		Output 5	
OUT3	OUT6		Output 6	
OUT4	OUT7		Output 7	
OUT5				
OUT6				
OUT7				


3.4.1. Digital Output Specification

Item	Digital Output (OUT0-7)
Output mode	NPN type, it is 0V when outputs
Frequency	<8kHz
Voltage level	DC24V
Max output current	+300mA
Max leakage current when off	25µA
Respond time to conduct	12µs
Respond time to close	80µs
Overcurrent protection	Support
Isolation method	optoelectronic isolation

Note:

- ✧ The times in the form are typical based on the resistive load, and may change when the load circuit changes.
- ✧ Due to the leak-type output, the shutdown of the output will be obviously affected by the external load circuit, and the output frequency should not be set too high in the application. And it is recommended to set below 8KHz.

3.4.2. Digital Output Wiring




→ Wiring Note:

- The wiring principle of digital outputs OUT (0-7) is shown in the figure above. The external signal receiving end can be an optocoupler or a relay or solenoid valve, all can be connected as long as the input current does not exceed 300mA.
- For the connection of the public end, please connect the "EGND" port on the power supply to the negative pole of the DC power supply of the external input device. If the DC power supply of the external device and the expansion module power supply are in the same power supply system, this connection can also be omitted.

3.5. EtherCAT Bus Interface

EIO16084 bus expansion module has 2 100M EtherCAT communication interfaces, and they support EtherCAT protocol. EtherCAT IN is connected to main controller or former level expansion module, but EtherCAT OUT is connected to drive equipment or next level expansion module, they can not be mixed. The pin definition is as follows:



PIN	Signal	Description
1	TX+	Send signal (+)
2	TX-	Send signal (-)
3	RX+	Receive signal (+)
4	NC	Reserved
5	NC	Reserved
6	RX-	Receive signal (-)
7	NC	Reserved
8	NC	Reserved


→ Specification

Item	Specification
Communication protocol	EtherCAT protocol
Valid service	CoE(PDO, SDO), FoE
Synchronization method	IO adopts input and output synchronization / DC-distributed clock
Physical level	100BASE-TX
Duplex mode	Full duplex
Topology	linear topology
Transfer media	Cable
Transfer distance	It is less than 100M between 2 nodes
Process data	Maximum 1486 bytes of one single frame
Synchronization shaking of two slave stations	<1us
Refresh	1000 digital input and output about is 30us, 16 servo axes about 30us

→ Communication Cable Requirements

EtherCAT communication interface adopts standard Ethernet RJ45 interface.

The network cable adopts Category 5e STP, and the crystal head has a metal shell to reduce interference and to prevent information from being eavesdropped. As shown below:



Item	Specification
Cable type	Flexible crossover cable, Category 5e
traverse	twisted pair
Line pairs	4
Isolation	cross skeleton
Connector	Crystal head with iron shell
Cable material	PVC
Cable length	Less than 100m

Use RJ45 network cable connection method:

- When installing, hold the crystal head that is with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.
- When disassembling, press the tail mechanism of the crystal head, and pull out the connector and the module in a horizontal direction.


Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.

3.6. AXIS Differential Pulse Axis Interface

This product provides 4 local differential pulse axis interfaces, each interface is a standard DB26 female socket.

→ [Interface Definition](#)

Interface	Pin	Signal	Description
	1	EGND	Negative pole of IO 24V power
	2	IN16-19/ALM	General input (recommended as driver alarm)
	3	OUT8-11/ENABLE	General output (recommended as driver enable)
	4	EA-	Encoder differential input signal A-
	5	EB-	Encoder differential input signal B-



	6	EZ-	Encoder differential input signal Z-
	7	+5V	Positive pole of 5V power of pulse/encoder signal
	8	Reserved	Reserved
	9	DIR+	Servo or step direction output +
	10	GND	Negative pole of 5V power of pulse/encoder signal
	11	PUL-	Servo or step pulse output -
	12	Reserved	Reserved
	13	GND	Negative pole of 5V power of pulse/encoder signal
	14	OVCC	Positive pole of IO 24V power
	15	OUT12- 15/CLR	General output, recommended to clear drive alarms
	16	IN20- 23/INP	General input, recommended to do on-position signal
	17	EA+	Encoder differential input signal A+
	18	EB+	Encoder differential input signal B+
	19	EZ+	Encoder differential input signal Z+
	20	GND	Negative pole of 5V power of pulse/encoder signal
	21	GND	
	22	DIR-	Servo or step direction output -
	23	PUL+	Servo or step pulse output +
	24	GND	Negative pole of 5V power of pulse/encoder signal
	25	Reserved	Reserved
	26	Reserved	Reserved

→Pulse Axis PIN & IO PIN

Pulse Axis No.	IN (PIN 2)	OUT (PIN 3)	OUT (PIN 15)	IN (PIN 16)
AXIS0	IN16	OUT8	OUT12	IN20
AXIS1	IN17	OUT9	OUT13	IN21
AXIS2	IN18	OUT10	OUT14	IN22
AXIS3	IN19	OUT11	OUT15	IN23

3.6.1. AXIS Interface Signal Specification & Wiring


→ Specification:

Signal	Item	Description
PUL/DIR	Signal type	Differential output signal
	Voltage range	0-5V
	Maximum frequency	10MHz
EA/EB/EZ	Signal type	Differential input signal
	Voltage range	0-5V
	Maximum frequency	5MHz
IN16-23	Input method	NPN leak type, it is triggered when low electric level is input.
	Frequency	<5kHz
	Impedance	6.8KΩ
	Voltage level	DC24V
	The voltage to open	<10.5V
	The voltage to close	>10.7V
	Minimal current	-1.8mA (negative)
	Maximum current	-4mA (negative)
	Isolation	optoelectronic isolation
OUT8-15	Output method	NPN leak type, it is 0V when outputs
	Frequency	< 8kHz
	Voltage level	DC24V
	Maximum current	+50mA


	Overcurrent protection	No
	Isolation	optoelectronic isolation
+5V, GND	Maximum output current for 5V	50mA
OVCC, EGND	Maximum output current for 24V	50mA

→ Wiring Reference:


- Reference example of wiring with Panasonic A5/A6 servo driver:



- PUL/DIR Single-Ended Wiring:



- EA/EB/EZ Single-Ended Wiring:



→ **Wiring Note:**

- ✧ The wiring principle of the differential pulse axis interface is shown in the figure above, and the wiring methods of different types of drivers are different, please connect carefully.
- ✧ Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.

Chapter IV Expansion Module


4.1. EtherCAT Expansion Wiring Reference

[EIO16084 expansion module](#) is powered by the single power. The main power can supply power for IO, the main power uses 24V DC power.

After the expansion wiring is completed, each EIO expansion module does not need to develop again. It only needs to manually configure the unique IO address and axis address in the EtherCAT master controller, and it can be accessed after the configuration is completed. The IO address number is set through the bus command NODE_IO, and the program on the controller can access the resources on the expansion module only through the IO number.

When wiring, pay attention that EtherCAT IN is connected to the upper-level module, and EtherCAT OUT is connected to the lower-level module. The IN and OUT ports cannot be mixed.

EIO expansion module wiring reference example:



Involved number concepts in above figure are as follows: the bus-related command parameters will use the following numbers:

Slot number (slot):

The slot number refers to the number of the bus interface on the controller, and the slot number of the EtherCAT bus is 0.

Device number (node):

The device number refers to the number of all devices connected to a slot. It starts from 0 and is automatically numbered according to the connection sequence of the devices on the bus. You can view the total number of devices connected to the bus through the NODE_COUNT(slot) command.


Drive number:

The controller will automatically identify the drive on the slot, and the number starts from 0, and the number is automatically numbered according to the connection sequence of the drive on the bus.


The drive number is different from the device number. Only the drive device number on the slot is assigned, and other devices are ignored. The drive number will be used when mapping the axis No.

4.2. EtherCAT Expansion Module Usage


1. Please follow the above wiring instructions to correctly complete the wiring of power supply, EtherCAT bus, IO signal and other modules.
2. After the controller is powered on, please use the ETHERNET interface and RS232 serial port to connect to RTSys.
3. The EIO16084 expansion module can only be used after bus initialization.
 - ① Execute the bus initialization program, identify the device number of the EIO expansion module and the connected drive number during the initialization process, operate the axis mapping according to the drive number, and use the AXIS_ADDRESS command to map the axis, also operate the IO mapping of the expansion module according to the device number, and use the NODE_IO command to map the IO, set DRIVE_PROFILE and ATYPE;
 - ② After successful initialization, enable the driver on the expansion module.
 - ③ Enable and set the basic motion parameters ATYPE, UNITS, SPEED, ACCEL, FWD_IN, REV_IN and other axis parameters, and then send the motion command to drive the motor.
4. After the setting is completed, the communication can be established. If the communication is successful, "controller status" - "slot 0 node" will display the information of the expansion module.




5. Corresponding input state values can be directly read through "IN" command, or through "RTSys/Tool/IN". Please refer to RTBasic Programming Manual.



6. Open or close outputs through "OP" command, or through "RTSys/Tool/OP". Please refer to RTBasic Programming Manual.



7. There are many parameters related to pulse-axis, and they can be set through relative commands, please refer to RTBasic Programming Manual. Or through "RTsys/View/Axis Parameter".



8. Through RTSys/View/Manual to operate relative motions.

Axis	ATYPE	UNITS	ACCEL	DECCEL	SPEED	DPOS	LeftVMove	RightVMove	Distance	Absolute	MPOS	IDLE	AXISSTATUS		
0	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop
1	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop
2	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop
3	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop
4	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop
5	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right		<input type="checkbox"/>	Move	0.000	-1	0h	Stop

→ Notes:

- Regardless of whether the IO on the expansion module is used or not, the NODE IO command needs to be used to map the input and output numbers of the EIO16084. The DRIVE_PROFILE of the expansion module is set to 0, and the ATYPE is set to 65, but the actual axis type is not 65 because it is a pulse type drive. The configuration of the real axis type uses the SDO command to configure the data dictionary 6011h settings.
- If a hard limit alarm occurs during the initialization process, you can point the mapping number of the hard limit FWD_IN and REV_IN to -1 in the axis parameter window, which means no mapping, and then modify FWD_IN and REV_IN when the limit switch needs to be connected.

4.3. EtherCAT Bus Expansion Resource Mapping

→ IO Mapping:

The program on the controller can access the resources on the expansion module only through the IO number. The IO number of the EtherCAT bus expansion module is set through the bus command NODE_IO, and the input and output are configured at the same time.

When IO mapping, first check the maximum IO number of the controller itself (including the external IO interface and the interface in the pulse axis), and then use the command to set.

If the extended IO coincides with the IO number of the controller itself, the two will work at the same time, so the mapped number of the IO mapping must not be repeated in

the entire control system.

IO mapping syntax:

NODE_ IO(slot, node) = iobase

slot: slot number, 0-default

node: device number, starting from 0

iobase : mapping the IO start number, the setting result will only be a multiple of 8

Example:

NODE_IO(0,0)=32 'set the IO start number of slot 0 interface device 0 to 32

If device 0 is EIO16084, after configuration according to the above syntax, the IO numbers corresponding to input IN0-23 are 32-55 in turn, the general input port numbers in the axis interface are 56-63, and the drive alarm inputs of axes AXIS 0-3 are 56-59 respectively. The IO numbers corresponding to the output OUT0-7 are 32-39 in sequence, the general output port numbers in the axis interface are 40-47, and the drive enable outputs of the axes AXIS 0-3 are 40-43 respectively.

0	41bh	1ab0h	0	8	32(32-63)	16(32-47)	0
---	------	-------	---	---	-----------	-----------	---

→ AXIS Mapping:

Before using the axis of the expansion module, you need to use the AXIS_ADDRESS command to map the axis number, and the axis mapping also needs to pay attention to the axis number of the entire system cannot be repeated. The mapping syntax of the EIO series extended axis is the same as that of the bus driver.

Axis mapping syntax:

AXIS_ADDRESS(axis number)=(slot number<<16)+driver number+1

Example:

AXIS_ADDRESS(0)=(0<<16)+0+1

'the first drive on the EtherCAT bus, drive number 0, bound as axis 0

AXIS_ADDRESS(1)=(0<<16)+1+1

'the second drive on the EtherCAT bus, drive number 1, bound as axis 1

If the first node is EIO16084, and EIO16084 is connected to drive, then driver 0 here is the first pulse driver connected to EIO16084, otherwise it is the EtherCAT driver.

Chapter V Data Dictionary

SDO command configures drive parameters:

For example: the real axis type setting of the extended pulse axis is set through the data dictionary 6011h, (refer to the parameters in the table below, set in order according to the axis number, the first drive sets the data dictionary 6011h+0*800h, and the second drive sets 6011h+ 1*800h, and so on, add 800h for each drive, and the same for other parameters).

5.1. Input & Output

Number	Description	Type	Read/write	Others
6000h	Input	ARRAY U8	RO	1-close
6200h	Output	ARRAY U8	RW	1-open
6206h	Abnormal output mode	ARRAY U8	RW	1-use abnormally output
6207h	Abnormal output usage status	ARRAY U8	RW	

5.2. The First Drive on The First Expansion Module

Number	Description	Type	Read/write	Others
6011h	Atype	UNSIGNED8	RW	<p>Axis type of expansion board:</p> <ul style="list-style-type: none"> ● 0: virtual axis ● 1: step or servo of pulse directional ● 2: servo of analog signal control ● 3: orthogonal encoder ● 4: step + encoder

					<ul style="list-style-type: none"> ● 5: step + pulse directional encoder ● 6: pulse directional encoder ● 7: pulse directional step/servo + EZ signal input
6012h	Invert_Step	UNSIGNED16	RW		See controller introduction Invert_Step
6013h	Iolevel	UNSIGNED32	RW		B0-origin electrical level B1-limit position level B8-automatic use enable signal B9-use ALM signal to alarm B11-B15: origin selection signal
6014h	Axisstatus	UNSIGNED32	RO		See controller introduction AXISSTATUS
6040h	Controlword	UNSIGNED16	RW		Relative master controller DRIVE_CONTROLWORD: B0- Switch on B1 - Enable voltage B3- Enable operation B7- Fault reset
6041h	Statusword	UNSIGNED16	RO		Relative master controller DRIVE_STATUS: B0 Ready to switch on B1 Switch on

				B2 Operation enabled B3 Fault B4 Voltage enabled B5 Quick stop B7 Warning B8 EZ status B9 Remote B10 Target reached B11 Internal limit active B12-13 Operation mode specific B14 EA status B15 EB status
6060h	Modes of operation	INTEGER 8	RW	6: home the origin port 8: cycle location
607Eh	Polarity	INTEGER 8	RW	1- opposite direction 0- normal direction
60fDh	Drive input compatibility	UNSIGNED 32	RW	

Chapter VI Run and Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce the probability of equipment failure.

6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
power supply	Check whether the voltage is rated	DC 24 V (-5%~5%)
surroundings	Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature)	-10 °C - 55 °C
	Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity)	10%-95% non-condensing
	Is there direct sunlight	No
	With or without droplets of water, oil, chemicals, etc.	No
	Whether there is dust, salt, iron filings, dirt	No
	Whether there is corrosive gas	No
	Whether there are flammable and explosive gases or articles	No

	Whether the device is subjected to vibration or shock	Should be within the range of vibration resistance and impact resistance
	Is the heat dissipation good	Keep good ventilation and heat dissipation
Installation and Wiring Status	Whether the basic unit and the expansion unit are installed firmly	The mounting screws should be tightened without loosening
	Whether the connecting cables of the basic unit and the expansion unit are fully inserted	The connection cable cannot be loosened
	Are the screws of the external wiring loose	Screws should be tightened without loosening
	Whether the cable is damaged, aged, cracked	The cable must not have any abnormal appearance

6.2. Common Problems

Problems	Suggestions
Motor does not rotate.	<ol style="list-style-type: none"> 1. Check whether the ATYPE of the controller is correct. 2. Check whether hardware position limit, software position limit, alarm signal work, and whether axis states are normal. 3. Check whether motor is enabled successfully. 4. Confirm whether pulse amount UNITS and speed values are suitable. If there is the encoder feedback, check whether MPOS changes. 5. Check whether pulse mode and pulse mode of drive are matched. 6. Check whether alarm is produced on motion controller station or drive station. 7. Check whether the wiring is correct. 8. Confirm whether controller sends pulses normally.
The position limit signal is	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally,

invalid.	<p>and whether the "input" view can watch the signal change of the limit sensor.</p> <ol style="list-style-type: none"> 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
No signal comes to the input.	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
The output does not work.	<ol style="list-style-type: none"> 1. Check whether IO power is needed. 2. Check whether the output number matches the ID of the IO board.
POWER led is ON, RUN led is OFF.	<ol style="list-style-type: none"> 1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the controller alone, and restart the controller after adjustment. 2. Check whether the ALM light flickers regularly (hardware problem).
RUN led is ON, ALM led is ON.	<ol style="list-style-type: none"> 1. Program running error, please check ZDevelop error code, and check application program.
Fail to connect controller to PC through serial port.	<ol style="list-style-type: none"> 1. Check whether the serial port parameters are modified by the running program, you can check all the current serial port configurations through ?*SETCOM. 2. Check whether the serial port parameters of the PC match the controller. 3. Open the device manager and check whether the serial driver of the PC is normal.
CAN expansion module cannot be connected.	<ol style="list-style-type: none"> 1. Check the CAN wiring and power supply circuit, whether the 120 ohm resistor is installed at both ends.

	<ol style="list-style-type: none">2. Check the master-slave configuration, communication speed configuration, etc.3. Check the DIP switch to see if there are multiple expansion modules with the same ID.4. Use twisted-pair cables, ground the shielding layer, and use dual power supplies for severe interference (the main power supply of the expansion module and the IO power supply are separately powered)
Fail to connect controller to PC through net port.	<ol style="list-style-type: none">1. Check IP address of PC, it needs to be at the same segment with controller IP address.2. Check controller IP address, it can be checked and captured after connection through serial port.3. When net port led is off, please check wiring.4. Check whether controller power led POWER and running indicator led RUN are ON normally.5. Check whether the cable is good quality, change one better cable to try again.6. Check whether controller IP conflicts with other devices.7. Check whether controller net port channel ETH are all occupied by other devices, disconnect to other devices, then try again.8. When there are multiple net cards, don't use other net cards, or change one computer to connect again.9. Check PC firewall setting.10. Use "Packet Internet Groper" tool (Ping), check whether controller can be Ping, if it can't, please check physical interface or net cable.11. Check IP address and MAC address through arp-a.