



ZMC3XX Pulse Motion Controller


ZMC304




This manual is mainly for ZMC304, ZMC306M.




Vision Motion
Controller



Motion
Controller



Motion
Control Card



IO Expansion
Module



HMI

Statement

Thank you for choosing our Zmotion products. Please be sure to read this manual carefully before use so that you can use this product correctly and safely. Zmotion is not responsible for any direct or indirect losses caused by the use of this product.

The copyright of this manual belongs to Shenzhen Zmotion Technology Co., Ltd. And reproduction, translation, and plagiarism of any content in this manual in any form is strictly prohibited without the written permission of Zmotion.

The information in this manual is for reference only. Due to design improvements and other reasons, Zmotion reserves the right of final interpretation of this information! Contents are subject to change without prior notice!

➤ Notes

In order to prevent possible harm and damage caused by incorrect use of this product, the following instructions are given on matters that must be observed.

■ Danger

Do not use it in places with water, corrosive or flammable gases, or near flammable substances.	May cause electric shock, fire, damage, etc.
When installing or disassembling, make sure the product is powered off.	
Cables should be connected securely, and exposed parts that are energized must be insulated by insulators.	
Wiring work must be performed by professionals.	

■ Notes

It should be installed within the specified environmental range.	May cause damage, mis-operation, etc.
Make sure there are no foreign objects on the product hardware circuit board.	
After installation, the product and the mounting bracket should be tight and firm.	
After installation, at least 2-3cm should be left between the product and surrounding components for ventilation and replacement.	
Never disassemble, modify, or repair it by yourself.	

Content

Chapter I Production Information.....	5
1.1. Product Information	5
1.2. Function Features.....	5
1.3. System Frame.....	6
1.4. Hardware Installment.....	7
Chapter II Product Specification	9
2.1. Basic Specification.....	9
2.2. Order Information	10
2.3. Interface Definition.....	10
2.4. Work Environment	12
Chapter III Wiring, Communication Configuration	13
3.1. Power Input	13
3.1.1. Power Specification	13
3.2. RS485, RS422, CAN Communication Interfaces	14
3.2.1. RS485, RS422, CAN Communication Specification & Wiring	14
3.2.2. Basic Usage Method	17
3.3. RS232 Serial Port.....	18
3.3.1. RS232 Specification & Wiring	19
3.3.2. Basic Usage Method	20
3.4. IN Digital Input & High-Speed Latch Port & Single-Ended Encoder	21
3.4.1. Digital Input Specification & Wiring	23
3.4.2. Basic Usage Method	24
3.5. OUT (Digital Output, PWM Terminal).....	25
3.5.1. Digital Output Specification & Wiring	26
3.5.2. Basic Usage Method	27
3.6. AD/DA Analog Input / Output.....	28
3.6.1. Analog Input / Output Specification & Wiring.....	28
3.6.2. Basic Usage Method	30
3.7. U Disk.....	30
3.8. ETHERNET	31
3.9. AXIS Differential Pulse Axis Interface	33

3.9.1. AXIS Interface Signal Specification & Wiring.....	34
3.9.2. Basic Usage Method	37
Chapter IV Expansion Module	40
4.1. CAN Bus Expansion Wiring.....	40
4.2. CAN Bus Expansion Resource Mapping	42
5.1. Program in RTSys Software	47
5.2. Upgrade Controller Firmware	52
5.3. Program in Host-Computer by PC Languages	53
Chapter VI Operation and Maintain.....	56
6.1. Regular Inspection and Maintenance	56
6.2. Common Problems & Solutions	57

Chapter I Production Information

1.1. Product Information

ZMC is the abbreviation of the network motion controller model launched by Zmotion Technology.

ZMC304 high-performance multi-axis motion controller is a kind of pulse type stand-alone motion controller. The controller itself supports 4 axes at most, but maximum 10 axes can be expanded to achieve complex continuous trajectory control requirements.


ZMC3 series high-performance multi-axis motion controllers can be applied in robots (SCARA, Delta, 6 joints), electronic semiconductor equipment (testing equipment, assembly equipment, locking equipment, soldering machine), dispensing equipment, non-standard equipment, printing and packaging equipment, textile and garment equipment, stage entertainment equipment, medical equipment, assembly line, etc.

1.2. Function Features

- ◆ The controller supports 4 axes motion control at most.
- ◆ Pulse output mode: pulse / direction or dual pulses
- ◆ Maximum pulse output frequency of each axis is 10MHZ.
- ◆ 528 isolated inputs and 528 isolated outputs can be extended at most through CAN.
- ◆ Axis position limit signal / origin signal ports can be configured as any input at will.
- ◆ The maximum output current of general digital outputs can reach 300mA, which can directly drive some kinds of solenoid valves.
- ◆ Interfaces: RS232, RS485, RS422, U Disk, EtherNET.
- ◆ Support up to 10 axes linear interpolation, arbitrary circular interpolation, helical interpolation, and spline interpolation.


- ◆ Support electronic cam, electronic gear, position latch, synchronous follow, virtual axis, and other functions.
- ◆ Support pulse closed loop, pitch compensation and other functions.
- ◆ Support multi-file and multi-task programming in ZBasic.
- ◆ A variety of program encryption methods to protect your intellectual property rights.
- ◆ Support power failure detection and power failure storage. (It can detect and save when power-off)

1.3. System Frame



1.4. Hardware Installment

The ZMC304 motion controller is installed horizontally with screws, and each controller should be fastened with 4 screws.



→ Unit: mm

→ Mounting Hole Diameter 4.5mm



**Installation
attention**

- Non-professionals are strictly prohibited to operate. Specifically, professionals who had been trained related electrical equipment, or who master electrical knowledge.
- Please be sure to read the product instruction manual and safety precautions carefully before installation.
- Before installation, please ensure that the product is powered off.
- Do not disassemble the module, otherwise the machine may be damaged.
- Avoid direct sunlight installation.

	<ul style="list-style-type: none">● In order to facilitate ventilation and controller replacement, 2-3cm should be left between the upper and lower parts of the controller and the installation environment and surrounding components.● Considering the convenient operation and maintenance of the controller, please do not install the controller in the following places:<ol style="list-style-type: none">a) places where the surrounding ambient temperature exceeds the range of -10°C-55°Cb) places where the ambient humidity exceeds the range of 10%-95% (non-condensing)c) places with corrosive gases and flammable gasesd) places with many conductive powders such as dust and iron powder, oil mist, salt, and organic solvents
--	--

Chapter II Product Specification


2.1. Basic Specification

Item	Description	
Model	ZMC304	ZMC306M
Basic Axes	4	6
Max Extended Axes	10	
Type of Basic Axes	Local pulse axes / encoder axes	Local pulse / encoder / single-ended pulse axes
Digital IO	24 inputs and 8 outputs.	
IO in AXIS Interface	4 inputs and 4 outputs	
Max Extended IO	528 inputs, 528 outputs	
PWM	2	
AD/DA	2 general ADs and 2 general DAs, 0-10V	
Max Extended AD/DA	128 ADs, 64 DAs	
Pulse Bit	32	
Encoder Bit	32	
Speed and Acceleration Bit	32	
Highest Pulse Frequency	10MHz	
Motion Buffer of Each Axis	128	
Array Space	32000	
Program Space	300KByte	
Flash Space	128MByte	
Power Supply Input	24V DC input	
Communication Interfaces	RS232, RS485, RS422, Ethernet, U Disk, CAN	
Dimensions	205mm*134mm*31mm	

2.2. Order Information

Model	Description
ZMC304	4 axes, point to point, linear, circular, electronic cam, continuous trajectory motion, robot structure.
ZMC306M	6 axes, point to point, linear, circular, electronic cam, continuous trajectory motion, robot structure.

2.3. Interface Definition



→ Interface Description

Mark	Interface	Number	Description
POWER	The led that indicates the current state.	1	Power state: it lights when power is conducted.
RUN		1	Run state: it lights when runs normally
ALM		1	Error state: it lights when runs incorrectly
RS232	RS232 serial port (port0)	1	Use MODBUS_RTU protocol
RS485	RS485 serial port (port1)	1	Use MODBUS_RTU protocol
RS422	RS422 serial port (port2)	1	Use MODBUS_RTU protocol
ETHERNET	Network port	1	Use MODBUS_TCP protocol, expand the number of network ports through the interchanger, and the number of net port channels can be checked through "?*port" command, default IP address is 192.168.0.11
UDISK	U disk interface	1	Insert U disk equipment
E+24V	Main power supply	1	24V DC power, it supplies the power for controller.
CAN	CAN bus interface	1	Connect to CAN expansion modules and other standard CAN devices.
IN	Digital IO input port	24+4	NPN type, the power is supplied by internal 24V power supply. There are 2 high-speed inputs, and IN0-1 have the latch function, IN0-2 have encoder function.
OUT	Digital IO output port	8+4	NPN type, the power is supplied by internal 24V power supply. There are 2 high-speed outputs, OUT0-1 have PWM function.
AD	Analog input port	2	12-bit resolution, 0-10V.
DA	Analog output port	2	12-bit resolution, 0-10V.
AXIS	Pulse axis interface	4	It includes differential pulse output and differential encoder input.

2.4. Work Environment

Item	Parameters	
Work Temperature	-10°C-55°C	
Work relative Humidity	10%-95% non-condensing	
Storage Temperature	-40°C ~ 80°C (not frozen)	
Storage Humidity	Below 90%RH (no frost)	
vibration	Frequency	5-150Hz
	Displacement	3.5mm(directly install)(<9Hz)
	Acceleration	1g(directly install)(>9Hz)
	Direction	3 axial direction
Shock (collide)	15g, 11ms, half sinusoid, 3 axial direction	
Degree of Protection	IP20	

Chapter III Wiring Communication Config

3.1. Power Input

The power supply input adopts a 3Pin (there are all 3 terminals, E+24V, EGND and FG) screw-type pluggable wiring terminal. This 3Pin terminal is the power supply of the controller.

→ Terminal Definition:

Terminal	Name	Type	Function
	E+24V	Input	Positive (+) terminal of DC power input (connect positive of power to positive of controller)
	EGND	Input	Negative (-) terminal of power input
	FG	Earthing (Grounding)	Protection

3.1.1. Power Specification

→ Specification

Item	Description
Voltage	DC24V (-5%~5%)
The current to open	≤0.5A
The current to work	≤0.4A
Anti-reverse connection	YES
Overcurrent Protection	YES

3.2. RS485, RS422, CAN Communication Interfaces

The communication interface adopts a 10Pin screw-type pluggable wiring terminal and the gap spacing between 2 terminals should be 3.81mm. This terminal is shared by controller RS485, CAN and RS422 communication. It supports MODBUS_RTU protocol and custom communication.

→ Terminal Definition:

Terminal	Name	Function
485B 485A EGND CANL CANH EGND 	485B	485-
	485A	485+
	EGND	External power supply ground
	CANL	CAN differential data -
	CANH	CAN differential data +
	EGND	External power supply ground
	422TX-	RS422 send -
	422TX+	RS422 send +
	422RX-	RS422 receive -
	422RX+	RS422 receive +

3.2.1. RS485 & RS422 & CAN Specification & Wiring

The RS485 serial port supports the MODBUS_RTU protocol and custom communication, mainly including 485A, 485B and public end.

The RS422 serial port supports the MODBUS_RTU protocol and custom communication, mainly including 422TX-, 422TX+, 422RX-, 422RX+ and public end.


The CAN interface of the controller adopts the standard CAN communication protocol, which mainly includes three ports, CANL, CANH and the public end. And it can connect ZIO/ZMIO expansion modules and other standard CAN devices.

→ Specification


Item	RS485	CAN	RS422
Maximum Communication Rate	115200bps	1Mbps	115200bps
Terminal Resistor	120Ω	120Ω	No
Topological Structure	Daisy Chain Topology		Point to many
The number of nodes can be extended	Up to 127	Up to 16	Up to 10
Communication Distance	The longer communication distance is, the lower communication rate is, and max 30m is recommended.		

→ Wiring Reference


Connect 485A and 485B of RS485 to 485A and 485B of the controller correspondingly, and connect the public ends “EGND” of RS485 communication parties together.



Connect the CANL and CANH of the standard CAN module to the CANL and CANH of the other side correspondingly. And public ends of the CAN bus communication both parties are connected together. In CAN bus left and right sides, connect a 120Ω resistor respectively (please see below graphic).



Connect 422TX and 422RX of RS422 to 422TX and 422RX of the controller correspondingly, and connect the public ends "EGND" of RS422 communication parties together.




→ **Wiring Notes:**

- As above, RS485 and CAN bus belong to daisy chain topology connection, and RS422 belongs to point-to-many connection (the star topology structure cannot be used). When the use environment is ideal and there are no many nodes, the branch structure also can be used.
- Please connect a 120Ω terminal resistor in parallel to each end of the CAN bus / RS485 for matching the circuit impedance and ensuring communication stability.
- Please be sure to connect the public ends of each node on the CAN bus / RS485 to prevent the CAN chip from burning out.
- Please use STP (Shielded Twisted Pair), especially in bad environments, and make sure the shielding layer is fully grounded.

- When on-site wiring, pay attention to make the distance between strong current and weak current, it is recommended for the distance to be more than 20cm.
- It should be noted that the equipment grounding (chassis) on the entire line must be good, and the grounding of the chassis should be connected to the standard factory ground pile.

→ **Cable Requirements:**

Shielded Twisted Pair, and the shielded cable is grounded.



3.2.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any one interface among the three interfaces (ETHERNET, RS232, RS485) to connect to RTSys;
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configured parameters, see "ZBasic Programming Manual" for details.
- (4) Please use the "CANIO_ADDRESS" command to set the master's "address" and "speed" according to the needs, and use the "CANIO_ENABLE" command to enable or disable the internal CAN master function, or through "RTSys/Controller/State the Controller/Communication Info" to view the CAN status intuitively, and refer to the "ZBasic Programming Manual" for details.


```
CAN communication settings:  
CANIO_ADDRESS = 32, CANIO_ENABLE = 1  
ZCAN Master  
CAN baud: 500KBPS  
CAN enable: ON  
  
Serial port configuration:  
Port0:(RS232) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0  
Port1:(RS485) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0  
Port2:(RS422) is ModbusSlave Mode.  
Address:1, variable:2  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0
```

- (5) According to their respectively instructions, correctly set the relevant parameters of the third-party equipment to match the parameters of each node.
- (6) Correctly set the "address" and "speed" of the slave station expansion module according to the manual of the slave station.
- (7) After all the settings are completed, restart the power supply of all stations to establish communication.
- (8) Note that the "speed" settings of each node on the CAN bus must be consistent, and the "address" settings cannot cause conflicts, otherwise the "ALM" alarm light will be on, and the communication establishment will fail or the communication will be disordered.

3.3. RS232 Serial Port

RS232 is in one standard DB9 male socket and supports MODBUS_RTU protocol and custom communication.

→ **Interface Definition:**


Terminal	PIN	Name	Type	Function
	1, 4, 6, 7, 8	NC	Spare	Reserved
	2	RXD	Input	RS232 signal, receive data
	3	TXD	Output	RS232 signal, send data
	5	EGND	Output	Negative pole output of 5V power, and output for the public end
	9	E5V	Output	Positive pole output of 5V power, maximum is 300mA

3.3.1. RS232 Specification & Wiring

→ **Specification:**

Item	RS232
Maximum Communication Rate (bps)	115200
Terminal Resistor	No
Topology Structure	Connect correspondingly (1 to 1)
The number of nodes can be extended	1
Communication Distance	The Longer communication distance is, the lower communication rate is, maximum 5m is recommended.

→ **Wiring Reference:**




→ **Wiring Notes:**

- The wiring of RS232 is as above, it needs to cross-wiring for sending and receiving signals, and it is recommended to use a double-female head cross line when connecting to a computer.
- Please be sure to connect the public ends of each communication node to prevent the communication chip from burning out.
- Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.

→ **Cable Requirements:**

Shielded Twisted Pair, and the shielded cable is grounded.



3.3.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any one interface among the three interfaces ETHERNET, RS232 (there is default parameter, which can be connected directly) and RS485 (there is default parameter, which can be connected directly, but for hardware, adapter head is needed) to connect to RTSys.
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configured parameters, see "ZBasic Programming Manual" for details.
- (4) According to their respectively instructions, correctly set the relevant parameters of

the third-party equipment to match the parameters of each node.

- (5) When all is configured, it can start to do communicating.
- (6) Communication data of RS232 / RS485 can be directly viewed through "RTSys / Controller / State the Controller / CommunicationInfo".

```

CAN communication settings:
CANIO_ADDRESS = 32, CANIO_ENABLE = 1
ZCAN Master
CAN baud: 500KBPS
CAN enable: ON

Serial port configuration:
Port0:(RS232) is ModbusSlave Mode.
Address:1, variable:2
Baud:38400
DataBits:8
StopBits:1
Parity:0
Port1:(RS485) is ModbusSlave Mode.
Address:1, variable:2
Baud:38400
DataBits:8
StopBits:1
Parity:0
Port2:(RS422) is ModbusSlave Mode.
Address:1, variable:2
Baud:38400
DataBits:8
StopBits:1
Parity:0

```

3.4. IN Digital Input & High-Speed Latch Port & Single-Ended Encoder

The digital input adopts 3 groups of 10Pin (there are 3 groups of 10 terminals) screw-type pluggable terminals, and the gap distance between terminals should be 3.81mm. In addition, the high-speed latch function and single-ended encoder functions are integrated in digital input signals.

→ Terminal Definition

Terminal	Name	Type	Function 1	Function 2	Function 3
	EGND	/	IO Public End	/	
	EGND	/		/	
	IN0	NPN type,	Input 0	High	EA4

	EGND	IN1	high-speed input	Input 1	Speed Latch	EB4
	IN0	IN2	NPN type, low-speed input	Input 2	/	EZ4
	IN1	IN3		Input 3	/	/
	IN2	IN4		Input 4	/	/
	IN3	IN5		Input 5	/	/
	IN4	IN6		Input 6	/	/
	IN5	IN7		Input 7	/	/
	EGND	/	IO Public End	/	/	
	EGND	/		/	/	
	IN8	NPN type, low-speed input	Input 8	/	/	
	IN9		Input 9	/	/	
	IN10		Input 10	/	/	
	IN11		Input 11	/	/	
	IN12		Input 12	/	/	
	IN13		Input 13	/	/	
	IN14		Input 14	/	/	
	IN15		Input 15	/	/	
	EGND	/	IO Public End	/	/	
	EGND	/		/	/	
	IN16	NPN type, low-speed input	Input 16	/	/	
	IN17		Input 17	/	/	
	IN18		Input 18	/	/	
	IN19		Input 19	/	/	
	IN20		Input 20	/	/	
	IN21		Input 21	/	/	
	IN22		Input 22	/	/	
	IN23		Input 23	/	/	


3.4.1. Digital Input Specification & Wiring

→ Specification


Item	High-Speed Input (IN0-1)	Low-Speed Input (IN2-23)
Input mode	NPN type, input is triggered when there is low-electric level	
Frequency	< 100kHz	< 5kHz
Impedance	3.3KΩ	4.7KΩ
Voltage level	DC24V	DC24V
The voltage to open	<15V	<14.5V
The voltage to close	>15.1V	>14.7V
Minimal current	-2.3mA (negative)	-1.8mA (negative)
Max current	-7.5mA (negative)	-6mA (negative)
Isolation mode	Optoelectronic isolation	
Note: the above parameters are standard values when the voltage of controller power supply (E+24V port) is 24V.		

→ Wiring Reference

General IN Wiring:



Single-Ended Encoder Wiring:



→ Wiring Note:

- The wiring principle of high-speed digital input IN (0-1) and low-speed digital input IN (2-23) is shown in the figure above. The external signal source can be an optocoupler, a key switch or a sensor, etc., all can be connected as long as the requirements on output of electric level can be achieved.
- For the public end, please connect the "EGND" port on the power supply to the "COM" terminal of the external input device. If the signal area power supply of the external device and the power supply of the controller are in the same power supply system, this connection also can be omitted.

3.4.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please select any one interface among the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.
- (3) State values of relative input ports can be read directly through "IN" command, also, it can be read through "RTSys/Tool/In". Please refer to "RTBasic" for details.
- (4) Latch function can be set and triggered through "REGIST" instruction, in software,

use REG_INPUTS to configure. Please refer to "RTBasic" for details.

3.5. OUT (Digital Output, PWM Terminal)

The digital output adopts a set of screw-type pluggable terminals with a spacing of 3.81mm, and the PWM and single-ended pulse functions are integrated in digital output signal.

→ Terminal Definition

Terminal	Name	Type	Function 1	Function 2
EGND	EGND	/	External power ground	/
E5V	E5V	/	External 5V power output, max is 300mA	/
OUT0	OUT0	NPN Leakage type, high-speed output	Output 0	PWM 0
OUT1	OUT1		Output 1	PWM 1
OUT2	OUT2		Output 2	/
OUT3	OUT3		Output 3	/
OUT4	OUT4		Output 4	/
OUT5	OUT5		Output 5	/
OUT6	OUT6		Output 6	/
OUT7	OUT7		Output 7	/

Note:


- ◆ The E5V power output port is used for PWM or common anode wiring of single-ended axis. It is not recommended for other purposes due to lower power.
- ◆ OUT0-1 have the function of PWM. When PWM is off, it is general output.

3.5.1. Digital Output Specification & Wiring

→ Specification

Item	High Speed Output (OUT0-1)	Low Speed Output (OUT2-7)
Output mode	NPN leakage type, it is 0V when outputs	
Frequency	< 400kHz	< 8kHz
Voltage level	DC24V	DC24V
Max output current	+300mA	+300mA
Max leakage current when off	25µA	25µA
Respond time to conduct	1µs (resistive load typical value)	12µs
Respond time to close	3µs	80µs
Overcurrent protection	Support	Support
Isolation method	Optoelectronic isolation	
Note: <ul style="list-style-type: none"> ✧ The times in the form are typical based on the resistive load, and may change when the load circuit changes. ✧ Due to the leak-type output, the shutdown of the output will be obviously affected by the external load circuit, and the output frequency should not be set too high in the application. 		

→ Wiring Reference



→ Wiring Note:

- The wiring principle of high-speed digital output OUT (0-1) and low-speed digital output OUT (2-7) is shown in the figure above. The external signal receiving end can be an optocoupler or a relay or solenoid valve, all can be connected as long as the input current does not exceed 300mA.
- For the connection of the public end, please connect the "EGND" port on the power supply to the negative pole of the DC power supply of the external input device. If the DC power supply of the external device and the controller power supply are in the same power supply system, this connection can also be omitted.
- The E5V port is a 5V power output port, which can be used when some loads need to provide an external 5V power input, the maximum current is 300mA.

3.5.2. Basic Usage Method


- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any one interface among the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.

- (3) Open or close output port directly through "OP" command, also, it can be opened or closed through "RTSys/Tool/Op". Please refer to "RTBasic" for details.
- (4) The PWM function, set the frequency and duty cycle through "PWM_FREQ" and "PWM_DUTY". Please refer to ZBasic for details.

3.6. AD/DA Analog Input / Output

The analog port adopts a set of 6Pin screw-type pluggable terminals with a spacing of 3.81mm.

→ Terminal Definition


Terminal	Name	Type	Function
	DA0	Output	Analog output terminal: AOUT(0)
	DA1		Analog output terminal: AOUT(1)
	DAGND	Public end	Public end of this analog
	AD0	Input	Analog input terminal: AIN(0)
	AD1		Analog input terminal: AIN(1)
	ADGND	Public end	Analog Public End

3.6.1. Analog Input / Output Specification & Wiring

→ Specification

Item	AD (0-1)	DA (0-1)
Resolution	12-bit	12-bit
Data range	0-4095	0-4095
Signal range	0-10V input	0-10V output
Data refresh	1kHz	1kHz
Voltage input impedance / output load	>300KΩ (voltage input impedance)	>10KΩ (voltage output load)

→ Wiring Reference




→ Wiring Note:

- The analog input/output wiring method is as shown in the figure above, and the external load signal range must match with this signal range.
- Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.


→ Cable Requirements:

Shielded Twisted Pair, and the shielded cable is grounded.




3.6.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any one interface among the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.
- (3) Analog input voltage can be read through "AIN" command and corresponding analog voltage can be output through "AOUT" command, also, data of each channel can be checked through "RTSys/View/AD/DA". Please refer to "ZBasic" for details.



3.7. U Disk

The ZMC304 motion controller provides a USB communication interface, which can insert the U disk device. It is used for ZAR program upgrading, controller data importing and exporting, file 3 executing, etc. Its schematic diagram is shown in the figure below:




→ Specification

Item	USB2.0
Highest Communication Ratio	12Mbps
Max Output Current of 5V	500mA
Whether Isolates	No


3.8. ETHERNET

ZMC304 motion controller has a 100M network port, and it supports MODBUS_TCP protocol and custom communication, the default IP address is 192.168.0.11. The pin definition is as follows:




PIN	Signal	Description
1	TX+	Send signal (+)
2	TX-	Send signal (-)
3	RX+	Receive signal (+)
4	NC	Reserved
5	NC	Reserved
6	RX-	Receive signal (-)
7	NC	Reserved
8	NC	Reserved

The Ethernet port of the controller can be connected to a computer, etc. through an Ethernet cable, and using point to point connection method. The schematic diagram is as follows:




The controller can also be connected to the interchanger through an Ethernet cable, and then use interchanger to connect to other devices, then multi-point connection can be achieved. The schematic diagram is as follows:



→ Communication Cable Requirements

Both ETHERNET communication interface adopts standard Ethernet RJ45 interface.

The network cable adopts Category 5e STP, and the crystal head has a metal shell to reduce interference and to prevent information from being eavesdropped. As shown below:



Item	Specification
Cable type	Flexible crossover cable, Category 5e
traverse	twisted pair
Line pairs	4
Isolation	cross skeleton
Connector	Crystal head with iron shell
Cable material	PVC

Cable length	Less than 100m
--------------	----------------

Use RJ45 network cable connection method:


- When installing, hold the crystal head that is with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.
- When disassembling, press the tail mechanism of the crystal head, and pull out the connector and the module in a horizontal direction.

Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.

3.9. AXIS Differential Pulse Axis Interface

This product provides 4 local differential pulse axis interfaces, each interface is a standard DB15 female socket.

→ Interface Definition

Interface	Pin	Signal	Description
	1	PUL+	Servo/stepper pulse output (differential signal) +
	2	DIR+	Servo/stepper directional output (differential signal) +
	3	GND	Negative pole of 5V power of pulse/encoder signal
	4	EA+	Encoder differential input signal A+
	5	EB+	Encoder differential input signal B+
	6	EZ+	Encoder differential input signal Z+
	7	IN24-27/ALM	Digital input, recommended as drive alarm
	8	EGND	Negative pole of IO 24V power
	9	PUL-	Servo/stepper pulse output (differential signal) -

	10	DIR-	Servo/stepper directional output (differential signal) -
	11	+5V	Positive pole of 5V power of pulse/encoder signal
	12	EA-	Encoder differential input signal A-
	13	EB-	Encoder differential input signal B-
	14	EZ-	Encoder differential input signal Z-
	15	OUT8- 11/ENABLE	Digital output, recommended as drive enable

Note:

- ◇ ALM and ENABLE are recommended to be used as axis IO, because the drive capacity is small.
- ◇ +5V is only used for communication between the controller and the servo driver, please do not use it as power supply for other places.

Pulse Axis Pin No. & IO

Pulse Axis No.	Related IN (PIN 7)	Related OUT (PIN 15)
AXIS 0	IN24	OUT8
AXIS 1	IN25	OUT9
AXIS 2	IN26	OUT10
AXIS 3	IN27	OUT11

3.9.1. AXIS Interface Signal Specification & Wiring


→ Specification:

Signal	Item	Description
PUL/DIR	Signal type	Differential output signal
	Voltage range	0-5V
	Maximum frequency	10MHz
EA/EB/EZ	Signal type	Differential input signal
	Voltage range	0-5V
	Maximum frequency	5MHz
IN24-27	Input method	NPN leak type, it is triggered


		when low electric level is input.
	Frequency	< 5kHz
	Impedance	6.8KΩ
	Voltage level	DC24V
	The voltage to open	<10.5V
	The voltage to close	>10.7V
	Minimal current	-1.8mA (negative)
	Maximum current	-4mA (negative)
	Isolation	optoelectronic isolation
OUT8-11	Output method	NPN leak type, it is 0V when outputs
	Frequency	< 8kHz
	Voltage level	DC24V
	Maximum current	+50mA
	Overcurrent protection	No
	Isolation	optoelectronic isolation
+5V, GND	Maximum output current for 5V	50mA
OVCC, EGND	Maximum output current for 24V	50mA

→ Wiring Reference:


Reference example of wiring with Panasonic A5/A6 servo driver.



Single-Ended Pulse-Axis Wiring:



Single-Ended Encoder Wiring:



→ Wiring Note:

- ✧ The wiring principle of the differential pulse axis interface is shown in the figure above, and the wiring methods of different types of drivers are different, please connect carefully.
- ✧ Please use STP, especially in bad environments, and make sure the shielding layer is fully grounded.

3.9.2. Basic Usage Method

- (1) Please follow the above wiring instructions to wiring correctly.
- (2) After powered on, please use any one interface among the three interfaces ETHERNET,

RS232 (default parameter, it can be connected directly) and RS485 (default parameters, it can be connected directly, but for hardware, adapter head is needed) to connect to RTSys.

- (3) Set axis parameters, such as, ATYPE, UNITS, SPEED, ACCEL, FWD_IN, REV_IN, etc.
- (4) There are many parameters related to pulse axis, they can be set and checked through relative instructions, please see "axis parameter and axis status" of "RTBasic", or see "RTSys/View/Axis parameter".

Axis select		Parameter select			
		Axis0	Axis1	Axis2	Axis3
COMMENT					
ATYPE	0	0	0	0	0
UNITS	1	1	1	1	1
ACCEL	10000	10000	10000	10000	10000
DECCEL	0	0	0	0	0
SPEED	1000	1000	1000	1000	1000
CREEP	100	100	100	100	100
LSPEED	0	0	0	0	0
MERGE	0	0	0	0	0
SRAMP	0	0	0	0	0
DPOS	0	0	0	0	0
MPOS	0	0	0	0	0
ENDMOVE	0	0	0	0	0
FS_LIMIT	200000000	200000000	200000000	200000000	200000000
RS_LIMIT	-200000000	-200000000	-200000000	-200000000	-200000000

- (5) Control corresponding motion through "View – Manual".

Manual															
Axis	ATYPE	UNITS	ACCEL	DECCEL	SPEED	DPOS	Left\Move	Right\Move	Distance	Absolute	MPOS	IDLE	AXISSTATUS		
0	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop
1	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop
2	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop
3	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop
4	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop
5	0	1.000	10000.C	0.000	1000.0C	0.000	Left	Right			Move	0.000	-1	0h	Stop

Refer to BASIC Routine:

BASE(0,1)	'select axis 0 and axis 1
ATYPE = 1,1	'set axis 0 and axis 1 as pulse axes
UNITS = 1000,1000	'set pulse amount as 1000 pulses

SPEED = 10,10	'set axis speed as 10*1000 pulse/s
ACCEL = 1000,1000	'set axis acceleration as 1000*1000 pulse/s/s
FWD_IN = -1,-1	'prohibit using axis positive hardware position limit
REV_IN = -1,-1	'prohibit using axis negative hardware position limit
MOVE(10) AXIS(0)	'axis 0 moves distance of 10*1000 pulses in positive
MOVE(-20) AXIS(0)	'axis 0 moves distance of 20*1000 pulses in negative

Chapter IV Expansion Module

The controller can expand digital IO, analog IO, pulse axis and other resources through CAN bus (ZIO series expansion modules / ZMIO310 CAN expansion modules. For details, please refer to each manual.

4.1. CAN Bus Expansion Wiring

[ZIO series expansion modules](#) or [ZMIO310-CAN coupler with sub modules](#) can be used.



Connect control card to CAN bus expansion modules, when the eighth bit of the DIP switch of the expansion module is turned to ON, which indicates that a 120-ohm resistor has been connected, but needs to connect one 120-ohm resistor externally. When connecting multiple CAN expansion modules, you only need to dial ON for the eighth digit of the last expansion module, which means please do not dial bit-8 of other modules.

The CAN expansion module is powered by the dual power supply. Except the main power supply, an additional IO power supply is required to supply independent power for IO. Both the main power supply and the IO power supply use 24V DC power supply. For ZAIO, it only needs to connect to the main power supply.

To prevent interference, separate the IO power supply from the main power supply.

Please select the expansion module according to the requirements, and select IO mapping or axis mapping according to the resources of the expansion module.


Wiring reference of connection between ZIO expansion module and control card and standard wiring of CAN bus are shown as below:



→ **Wiring Note:**

- ✧ ZMC304 controller uses the single power, and CAN expansion module uses dual-power. When using, main power supply of expansion module and main power supply of controller can share one power. When they use different power supplies, controller power EGND needs to connect to expansion module power GND, otherwise CAN may be burnt out.
- ✧ When connecting multiple CAN expansion modules on the CAN bus, a 120-ohm resistor needs to be connected in parallel between the CANL and CANH terminals, for the expansion module that is with 8-digit dialing codes, the terminal resistor can be realized by dialing the code (DIP).

4.2. CAN Bus Expansion Resource Mapping



The ZCAN expansion module generally has an 8-bit DIP switch, dial ON to take effect, and the meaning of the DIP is as follows:

1-4: they are used for ZCAN expansion module IO address mapping, the corresponding value is 0-15.

5-6: CAN communication speed, corresponding value is 0-3, four different speeds are optional.

7: reserved.

8: 120-ohm resistor, dial ON means a 120-ohm resistor is connected between CANL and CANH.

The IO numbers of the entire control system cannot be repeated, and existed numbers must be avoided when mapping resources. And the DIP switch must be dialed before power-on, if re-dial after power-on, it is invalid. It needs to be powered on again to take effect.

Dial 1-4 to select the CAN address, and the controller sets the IO number range of the corresponding expansion module according to the CAN DIP address. When each is dialed as OFF, the corresponding value is 0, when it is ON, it corresponds to a value of 1, and the address combination value = dial 4×8 + dial code 3×4 + dial code 2×2 + dial code 1.

Dial code 5-6 to select CAN bus communication speed, speed combination value=dial code 6×2 + dial code 5×1 , the combined value range is 0-3.

The corresponding speeds are as follows:

DIP 5-6 combination value	CANIO_ADDRESS high 8-bit value	CAN communication speed
0	0 (corresponds to decimal 128)	500KBPS (default value)
1	1 (corresponds to decimal 256)	250KBPS
2	2 (corresponding to decimal 512)	125KBPS
3	3 (corresponding to decimal 768)	1MBPS

The controller side sets the CAN communication speed through the CANIO_ADDRESS command. There are also four speed parameters that can be selected. The

communication speed must be consistent with the communication speed of the expansion module that corresponds to the combination value, then they can communicate with each other.

The factory default communication speed is 500 KBPS on both sides, there is no need to set this, unless you need to change the speed.

The CANIO_ADDRESS command is a system parameter, and it can set the master-slave end of CAN communication. The default value of the controller is 32, that is, CANIO_ADDRESS=32 is the master end, and the slave end is set between 0-31.

The CAN communication configuration can be viewed in the "State the Controller" window.

→ **IO Mapping:**

the CAN expansion module uses bit1-4 of the DIP switch. According to the number of currently included IO points(the largest number in IN and OP must include IO point in the axis interface), use the bit 1-4 to set the ID, so as to determine the number range of IO to be expanded.

If the controller itself contains 28 INs and 16 OPs, then the starting address set by the first extended board should exceed the maximum value of 28. According to below rule, the dial code should be set to the combination value 1 (binary combination value 0001, from right to left, dial code 1-4, at this time dial 1 is set to ON, and the others are set to OFF), the IO number on the expansion board = the expansion board number value + the initial IO number value, among them, the IOs that are vacant from 29-31 Numbers are not used. Subsequent extended boards continue to confirm the dial settings according to the IO points in turn.

The initial digital IO mapping number starts from 16 and increases in multiples of 16. The distribution of digital IO numbers corresponding to different dial IDs is as follows:

DIP 1-4 combination value	Starting IO number	Ending IO number
0	16	31
1	32	47
2	48	63
3	64	79
4	80	95
5	96	111
6	112	127
7	128	143

8	144	159
9	160	175
10	176	191
11	192	207
12	208	223
13	224	239
14	240	255
15	256	271

The initial IO mapping number of the analog AD starts from 8 and increases in multiples of 8. The initial IO mapping number of the analog DA starts from 4 and increases in multiples of 4. The allocation of digital IO numbers corresponding to different dial code IDs is as follows:

DIP 1-4 combination value	Starting AD number	End AD number	Starting DA number	End DA number
0	8	15	4	7
1	16	23	8	11
2	24	31	12	15
3	32	39	16	19
4	40	47	20	23
5	48	55	24	27
6	56	63	28	31
7	64	71	32	35
8	72	79	36	39
9	80	87	40	43
10	88	95	44	47
11	96	103	48	51
12	104	111	52	55
13	112	119	56	59
14	120	127	60	63
15	128	135	64	67

→ Axis Mapping:

When the CAN bus expansion mode is used to expand the pulse axis, ZIO16082M can be selected to expand two pulse axes. These two pulse axes need to be mapped and bound with the axis No., then access.

Extended axes need to perform axis mapping operations, using the AXIS_ADDRESS command to map, and the mapping rules are as follows:

AXIS_ADDRESS(axis No.)=(32*0)+ID

'the local axis interface of the expansion module AXIS 0

AXIS_ADDRESS(axis No.)=(32*1)+ID

'the local axis interface of the expansion module AXIS 1

The ID is the combined value of the DIP bit1-4 of the expansion module. After the mapping is completed and the axis parameters such as ATYPE are set, the expansion axis can be used.

Example:

ATYPE(6)=0 'set as virtual axis

AXIS_ADDRESS(6)=1+(32*0)

'ZCAN expansion module ID 1 axis 0 is mapped to axis 6

ATYPE(6)=8 'ZCAN extended axis type, pulse direction stepping or servo

UNITS(6)=100 0 'pulse equivalent 1000

SPEED(6)=100 'speed 100units/s

ACCEL(6)=1000 'acceleration 1000units/s^2

MOVE(100) AXIS(6) 'extended axis movement 100units

Extended resource viewing:

According to the CAN connection, after the power is turned on, and the wiring resistance dial code is set correctly, the power indication led (POWER) and the running indication led (RUN), the IO power indication led (IO POWER) are on, and the alarm indication led (ALM) is off. At the same time, the "Controller" - "State the controller" - "ZCanNodes" in the RTSys software displays the expansion module information and the extended IO number range.

The dial ID and the corresponding resource number when connecting multiple expansion modules are as follows:

Local	432-0(ZMC432)	32	30(0-29)	18(0-17)	0	2(0-1)	
1	48(ZIO1632)	0	16(32-47)	32(32-63)	0	0	
3	26(ZIO16082)	2	16(64-79)	8(64-71)	0	0	
4	10(ZAIO0802)	0	0	0	8(40-47)	2(20-21)	

ALM indicator light is on, please check whether the wiring, resistor and dial setting are correct, and whether the CANIO_ADDRESS command of the controller is set as the master end (32), and whether the CAN communication speed is consistent.

Chapter V Programming

5.1. Program in RTSys Software


RTSys is a PC-side program development, debugging and diagnostic software for the Zmotion motion controllers. Through it, users can easily edit and configure the controller program, quickly develop applications, diagnose system operating parameters in real time, and debug the running program in real time. What's more, it supports Chinese and English bilingual environments.

In RTSys, there are 4 programming languages for motion control development, Basic, PLC, HMI and C language, they can run multi-tasks among them, especially for Basic, multi-task running can be achieved separately, hybrid programming is also OK with PLC, HMI and C language.



RTSys Downloading Address: https://www.zmotionglobal.com/pro_info_282.html




And related manuals can be found in “Download”:





Features		Parameters		System Architecture	Download
Name	Version No	Format	Size	Download	
RTSys Development Software	V1.2.02	RAR	148MB	Download	
RTSys User Manual V1.2.0	V1.2.0	PDF	5.33MB	Download	
RTBasic Programming Manual	V1.1.0	PDF	18.3MB	Download	
RTHMI Programming Manual	V1.2.0	PDF	7.23MB	Download	
Quick Start	VQuick Start	ZIP	16.1MB	Download	
ZVision Basic Programming Manual V1.3.0	V1.3.0	PDF	10.6MB	Download	
ZPLC	V1.0	PDF	1.7M	Download	

Step	Operations	Display Interface
1	Switch the Language: “Language” – “English”, then there will pop up one window,	

	click OK, and restart it.	<p>Language Switch Video Showing:</p> <p>E. How to Switch the Language</p> <p>Find "视图" (the fourth one in the above menu), then find the "语言", choose English, restart RTSys. English RTSys will take effect when opened again.</p>
2	<p>New Project:</p> <p>"File" – "New Project", Save as window will pop up, then enter file name, save the project file with suffix ".zpj".</p>	

3	<p>New File: "File"</p> <ul style="list-style-type: none"> – "New File", select file type to build, here select Basic, click "OK". 	
4	<p>Set Auto Run</p> <p>No.: right click the file, open task number setting window, enter task No., which can be any + value, no priority, but not the same.</p>	

5	<p>Save File: edit the program in program editing window, click "save", new built file will be saved under "zpj." project automatically.</p> <p>"Save all" means all files under this project will be saved.</p>	
6	<p>Connection: Click "controller - connect", if no controller, select connect to simulator.</p>	
6	<p>Then, "connect to controller" window will pop up, you can select serial port or net port to connect, select matched serial port parameters or net port IP address, then click "connect".</p>	
7	<p>Download Program into</p>	<ul style="list-style-type: none"> ● RAM: it will not save when power off. ● ROM: it will save data when power off, and when the program

	<p>Controller: "Ram/Rom" – "download RAM / download ROM", if it is successful, there is print indication, at the same time, program is downloaded into controller and runs automatically.</p>	<p>is connected to controller again, running according to task No.</p> 
8	<p>Debug: "Debug" – "Start/Stop Debug" to call "Task" and "Watch" window, because it was downloaded before, here select "Attach the current".</p>	 
9	<p>Scope function: Click "View" – "Scope" to open oscilloscope. It can capture needed data, for debugging.</p>	

Notes:

- When opening an project, choose to open the zpj file of the project. **If only the Bas file is opened, the program cannot be downloaded to the controller.**
- When the project is not created, only the Bas file **cannot be** downloaded to the controller.
- The number 0 in automatic operation represents the task number, and the program runs with task 0, and the task number has no priority.
- If no task number is set for the files in the entire project, when downloading to the controller, the system prompts the following message **WARN: no program set autorun**

5.2. Upgrade Controller Firmware

Firmware upgrade can be achieved by downloading zfm firmware package in RTSys. zfm file is the firmware upgrade package of controller, please select corresponding firmware because different models are with different packages, please contact manufacturer).

How to update:

- a. Open [ZDevelop](#) / [RTSys](#) software, then click "controller – connect", find PCI/LOCAL method, click "connect". If connected, there will be "Connected to Controller: PCIE464 Version: 4.93 – 20231220." In "output" window.
- b. Click "controller – state the controller", find basic info, then current software version can be checked.
- c. Click "controller – update firmware", current controller model and software version can be viewed.
- d. Click "browse", and select saved firmware file, click "update", then one window will pop up, please click "ok".
- e. After that, "connect to controller" window appears again, and please select "PCI/Local" again, and click "connect".
- f. When connection is successful, "firmware update" interface is shown. Now

system enters ZBIOS state, please click "update" again.

- g. When it is loaded, "firmware update" window disappears, now in output window, it shows "Update firmware to Controller Success".
- h. Do step a and step b again, check whether the firmware is updated or not.

5.3. Program in Host-Computer by PC Languages

The controller supports development under various operating systems such as windows, linux, Mac, Android, and wince, and provides dll libraries in various environments such as vc, c#, vb.net, and labview, as shown in the figure below. PC software programming refers to ["Zmotion PC Function Library Programming Manual"](#).









The program developed using the PC software cannot be downloaded to the controller, and it is connected to the controller through the dll dynamic library. The dll library needs to be added to the header file and declared during development.

- Get PC library file, example: https://www.zmotionglobal.com/download_list_17.html

A screenshot of a website page showing a list of software development examples. The top navigation bar includes links for Hardware Manuals, Software Manuals (highlighted with a red arrow), Tool Software, Products Catalogs, Development Examples (highlighted with a red box and arrow), PC Library Files, and Product 3D Model. Below the navigation is a table with rows for Quick Start, Bus INIT BASIC, C Sharp, C PLUS PLUS, LABVIEW, Python, and Linux C Sharp 64 Bit. Each row has a 'Download' button on the right. The 'Development Examples' link in the navigation bar is highlighted with a red box and arrow.

The c++ project development process in VS is as follows:

Step	Operations	Display Interface
1	Open VS, click "File" – "New" – "Project".	
2	Select development language as "Visual C++" and the select program type as "MFC application type".	
3	Select "Based on basic box", click "next" or "finish"	
4	Find C++ function library provided by manufacturer. Routine is below (64-bit library)	
5	Copy all DLL related library files under the above path to the newly created project.	

6	<p>Add a static library and related header files to the project. Static library: zauxdll.lib, zmotion.lib</p> <p>Related header files: zauxdll2.h, zmotion.h</p>	<p>1) Right-click the header file first, and then select: "Add" → "Existing Item".</p>	 
7	<p>Declare the relevant header files and define the controller connection handle, so far the project is newly created.</p>		

Chapter VI Operation and Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce the probability of equipment failure.

6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
power supply	Check whether the voltage is rated	DC 24V (-5%~5%)
surroundings	Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature)	-10°C - 55°C
	Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity)	10%-95% non-condensing
	Is there direct sunlight	No
	With or without droplets of water, oil, chemicals, etc.	No
	Whether there is dust, salt, iron filings, dirt	No
	Whether there is corrosive gas	No
	Whether there are flammable and	No

	explosive gases or articles	
	Whether the device is subjected to vibration or shock	Should be within the range of vibration resistance and impact resistance
	Is the heat dissipation good	Keep good ventilation and heat dissipation
Installation and Wiring Status	Whether the basic unit and the expansion unit are installed firmly	The mounting screws should be tightened without loosening
	Whether the connecting cables of the basic unit and the expansion unit are fully inserted	The connection cable cannot be loosened
	Are the screws of the external wiring loose	Screws should be tightened without loosening
	Whether the cable is damaged, aged, cracked	The cable must not have any abnormal appearance

6.2. Common Problems & Solutions

Problems	Suggestions
Motor does not rotate.	<ol style="list-style-type: none"> 1. Check whether the ATYPE of the controller is correct. 2. Check whether hardware position limit, software position limit, alarm signal work, and whether axis states are normal. 3. Check whether motor is enabled successfully. 4. Confirm whether pulse amount UNITS and speed values are suitable. If there is the encoder feedback, check whether MPOS changes. 5. Check whether pulse mode and pulse mode of drive are matched. 6. Check whether alarm is produced on motion controller station or drive station. 7. Check whether the wiring is correct. 8. Confirm whether controller sends pulses normally.

The position limit signal is invalid.	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
No signal comes to the input.	<ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller.
The output does not work.	<ol style="list-style-type: none"> 1. Check whether IO power is needed. 2. Check whether the output number matches the ID of the IO board.
POWER led is ON, RUN led is OFF.	<ol style="list-style-type: none"> 1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the controller alone, and restart the controller after adjustment. 2. Check whether the ALM light flickers regularly (hardware problem).
RUN led is ON, ALM led is ON.	<ol style="list-style-type: none"> 1. Program running error, please check RTSys error code, and check application program.
Fail to connect controller to PC through serial port.	<ol style="list-style-type: none"> 1. Check whether the serial port parameters are modified by the running program, you can check all the current serial port configurations through ?*SETCOM. 2. Check whether the serial port parameters of the PC match the controller. 3. Open the device manager and check whether the serial driver of the PC is normal.
CAN expansion module cannot be connected.	<ol style="list-style-type: none"> 1. Check the CAN wiring and power supply circuit, whether the 120 ohm resistor is installed at both

	<p>ends.</p> <ol style="list-style-type: none">2. Check the master-slave configuration, communication speed configuration, etc.3. Check the DIP switch to see if there are multiple expansion modules with the same ID.4. Use twisted-pair cables, ground the shielding layer, and use dual power supplies for severe interference (the main power supply of the expansion module and the IO power supply are separately powered)
Fail to connect controller to PC through net port.	<ol style="list-style-type: none">1. Check IP address of PC, it needs to be at the same segment with controller IP address.2. Check controller IP address, it can be checked and captured after connection through serial port.3. When net port led is off, please check wiring.4. Check whether controller power led POWER and running indicator led RUN are ON normally.5. Check whether the cable is good quality, change one better cable to try again.6. Check whether controller IP conflicts with other devices.7. Check whether controller net port channel ETH are all occupied by other devices, disconnect to other devices, then try again.8. When there are multiple net cards, don't use other net cards, or change one computer to connect again.9. Check PC firewall setting.10. Use "Packet Internet Groper" tool (Ping), check whether controller can be Ping, if it can't, please check physical interface or net cable.11. Check IP address and MAC address through arp-a.