




EtherCAT & Pulse Motion Controller


ZMC316BE




Motion
Controller



Motion
Control Card



Vision Motion
Controller



IO Expansion
Module



HMI

Statement

Thank you for choosing our Zmotion products. Please be sure to read this manual carefully before use so that you can use this product correctly and safely. Zmotion is not responsible for any direct or indirect losses caused by the use of this product.

The copyright of this manual belongs to Shenzhen Zmotion Technology Co., Ltd. And reproduction, translation, and plagiarism of any content in this manual in any form is strictly prohibited without the written permission of Zmotion.

The information in this manual is for reference only. Due to design improvements and other reasons, Zmotion reserves the right of final interpretation of this information! Contents are subject to change without prior notice!

➤ Notes

In order to prevent possible harm and damage caused by incorrect use of this product, the following instructions are given on matters that must be observed.

■ Danger

| | |
|--|--|
| Do not use it in places with water, corrosive or flammable gases, or near flammable substances. | May cause electric shock, fire, damage, etc. |
| When installing or disassembling, make sure the product is powered off. | |
| Cables should be connected securely, and exposed parts that are energized must be insulated by insulators. | |
| Wiring work must be performed by professionals. | |

■ Notes

| | |
|---|---------------------------------------|
| It should be installed within the specified environmental range. | May cause damage, mis-operation, etc. |
| Make sure there are no foreign objects on the product hardware circuit board. | |
| After installation, the product and the mounting bracket should be tight and firm. | |
| After installation, at least 2-3cm should be left between the product and surrounding components for ventilation and replacement. | |
| Never disassemble, modify, or repair it by yourself. | |

Content

| | |
|---|----|
| Chapter I Production Information..... | 5 |
| 1.1. Product Information | 5 |
| 1.2. Function Features..... | 5 |
| 1.3. System Frame..... | 6 |
| 1.4. Hardware Installment..... | 7 |
| Chapter II Product Specification | 9 |
| 2.1. Basic Specification..... | 9 |
| 2.2. Order Information | 10 |
| 2.3. Interface Definition..... | 11 |
| 2.4. Work Environment | 12 |
| Chapter III Wiring & Communication..... | 14 |
| 3.1. Power Input | 14 |
| 3.1.1. Power Specification | 14 |
| 3.2. RS485, RS422, CAN Communication Interface | 14 |
| 3.2.1. RS485, RS422, CAN Communication Specification & Wiring | 15 |
| 3.2.2. Basic Usage | 18 |
| 3.3. RS232 Serial Port..... | 19 |
| 3.3.1. RS232 Communication Specification & Wiring | 19 |
| 3.3.2. Basic Usage Method | 21 |
| 3.4. IN Digital Input & Single-Ended Encoder & High-Speed Latch..... | 21 |
| 3.4.1. Digital Input Specification & Wiring | 23 |
| 3.4.2. Basic Usage Method | 24 |
| 3.5. OUT: Digital Output, PWM Terminal, Single-Ended Pulse | 25 |
| 3.5.1. Digital Output Specification & Wiring | 26 |
| 3.5.2. Basic Usage | 28 |
| 3.6. AD/DA Analog Input & Output | 28 |
| 3.6.1. Analog Input / Output Specification & Wiring..... | 29 |
| 3.6.2. Basic Usage Method | 30 |
| 3.7. U Disk..... | 30 |
| 3.8. ETHERNET | 31 |
| 3.9. EtherCAT Bus Interface | 32 |
| 3.10. ENCODER Interface..... | 34 |
| 3.10.1. ENCODER Interface Specification & Wiring | 35 |
| 3.11. AXIS Differential Pulse Axis Interface | 36 |
| 3.11.1. AXIS Interface Signal Specification & Wiring..... | 37 |
| 3.11.2. Basic Usage Method | 39 |
| Chapter IV Expansion Module | 41 |
| 4.1. CAN Bus Expansion | 41 |

| | |
|---|----|
| 4.1.1. CAN Bus Expansion Wiring | 41 |
| 4.1.2. CAN Bus Expansion Resource Mapping | 43 |
| 4.2. EtherCAT Bus Expansion | 47 |
| 4.2.1. EtherCAT Bus Expansion Wiring | 47 |
| 4.2.2. EtherCAT Bus Expansion Resource Mapping | 49 |
| Chapter V Programming..... | 51 |
| 5.1. Program in RTSys Software | 51 |
| 5.2. Upgrade Controller Firmware | 56 |
| 5.3. Program in Host-Computer by PC Languages | 57 |
| Chapter VI Operation and Maintain..... | 60 |
| 6.1. Regular Inspection and Maintenance | 60 |
| 6.2. Common Problems & Solutions | 61 |

Chapter I Production Information

1.1. Product Information

ZMC is the abbreviation of the network motion controller model launched by Zmotion Technology.

ZMC316BE high-performance multi-axis motion controller is a stand-alone motion controller compatible with EtherCAT bus and pulse type. The controller itself supports 16 axes at most, but it can be extended to 22 axes for complex continuous trajectory control requirements.


ZMC3 series high-performance multi-axis motion controller can be applied in robots (SCARA, Delta, 6 joints), electronic semiconductor equipment (testing equipment, assembly equipment, locking equipment, soldering machine), dispensing equipment, non-standard equipment, printing and packaging equipment, textile and garment equipment, stage entertainment equipment, medical equipment, assembly line, etc.

1.2. Function Features

- ◆ Motion control of up to 22 axes.
- ◆ Pulse output mode: pulse / direction or dual pulses.
- ◆ Maximum pulse frequency output of each axis: 10MHZ.
- ◆ 4096 isolated inputs and 4096 isolated outputs can be extended at most by CAN.
- ◆ Axis position limit signal / origin signal port can be configured as any input at will.
- ◆ The maximum output current of general digital outputs can reach 300mA, which can directly drive some kinds of solenoid valves.
- ◆ Interfaces: EtherCAT, RS232, RS485, RS422, U Disk, Ethernet.


- ◆ Support linear interpolation, any circular interpolation, helical interpolation and spline interpolation of 22 axes at most.
- ◆ Support electronic cam, electronic gear, position latch, synchronous follow, virtual axis, etc.
- ◆ Support pulse closed loop, pitch compensation and other functions.
- ◆ Multi-file and multi-task programming in Basic.
- ◆ A variety of program encryption methods to protect your intellectual property rights.
- ◆ Power failure detection and power failure storage.

1.3. System Frame



1.4. Hardware Installment

The ZMC316BE motion controller adopts the horizontal installation method of screw fixing, and each controller should be installed with 4 screws for fastening.



→ Unit: mm → Installation Hole Diameter: 4.5mm

| | |
|--|---|
|  Installation attention | <ul style="list-style-type: none"> Non-professionals are strictly prohibited to operate. Specifically, professionals who had been trained related electrical equipment, or who master electrical knowledge. Please be sure to read the product instruction manual and safety precautions carefully before installation. Before installation, please ensure that the product is powered off. Do not disassemble the module, otherwise the machine may be damaged. Avoid direct sunlight installation. |
|--|---|

| | |
|--|--|
| | <ul style="list-style-type: none">● In order to facilitate ventilation and controller replacement, 2-3cm should be left between the upper and lower parts of the controller and the installation environment and surrounding components.● Considering the convenient operation and maintenance of the controller, please do not install the controller in the following places:<ol style="list-style-type: none">a) places where the surrounding ambient temperature exceeds the range of -10°C-55°Cb) places where the ambient humidity exceeds the range of 10%-95% (non-condensing)c) places with corrosive gases and flammable gasesd) places with many conductive powders such as dust and iron powder, oil mist, salt, and organic solvents |
|--|--|

Chapter II Product Specification


2.1. Basic Specification

| Item | Description |
|--------------------------|---|
| Model | ZMC316BE |
| Basic Axes | 16 (15 specialized pulse axis interfaces + 1 general output that supports pulse output) |
| Max Extended Axes | 22 |
| Basic Axes Type | EtherCAT/local pulse axis/encoder axis |
| Digital IO | 24+15 inputs, 8+15 outputs |
| Max Extended IO | 4096 inputs, 4096 outputs |
| PWM | 2 |
| AD/DA | 2 general ADs, 0-10V. 2 general DAs, 0-10V. |
| Max Extended AD/DA | 520 ADs, 520 DAs |
| Pulse Bit | 32 |
| Encoder Bit | 32 |
| Speed & Acceleration Bit | 32 |
| Pulse Max Frequency | 10MHz |
| Motion Axis Buffer | 128 |
| Array Space | 320000 |
| Program Space | 15MByte |
| Flash Space | 126MByte |
| Power Supply Input | 24V DC input |
| Communication Interfaces | RS232, RS485, RS422, Ethernet, U disk, CAN, EtherCAT |
| Dimensions | 241mm*149mm*37mm |

2.2. Order Information

| ZMC316BE-6-XXX | |
|----------------|--|
| Mark | Description |
| ZMC316BE | 16-Axis Controller |
| Mark | Communication Protocol |
| E | EtherCAT |
| Mark | Other Functions |
| XXX | Customized Functions |
| Mark | Functions |
| 1 | point, electronic cam |
| 2 | point, electronic cam, line |
| 6 | point, electronic cam, line, arc |
| Empty | point, electronic cam, line, arc, continuous trajectory motion, robotic arm |
| Model | Description |
| ZMC316BE | 16 axes, point to point, linear, circular, electronic cam, continuous trajectory motion, robotic arm instructions. |

2.3. Interface Definition



→ [Interface Description](#)

| Mark | Interface | Number | Description |
|-------|-------------------------------|--------|---|
| POW | Status Indication Light | 1 | Power indicator: it lights when power is conducted. |
| RUN | | 1 | Run indicator: it lights when runs normally |
| ALM | | 1 | Error indicator: it lights when runs abnormally |
| RS232 | RS232 serial port (port0) | 1 | Use MODBUS_RTU protocol |
| RS485 | RS485 serial | 1 | Use MODBUS_RTU protocol |

| | | | |
|----------|---------------------------|-------|--|
| | port (port1) | | |
| RS422 | RS422 serial port (port2) | 1 | Use MODBUS_RTU protocol |
| EtherCAT | EtherCAT bus interface | 1 | EtherCAT bus interface, connect to EtherCAT bus drive and EtherCAT bus expansion module |
| ETHERNET | Ethernet | 1 | Use MODBUS_TCP protocol, expand Ethernet through interchanger, the number of net port channels can be checked through "?*port", default IP address id 192.168.0.11 |
| UDISK | U disk interface | 1 | Insert U disk equipment |
| E+24V | Main power | 1 | 24V DC power supplies for controller |
| CAN | CAN bus interface | 1 | Connect to CAN expansion module or controller. |
| IN | Digital IO input | 24+15 | NPN type, internal 24V supply power, 2 high-speed inputs, IN0-1 have latch function, IN0-2 have encoder function. |
| OUT | Digital IO output | 8+15 | NPN type, OUT0-1 support PWM function, OUT2-3 support pulse output function. |
| AD/DA | Analog input / output | 2 | Resolution: 12 bits, 0-10V |
| ENCODER | Encoder | 3 | Include differential encoder input |
| AXIS | Pulse axis | 15 | Include differential pulse output |

2.4. Work Environment

| Item | | Parameters |
|------------------------|-----------|---------------------------|
| Work Temperature | | -10°C-55°C |
| Work relative Humidity | | 10%-95% non-condensing |
| Storage Temperature | | -40°C ~ 80°C (not frozen) |
| Storage Humidity | | Below 90%RH (no frost) |
| vibration | Frequency | 5-150Hz |

| | | |
|--|----------------------|---|
| | Displacement | 3.5mm(directly install)(<9Hz) |
| | Acceleration | 1g(directly install)(>9Hz) |
| | Direction | 3 axial direction |
| | Shock (collide) | 15g, 11ms, half sinusoid, 3 axial direction |
| | Degree of Protection | IP20 |

Chapter III Wiring & Communication

3.1. Power Input

The power input adopts a screw-type pluggable terminal with a 5Pin pitch of 3.81mm, which is the power supply of the controller.

→ Terminal Definition:

| Terminal | Name | Type | Function |
|---|-------|-------------------|------------------------|
|  | E+24V | Input | DC input positive pole |
| | EGND | Input | DC input negative pole |
| | FG | Connect to ground | Case Protection Ground |

3.1.1. Power Specification

→ Specification

| Item | Description |
|-------------------------|----------------|
| Input Voltage | DC24V (-5%~5%) |
| Opening Current | ≤0.5A |
| Work Current | ≤0.4A |
| Anti-reverse connection | YES |
| Overcurrent Protection | YES |

3.2. RS485, RS422, CAN Communication Interface

The communication interface adopts a screw-type pluggable wiring terminal with a 10Pin spacing of 3.81mm. And this terminal can be shared with controller RS485, RS422 and CAN communication. It supports MODBUS_RTU protocol and custom communication.

→ Terminal Definition:

| Terminal | Name | Function |
|----------|--------|--------------------------|
| 485B | 485B | 485- |
| 485A | 485A | 485+ |
| EGND | EGND | Communication Public End |
| CANL | CANL | CAN differential data - |
| CANH | CANH | CAN differential data + |
| EGND | EGND | Communication Public End |
| 422TX- | 422TX- | RS422 send - |
| 422TX+ | 422TX+ | RS422 send + |
| 422RX- | 422RX- | RS422 receive - |
| 422RX+ | 422RX+ | RS422 receive + |

3.2.1. RS485, RS422, CAN Specification & Wiring

The RS485 serial port supports the MODBUS_RTU protocol and custom communication, mainly including 485A, 485B and common port.

The CAN interface of the controller adopts the standard CAN communication protocol, which mainly includes three ports, CANL, CANH and the common port. And it supports connecting CAN expansion modules and other standard CAN devices.

RS422 serial port supports MODBUS_RTU protocol and custom communication, mainly including 422TX-, 422TX+, 422RX-, 422RX+ and common port.


→ Specification

| Item | RS485 | CAN | RS422 |
|------------------------------|----------------------------------|------|----------------------|
| Max Communication Rate (bps) | 115200 | 1M | 115200 |
| Terminal Resistor | / | 120Ω | / |
| Topology | Daisy chain connection structure | | Point to multi-point |


| | | | |
|------------------------|--|----------|----------|
| Nodes can be extended | Up to 127 | Up to 16 | Up to 10 |
| Communication Distance | Longer communication distance, lower communication rate, max 30m is recommended. | | |

→ Wiring Reference

Connect 485A and 485B of RS485 to 485A and 485B of the controller correspondingly, and connect the common terminal EGND of both parties of RS485 communication together.




Connect the CANL and CANH of the standard CAN module to the CANL and CANH of the other side correspondingly. And public ends of the CAN bus communication both parties are connected together. In CAN bus left and right sides, connect a 120Ω resistor respectively (please see below graphic).



Connect 422TX and 422RX of RS422 to 422TX and 422RX of the corresponding

controller, and connect the common terminal EGND of both RS422 communication parties together.




→ **Wiring Notes:**

- As above, the daisy chain topology is used for wiring, so the star topology cannot be used. When the use environment is ideal and there are few nodes, the branch structure can also be considered.
- Please connect a 120Ω terminal resistor in parallel at the two ends of the CAN bus to match the circuit impedance and ensure communication stability.
- Please be sure to connect the common terminal of each node on the CAN bus to prevent the CAN chip from burning out.
- Please use twisted-pair shielded wires, especially in harsh environments, make sure the shielding layer is fully grounded.
- On-site wiring should also pay attention to the distance between strong current and weak current wiring, it is recommended to be more than 20cm.
- It should be noted that the equipment grounding (chassis) on the entire line must be good, and the grounding of the chassis should be connected to the standard factory ground pile.

→ **Cable Requirements:**

Twisted pair shielded wire, and shielded cable grounded.



3.2.2. Basic Usage


- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use ETHERNET, RS232 or RS485 to connect to [RTSys](#).
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configuration parameters, see ["Basic Programming Manual"](#) for details.
- (4) Please use the "CANIO_ADDRESS" command to set the master's "address" and "speed" according to the needs, and use the "CANIO_ENABLE" command to enable or disable the internal CAN master function, or through "RTSys/Controller/State the Controller/Communication Info" to view the CAN status intuitively, and refer to the "Basic Programming Manual" for details.
- (5) Correctly set the relevant parameters of the third-party equipment according to their respective instructions to match the parameters of each node.
- (6) Correctly set the "address" and "speed" of the slave expansion module according to the manual of the slave.
- (7) After all the settings are completed, restart the power supply of all stations to establish communication.

(8) Note that the "speed" settings of each node on the CAN bus must be consistent, and the "address" settings cannot cause conflicts, otherwise the "ALM" alarm light will be on, and the communication establishment will fail or the communication will be disordered.

3.3. RS232 Serial Port

RS232 is in a standard DB9 male socket and supports MODBUS_RTU protocol and custom communication.

→ **Interface Definition:**

| Terminal | PIN | Name | Type | Function |
|---|---------------|------|--------|---|
|  | 1, 4, 6, 7, 8 | NC | Spare | Reserved |
| | 2 | RXD | Input | RS232 signal receive |
| | 3 | TXD | Output | RS232 signal send |
| | 5 | EGND | Output | 5V power supply outputs negative pole and this communication public end |
| | 6 | | | |
| | 9 | E5V | Output | 5V power supply outputs positive pole, max is 300mA |


3.3.1. RS232 Communication Specification & Wiring

→ **Specification:**

| Item | RS232 |
|------------------------------|--|
| Max Communication Rate (bps) | 115200 |
| Terminal Resistor | No |
| Topology | Connect correspondingly (point to point) |
| Nodes can be extended | 1 |

| | |
|------------------------|---|
| Communication Distance | Longer communication distance, lower communication rate, max 5m is recommended. |
|------------------------|---|

→ **Wiring Reference:**




→ **Wiring Notes:**

- The wiring of RS232 is as above, the sending and receiving signals need to be cross-connected, and it is recommended to use a double-female cross line when connecting to a computer.
- Please be sure to connect the common terminal of each communication node to prevent the communication chip from burning out.
- Please use twisted-pair shielded cables, especially in harsh environments, and make sure the shielding layer is fully grounded.

→ **Cable Requirements:**

Twisted pair shielded wire, and shielded cable grounded.



3.3.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use ETHERNET, RS232 (default parameter, it can be connected directly) and RS485 (default parameter can be directly connected, one adapter is needed for hardware) to connect to [RTSys](#).
- (3) Please use the "ADDRESS" and "SETCOM" commands to set and view the protocol station number and configuration parameters, see "Basic Programming Manual" for details.
- (4) Correctly set the relevant parameters of the third-party equipment according to their respective instructions to match the parameters of each node.
- (5) When all is configured, it can start to do communicating.
- (6) Communication data of RS232 can be directly viewed through "ZDevelop / Controller / State the Controller / CommunicationInfo".

```
CAN communication settings:  
CANIO_ADDRESS = 32, CANIO_ENABLE = 1  
ZCAN Master  
CAN baud: 500Kbps  
CAN enable: ON  
  
Serial port configuration:  
Port0:(RS232) is ModbusSlave Mode.  
Address:1, variable:2 delay:400ms  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0  
Port1:(RS485) is ModbusSlave Mode.  
Address:1, variable:2 delay:400ms  
Baud:38400  
DataBits:8  
StopBits:1  
Parity:0
```

3.4. IN Digital Input & Single-Ended Encoder & High-Speed Latch

The digital input adopts 3 groups of 10Pin screw-type pluggable terminals with a pitch of 3.81mm, and digital signal inputs integrate the high-speed latch and single-

ended encoder functions.

→ Wiring Definition

| Terminal | Name | Type | Function 1 | Function 2 | Function 3 |
|--|------|----------------------------------|---------------|---------------------|------------|
| | EGND | / | IO public end | / | / |
| | EGND | / | | / | / |
| IN0 | IN1 | NPN type, high-speed input | Input 0 | High Speed Latch | EA3 |
| | | | Input 1 | | EB3 |
| IN2 | IN3 | | Input 2 | / | EZ3 |
| | | | Input 3 | / | / |
| IN4 | IN5 | | Input 4 | / | / |
| | | | Input 5 | / | / |
| IN6 | IN7 | | Input 6 | / | / |
| | | | Input 7 | / | / |
| | EGND | / | IO public end | / | / |
| | EGND | / | | / | / |
| IN8 | IN9 | | Input 8 | / | / |
| | | | Input 9 | / | / |
| IN10 | IN11 | | Input 10 | / | / |
| | | | Input 11 | / | / |
| IN12 | IN13 | | Input 12 | / | / |
| | | | Input 13 | / | / |
| IN14 | IN15 | | Input 14 | / | / |
| | | | Input 15 | / | / |
| | EGND | / | IO public end | / | / |
| | EGND | / | | / | / |
| IN16 | IN17 | | Input 16 | / | / |
| | | | Input 17 | / | / |
| IN18 | IN19 | | Input 18 | / | / |
| | | | Input 19 | / | / |
| IN20 | IN21 | | Input 20 | / | / |
| | | | Input 21 | / | / |
| IN22 | IN23 | | Input 22 | / | / |
| | | | Input 23 | / | / |
| <p>Note:</p> <ul style="list-style-type: none"> ✧ Input 0 and input 1 both have latch input A and latch input B function at the same time. ✧ Encoder 3 is reserved for 24V encoder, which supports 24V handwheel. When ATYPE = 0, it is general output. | | | | | |


3.4.1. Digital Input Specification & Wiring

→ Specification


| Item | High-Speed Input (IN0-1) | Low-Speed Input (IN2-23) |
|--|-----------------------------------|---------------------------|
| Input mode | NPN type, low level input trigger | |
| Input frequency | <100kHz | <5kHz |
| Input impedance | 3.3KΩ | 4.7KΩ |
| Input voltage level | DC24V | DC24V |
| Input ON voltage | <15V | <14.5V |
| Input OFF voltage | >15.1V | >14.7V |
| Min input current | -2.3mA | -1.8mA |
| Max input current | -7.5mA | -6mA |
| Isolation mode | Photoelectronic isolation | Photoelectronic isolation |
| Note: the above parameters are standard values when the controller power supply voltage (E+24V port) is 24V. | | |

→ Wiring Reference

--General IN Wiring--



--Single-Ended Encoder IN Wiring--



→ Wiring Note:

- The wiring principle of high-speed digital input IN (0-1) and low-speed digital input IN (2-23) is shown in the figure above. The external signal source can be an optocoupler or a key switch or sensor, etc., all can be connected as long as the output level meets the requirements.
- For the common terminal, please select the "EGND" port on the IO terminal to connect to the "COM" terminal of the external input device. If the power supply of the signal area of the external device and the power supply of the controller are in the same power supply system, this connection can also be omitted.

3.4.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.
- (3) State values of relative inputs can be read directly through "IN" command, also, it can

be read through "RTSys/Tool/In". Please refer to "Basic" for details.

(4) Latch function can be set and opened through "REGIST" instruction, in software, use REG_INPUTS to configure. Please refer to "Basic" for details.

3.5. OUT: Digital Output, PWM Terminal, Single-Ended Pulse

The digital output adopts a set of screw-type pluggable terminals with a spacing of 3.81mm, and the digital output signal is integrated with PWM and single-ended pulse function.

→ **Wiring Definition**

| Terminal | Name | Type | Function 1 | Function 2 | Function 3 | |
|---|------|-----------------------------------|-------------------------------------|--------------|------------|--|
| EGND E5V OUT0 OUT1 OUT2 OUT3 OUT4 OUT5 OUT6 OUT7 | EGND | / | E5V power ground / IO public end | / | / | |
| | E5V | / | 5V power output, max 300mA | / | / | |
| | OUT0 | NPN type, high-speed output | Output 0 | PWM Output 0 | / | |
| | OUT1 | | Output 1 | PWM Output 1 | / | |
| | OUT2 | | Output 2 | / | PUL15 | |
| | OUT3 | | Output 3 | / | DIR15 | |
| | OUT4 | NPN type, low-speed output | Output 4 | / | / | |
| | OUT5 | | Output 5 | / | / | |
| | OUT6 | | Output 6 | / | / | |
| | OUT7 | | Output 7 | / | / | |
| Note: | | | | | | |
| <ul style="list-style-type: none"> ✧ The E5V power output port is used for PWM or single-ended axis common anode wiring. It is not recommended for other purposes due to lower power. ✧ OUT0-1 have the PWM function, when PWM is off, it is general output. ✧ In ZMC316BE, OUT2/3 have the function of axis 15. When ATYPE = 0, it is general output. | | | | | | |


3.5.1. Digital Output Specification & Wiring

→ Specification


| Item | High Speed (OUT0-3) | Low Speed (OUT4-7) |
|---|------------------------------------|--------------------|
| Output mode | NPN type, 0V when outputs | |
| Output frequency | <400kHz | <8kHz |
| Output voltage level | DC24V | DC24V |
| Max output current | +300mA | +300mA |
| Max leakage current when OFF | 25µA | 25µA |
| Conduction respond time | 1µs (resistive load typical value) | 12µs |
| Respond time when OFF | 3µs | 80µs |
| Overcurrent protection | Support | Support |
| Isolation method | Optical isolation | Optical isolation |
| Note: <ul style="list-style-type: none"> ✧ The times in the table are typical based on the resistive load, and may change when the load circuit changes. ✧ Due to the leak-type output, the shutdown of the output will be more obviously affected by the external load circuit, and the output frequency should not be set too high in the application. | | |

→ Wiring Reference

--General OUT Wiring--



--Pulse Axis Wiring--



Note [1]: for 5V pulse directional interface, please connect PUL+ and DIR+ to E5V.

→ Wiring Note:

- The wiring principle of high-speed digital output OUT (0-3) and low-speed digital output OUT (4-7) is shown in the figure above. The external signal receiving end can be an optocoupler or a relay or solenoid valve, all can be connected as long as the input current does not exceed 300mA.
- For the connection of the common terminal, please select the "EGND" port on the power terminal to connect to the negative pole of the DC power supply of the external

input device. If the DC power supply of the external device and the controller power supply are in the same power supply system, this connection can also be omitted.

- The E5V port is a 5V power output port, which can be used when some loads need to provide an external 5V power input, the maximum current is 300mA.


3.5.2. Basic Usage

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.
- (3) Terminal can be operated to ON or OFF directly through "OP" command, also, it can be opened or closed through "RTSys/Tool/Op". Please refer to "Basic" for details.
- (4) PWM function can be used to set frequency and duty cycle through "PWM_FREQ" and "PWM_DUTY". Please refer to Basic for details.

3.6. AD/DA Analog Input & Output

The analog port adopts a set of 6Pin screw-type pluggable terminals with a pitch of 3.81mm.

→ Wiring Definition


| Terminal | Name | Type | Function |
|---|------|------------|--------------------------------|
|  | DA0 | Output | Analog output terminal AOUT(0) |
| | DA1 | Output | Analog output terminal AOUT(1) |
| | AGND | Public End | Analog public end |
| | AD0 | Input | Analog input terminal AIN(0) |
| | AD1 | Input | Analog input terminal AIN(1) |
| | AGND | Public End | Analog public end |

3.6.1. Analog Input / Output Specification & Wiring

→ Specification

| Item | AD (0-1) | DA (0-1) |
|---------------------------------------|--------------------------------|-----------------------------|
| Resolution | 12-bit | 12-bit |
| Data range | 0-4095 | 0-4095 |
| Signal range | 0-10V input | 0-10V output |
| Data refresh ratio | 1KHz | 1KHz |
| Voltage input impedance / output load | 44KΩ (voltage input impedance) | >10KΩ (voltage output load) |

→ Wiring Reference




→ Wiring Note:

- The analog input/output wiring method is as shown in the figure above, and the external load signal range must match it.
- Please use twisted-pair shielded cables, especially in harsh environments, and make sure the shielding layer is fully grounded.


→ Cable Requirements:

Twisted pair shielded wire, and shielded cable grounded.




3.6.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 and RS485 to connect to RTSys.
- (3) Analog input voltage can be read through "AIN" command and corresponding analog voltage can be output through "AOUT" command, also, data of each channel can be checked through "RTSys/Tool/AD/DA". Please refer to "Basic" for details.



3.7. U Disk

The ZMC316BE motion controller provides a USB communication interface to insert a U disk device, which is used for ZAR program upgrade, controller data import and export, and 3 file executions. Its schematic diagram is shown in the figure below:




→ Specification


| Item | USB2.0 |
|--------------------------|--------|
| Max Communication Ratio | 12Mbps |
| Max Output Current of 5V | 500mA |
| Whether Isolates | No |

3.8. ETHERNET


ZMC316BE motion controller has a 100M Ethernet port, supports MODBUS_TCP protocol and custom communication, and the default IP address is 192.168.0.11. The pin definition diagram is as follows:



The Ethernet port of the controller can be connected point-to-point with a computer, HMI, etc. through an Ethernet cable. The schematic diagram is as follows:



The controller can also be connected to the interchanger through an Ethernet cable, and connected to other devices through the interchanger to realize multi-point connection. The schematic diagram is as follows:



3.9. EtherCAT Bus Interface

ZMC316BE motion controller has a 100M EtherCAT communication interface, supports EtherCAT protocol, and connects to EtherCAT driver or EtherCAT expansion module. The pin definition diagram is as follows:

The diagram shows a 9-pin connector with pins numbered 1 through 9. Pins 1 through 8 are labeled with their respective signals and descriptions. Pin 9 is labeled 'GND'. The signals are: TX+ (Send signal +), TX- (Send signal -), RX+ (Receive signal +), NC (Reserved), NC (Reserved), RX- (Receive signal -), NC (Reserved), and NC (Reserved).

| PIN | Signal | Description |
|-----|--------|--------------------|
| 1 | TX+ | Send signal (+) |
| 2 | TX- | Send signal (-) |
| 3 | RX+ | Receive signal (+) |
| 4 | NC | Reserved |
| 5 | NC | Reserved |
| 6 | RX- | Receive signal (-) |
| 7 | NC | Reserved |
| 8 | NC | Reserved |
| 9 | GND | |


→ Specification

| Item | Specification |
|---|---|
| Communication protocol | EtherCAT protocol |
| Communication period | Recommend 2ms, 4ms |
| Valid service | CoE (PDO, SDO), FoE |
| Synchronization method | IO adopts input and output synchronization / DC-distributed clock |
| Physical level | 100BASE-TX |
| Duplex mode | full duplex |
| Topology | linear topology |
| Transfer media | Cable |
| Transfer distance | It is less than 100M between 2 nodes |
| Process data | Max 1486 bytes of single frame |
| Synchronization shaking of two slave stations | <1us |
| Refresh | 1000 digital input and output about 30us |

→ Communication Cable Requirements

Both ETHERNET communication interface and EtherCAT communication interface adopt standard Ethernet RJ45 interface.

The network cable adopts Category 5e shielded twisted pair, and the crystal head has a metal shell to reduce interference and prevent information from being eavesdropped. As shown below:



| Item | Specification |
|------------|----------------------------------|
| Cable type | Flexible crossover cable, Cat 5e |

| | |
|----------------|------------------------------|
| Cable type | twisted pair |
| Cable pair | 4 |
| Isolation | cross skeleton |
| Connector | Crystal head with iron shell |
| Cable material | PVC |
| Cable length | Less than 100m |

Use RJ45 network cable connection method:


- When installing, hold the crystal head with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.
- When disassembling, press the tail mechanism of the crystal head and pull out the connector and the module in a horizontal direction.

Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.

3.10. ENCODER Interface

ZMC316BE provides 3 encoder interfaces, each interface is standard DB9 male socket.

→ Interface Definition

| Interface | Pin | Signal | Description |
|---|-----|----------|--------------------------------------|
|  | 1 | EA+ | Encoder differential input signal A+ |
| | 2 | EA- | Encoder differential input signal A- |
| | 3 | EB+ | Encoder differential input signal B+ |
| | 4 | EB- | Encoder differential input signal B- |
| | 5 | GND | Encoder signal 5V - |
| | 6 | EZ+ | Encoder differential input signal Z+ |
| | 7 | EZ- | Encoder differential input signal Z- |
| | 8 | +5V | Encoder signal 5V + |
| | 9 | Reserved | Reserved |

Note: encoder can be accessed through axis 16-18.


3.10.1. ENCODER Interface Specification & Wiring

→ Interface Definition


| Interface | Item | Description |
|-----------|-----------------------------|---------------------------|
| EA/EB/EZ | Signal type | Differential input signal |
| | Signal voltage range | 0-5V |
| | Signal max frequency | 5MHz |
| +5V, GND | 5V power max output current | 50mA |

→ Wiring Reference:

-- Reference example of wiring with Panasonic A5/A6 servo driver --




-- Single-Ended Encoder Axis Wiring --



3.11. AXIS Differential Pulse Axis Interface

This product provides 15 local differential pulse axis interfaces, each interface is a standard DB9 female socket.

→ Interface Definition

| Interface | Pin | Signal | Description |
|---|-----|-----------------|--|
|  | 1 | PUL+ | Servo/step pulse output differential signal + |
| | 2 | PUL- | Servo/step pulse output differential signal - |
| | 3 | DIR+ | Servo/step directional output differential signal + |
| | 4 | DIR- | Servo/step directional output differential signal - |
| | 5 | GND | Pulse signal 5V - |
| | 6 | IN24- 28/ALM | Digital input, it is recommended to do drive alarm |
| | 7 | OUT8- 22/ENA | Digital output, it is recommended to do drive enable |
| | 8 | +5V | Pulse signal 5V + |
| | 9 | EGND | Digital IO power 24V negative pole |
| Note: <ul style="list-style-type: none"> ALM and ENA are recommended to be used as axis IO due to their small drive capacity. +5V is only used for communication between the controller and the servo driver, please do not use it as power supply for other places. | | | |

| Pulse Axis No. | Corresponding IN (PIN 6) | Corresponding OUT (PIN 7) |
|----------------|--------------------------|---------------------------|
| AXIS0 | IN24 | OUT8 |
| AXIS1 | IN25 | OUT9 |
| AXIS2 | IN26 | OUT10 |
| AXIS3 | IN27 | OUT11 |
| AXIS4 | IN28 | OUT12 |
| AXIS5 | IN29 | OUT13 |
| AXIS6 | IN30 | OUT14 |

| | | |
|--------|------|-------|
| AXIS7 | IN31 | OUT15 |
| AXIS8 | IN32 | OUT16 |
| AXIS9 | IN33 | OUT17 |
| AXIS10 | IN34 | OUT18 |
| AXIS11 | IN35 | OUT19 |
| AXIS12 | IN36 | OUT20 |
| AXIS13 | IN37 | OUT21 |
| AXIS14 | IN37 | OUT22 |

3.11.1. AXIS Interface Signal Specification & Wiring


→ Specification:

| Signal | Item | Description |
|----------|-----------------------------|--|
| PUL/DIR | Signal type | Differential output signal |
| | Signal voltage range | 0-5V |
| | Signal max frequency | 10MHz |
| IN24-38 | Input method | NPN type, low electric level input trigger |
| | Input frequency | <5kHz |
| | Input impedance | 6.8KΩ |
| | Input voltage level | DC24V |
| | Input opening voltage | <10.5V |
| | Input closing voltage | >10.7V |
| | Min input current | -1.8mA |
| | Max input current | -4mA |
| | Isolation | Optical isolation |
| OUT8-22 | Output method | NPN type, 0V when outputs |
| | Output frequency | <8kHz |
| | Output voltage level | DC24V |
| | Max output current | +50mA |
| | Overcurrent protection | No |
| | Isolation | Optical isolation |
| +5V, GND | 5V power max output current | 50mA |


| | | |
|------|------------------------------|------|
| EGND | 24V power max output current | 50mA |
|------|------------------------------|------|

→ Wiring Reference:

-- Reference example of wiring with Panasonic A5/A6 servo driver --



-- Single-Ended Pulse Axis Wiring --



→ **Wiring Note:**


- ✧ The wiring principle of the differential pulse axis interface is shown in the figure above, and the wiring methods of different types of drivers are different, please connect carefully.
- ✧ Please use twisted-pair shielded cables, especially in harsh environments, and make sure the shielding layer is fully grounded.

3.11.2. Basic Usage Method

- (1) Please follow the above wiring instructions for correct wiring.
- (2) After power on, please use any of the three interfaces ETHERNET, RS232 (default parameter, it can be connected directly) and RS485 (default parameter can be connected directly, one adapter is needed for hardware) to connect to [RTSys](#).
- (3) Set axis parameters, such as, ATYPE, UNITS, SPEED, ACCEL, FWD_IN, REV_IN, etc.
- (4) There are many parameters related to pulse axis, they can be set and checked through relative instructions, please see "axis parameter and axis status" of "[Basic](#)", or see "RTSys/Tool/Axis parameter".

| COMMENT | Axis0 | Axis1 | Axis2 | Axis3 |
|----------|------------|------------|------------|------------|
| | ATYPE | 0 | 0 | 0 |
| UNITS | 1 | 1 | 1 | 1 |
| ACCEL | 10000 | 10000 | 10000 | 10000 |
| DECCEL | 0 | 0 | 0 | 0 |
| SPEED | 1000 | 1000 | 1000 | 1000 |
| CREEP | 100 | 100 | 100 | 100 |
| LSPEED | 0 | 0 | 0 | 0 |
| MERGE | 0 | 0 | 0 | 0 |
| SRAMP | 0 | 0 | 0 | 0 |
| DPOS | 0 | 0 | 0 | 0 |
| MPOS | 0 | 0 | 0 | 0 |
| ENDMOVE | 0 | 0 | 0 | 0 |
| FS_LIMIT | 200000000 | 200000000 | 200000000 | 200000000 |
| RS_LIMIT | -200000000 | -200000000 | -200000000 | -200000000 |
| DATUM_IN | -1 | -1 | -1 | -1 |
| FWD_IN | -1 | -1 | -1 | -1 |

(5) Control corresponding motion through “Tool – Manual”.



Refer to BASIC Routine:

| | |
|-------------------|---|
| BASE(0,1) | 'select axis 0 and axis 1 |
| ATYPE = 1,1 | 'set axis 0 and axis as pulse axes |
| UNITS = 1000,1000 | 'set pulse amount as 1000 pulses |
| SPEED = 10,10 | 'set axis speed as 10*1000 pulse/s |
| ACCEL = 1000,1000 | 'set axis acceleration as 1000*1000 pulse/s/s |
| FWD_IN = -1,-1 | 'prohibit using axis positive hardware position limit |
| REV_IN = -1,-1 | 'prohibit using axis negative hardware position limit |
| MOVE(10) AXIS(0) | 'axis 0 moves distance of 10*1000 pulses in positive |
| MOVE(-20) AXIS(0) | 'axis 0 moves distance of 20*1000 pulses in negative |

Chapter IV Expansion Module

The controller can expand digital IO, analog IO, pulse axis and other resources through CAN bus or EtherCAT bus. That is, it can use together with ZIO series CAN expansion modules, EIO series EtherCAT expansion modules, or ZMIO310 series vertical expansion modules. For details, please refer to corresponding user manual.

4.1. CAN Bus Expansion

[ZIO series expansion modules](#) or [ZMIO310-CAN coupler with sub modules](#) can be used.

Connect control card to CAN bus expansion modules, when the eighth bit of the DIP switch of the expansion module is turned to ON, which indicates that a 120-ohm resistor has been connected, but needs to connect one 120-ohm resistor externally. When connecting multiple CAN expansion modules, you only need to dial ON for the eighth digit of the last expansion module, which means please do not dial bit-8 of other modules.


4.1.1. CAN Bus Expansion Wiring

The ZIO expansion module is powered by the dual power supply. Except the main power supply, an additional IO power supply is required to supply independent power for IO. Both the main power supply and the IO power supply use 24V DC power supply. For ZAIO, it only needs to connect to the main power supply.

To prevent interference, separate the IO power supply from the main power supply.

Please select the expansion module according to the requirements, and select IO mapping or axis mapping according to the resources of the expansion module.


Wiring reference of connection between ZIO expansion module and control card and standard wiring of CAN bus are shown as below:



→ Wiring Note:

- ❖ ZMC316BE controller uses the single power, and ZIO expansion module uses dual-power. When using, main power supply of expansion module and main power supply of controller can share one power. When they use different power supplies, controller power EGND needs to connect to expansion module power GND, otherwise CAN may be burnt out.
- ❖ When connecting multiple ZIO expansion modules on the CAN bus, a 120-ohm resistor needs to be connected in parallel between the CANL and CANH terminals, for the ZIO expansion module that is with 8-digit dialing codes, the terminal resistor can be realized by dialing the code (DIP).

4.1.2. CAN Bus Expansion Resource Mapping



The ZCAN expansion module generally has an 8-bit DIP switch, dial ON to take effect, and the meaning of the DIP is as follows:

1-4: they are used for ZCAN expansion module IO address mapping, the corresponding value is 0-15.

5-6: CAN communication speed, corresponding value is 0-3, four different speeds are optional.

7: reserved.

8: 120-ohm resistor, dial ON means a 120-ohm resistor is connected between CANL and CANH.

The IO numbers of the entire control system cannot be repeated, and existed numbers must be avoided when mapping resources. And the DIP switch must be dialed before power-on, if re-dial after power-on, it is invalid. It needs to be powered on again to take effect.

Dial 1-4 to select the CAN address, and the controller sets the IO number range of the corresponding expansion module according to the CAN DIP address. When each is dialed as OFF, the corresponding value is 0, when it is ON, it corresponds to a value of 1, and the address combination value = dial 4 × 8 + dial code 3 × 4 + dial code 2 × 2 + dial code 1.

Dial code 5-6 to select CAN bus communication speed, speed combination value=dial code 6 × 2 + dial code 5×1, the combined value range is 0-3.

The corresponding speeds are as follows:

| DIP 5-6 combination value | CANIO_ADDRESS high 8-bit value | CAN communication speed |
|---------------------------|--------------------------------|-------------------------|
| 0 | 0 (corresponds to decimal 128) | 500KBPS (default value) |
| 1 | 1 (corresponds to decimal 256) | 250KBPS |

| | | |
|---|----------------------------------|---------|
| 2 | 2 (corresponding to decimal 512) | 125KBPS |
| 3 | 3 (corresponding to decimal 768) | 1MBPS |

The controller side sets the CAN communication speed through the CANIO_ADDRESS command. There are also four speed parameters that can be selected. The communication speed must be consistent with the communication speed of the expansion module that corresponds to the combination value, then they can communicate with each other.

The factory default communication speed is 500 KBPS on both sides, there is no need to set this, unless you need to change the speed.

The CANIO_ADDRESS command is a system parameter, and it can set the master-slave end of CAN communication. The default value of the controller is 32, that is, CANIO_ADDRESS=32 is the master end, and the slave end is set between 0-31.

The CAN communication configuration can be viewed in the "State the Controller" window.

→ **IO Mapping:**

the CAN expansion module uses bit1-4 of the DIP switch. According to the number of currently included IO points (the largest number in IN and OP must include IO point in the axis interface), use the bit 1-4 to set the ID, so as to determine the number range of IO to be expanded.

If the controller itself contains 28 INs and 16 OPs, then the starting address set by the first extended board should exceed the maximum value of 28. According to below rule, the dial code should be set to the combination value 1 (binary combination value 0001, from right to left, dial code 1-4, at this time dial 1 is set to ON, and the others are set to OFF), the IO number on the expansion board = the expansion board number value + the initial IO number value, among them, the IOs that are vacant from 29-31 Numbers are not used. Subsequent extended boards continue to confirm the dial settings according to the IO points in turn.

The initial digital IO mapping number starts from 16 and increases in multiples of 16. The distribution of digital IO numbers corresponding to different dial IDs is as follows (for ZMC316BE motion controller, its expansion module's DIP ID start from 2 at least, therefore, IO No. starts from 48 at least):

| DIP 1-4 combination value | Starting IO number | Ending IO number |
|---------------------------|--------------------|------------------|
| 0 | 16 | 31 |
| 1 | 32 | 47 |
| 2 | 48 | 63 |
| 3 | 64 | 79 |
| 4 | 80 | 95 |
| 5 | 96 | 111 |
| 6 | 112 | 127 |
| 7 | 128 | 143 |
| 8 | 144 | 159 |
| 9 | 160 | 175 |
| 10 | 176 | 191 |
| 11 | 192 | 207 |
| 12 | 208 | 223 |
| 13 | 224 | 239 |
| 14 | 240 | 255 |
| 15 | 256 | 271 |

The initial IO mapping number of the analog AD starts from 8 and increases in multiples of 8. The initial IO mapping number of the analog DA starts from 4 and increases in multiples of 4. The allocation of digital IO numbers corresponding to different dial code IDs is as follows:

| DIP 1-4 combination value | Starting AD No. | End AD No. | Starting DA No. | End DA No. |
|---------------------------|-----------------|------------|-----------------|------------|
| 0 | 8 | 15 | 4 | 7 |
| 1 | 16 | 23 | 8 | 11 |
| 2 | 24 | 31 | 12 | 15 |
| 3 | 32 | 39 | 16 | 19 |
| 4 | 40 | 47 | 20 | 23 |
| 5 | 48 | 55 | 24 | 27 |
| 6 | 56 | 63 | 28 | 31 |
| 7 | 64 | 71 | 32 | 35 |
| 8 | 72 | 79 | 36 | 39 |
| 9 | 80 | 87 | 40 | 43 |
| 10 | 88 | 95 | 44 | 47 |

| | | | | |
|----|-----|-----|----|----|
| 11 | 96 | 103 | 48 | 51 |
| 12 | 104 | 111 | 52 | 55 |
| 13 | 112 | 119 | 56 | 59 |
| 14 | 120 | 127 | 60 | 63 |
| 15 | 128 | 135 | 64 | 67 |

→ Axis Mapping:

When the CAN bus expansion mode is used to expand the pulse axis, ZIO16082M can be selected to expand two pulse axes. These two pulse axes need to be mapped and bound with the axis No., then access.

Extended axes need to perform axis mapping operations, using the AXIS_ADDRESS command to map, and the mapping rules are as follows:

AXIS_ADDRESS(axis No.)=(32*0)+ID

'the local axis interface of the expansion module AXIS 0

AXIS_ADDRESS(axis No.)=(32*1)+ID

'the local axis interface of the expansion module AXIS 1

The ID is the combined value of the DIP bit1-4 of the expansion module. After the mapping is completed and the axis parameters such as ATYPE are set, the expansion axis can be used.

Example:

ATYPE(6)=0 'set as virtual axis

AXIS_ADDRESS(6)=1+(32*0)

'ZCAN expansion module ID 1 axis 0 is mapped to axis 6

ATYPE(6)=8 'ZCAN extended axis type, pulse direction stepping or servo

UNITS(6)=100 0 'pulse equivalent 1000

SPEED(6)=100 'speed 100units/s

ACCEL(6)=1000 'acceleration 1000units/s^2

MOVE(100) AXIS(6) 'extended axis movement 100units

Extended resource viewing:

According to the CAN connection, after the power is turned on, and the wiring

resistance dial code is set correctly, the power indication led (POWER) and the running indication led (RUN), the IO power indication led (IO POWER) are on, and the alarm indication led (ALM) is off. At the same time, the "Controller" - "State the controller" - "ZCanNodes" in the RTSys software displays the expansion module information and the extended IO number range.

The dial ID and the corresponding resource number when connecting multiple expansion modules are as follows:

| | | | | | | |
|-------|---------------|----|-----------|-----------|----------|----------|
| Local | 432-0(ZMC432) | 32 | 30(0-29) | 18(0-17) | 0 | 2(0-1) |
| 1 | 48(ZIO1632) | 0 | 16(32-47) | 32(32-63) | 0 | 0 |
| 3 | 26(ZIO16082) | 2 | 16(64-79) | 8(64-71) | 0 | 0 |
| 4 | 10(ZAIO0802) | 0 | 0 | 0 | 8(40-47) | 2(20-21) |

ALM indicator light is on, please check whether the wiring, resistor and dial setting are correct, and whether the CANIO_ADDRESS command of the controller is set as the master end (32), and whether the CAN communication speed is consistent.

4.2. EtherCAT Bus Expansion

[The EIO expansion modules](#) and [ZMIO310-ECAT are expansion modules](#) used by the EtherCAT bus controller. For example, EIO series can expand the resources of digital IO and pulse axis. When the resources of the controller are insufficient, the EtherCAT bus controller can be connected to multiple EIO expansion modules for expansion, you can view the maximum number of IO expansion points and the maximum number of expansion axes of the controller, and in this way, it supports IO remote expansion.

4.2.1. EtherCAT Bus Expansion Wiring


After the expansion wiring is completed, each EIO expansion module does not need to develop again. It only needs to manually configure the unique IO address and axis address in the EtherCAT master controller, and it can be accessed after the configuration is completed.

The IO address number is set through the bus command NODE_IO, and the program on the controller can access the resources on the expansion module only through the IO

number. The configuration of the axis address uses the AXIS_ADDRESS command to map axis number, and when the binding is completed, specify the axis number through the BASE or AXIS command.

When wiring, pay attention that EtherCAT IN is connected to the upper-level module, and EtherCAT OUT is connected to the lower-level module. The IN and OUT ports cannot be mixed.

EIO expansion module wiring reference example:



Involved number concepts in above figure are as follows: the bus-related command parameters will use the following numbers:

Slot No. (slot):

The slot number refers to the number of the bus interface on the controller, and the slot number of the EtherCAT bus is 0.

Device No. (node):

The device number refers to the number of all devices connected to a slot. It starts from 0 and is automatically numbered according to the connection sequence of the devices on the bus. You can view the total number of devices connected to the bus through the NODE_COUNT(slot) command.

Drive No.:

The controller will automatically identify the drive on the slot, and the number starts

from 0, and the number is automatically numbered according to the connection sequence of the drive on the bus.

The drive number is different from the device number. Only the drive device number on the slot is assigned, and other devices are ignored. The drive number will be used when mapping the axis number.

4.2.2. EtherCAT Bus Expansion Resource Mapping

→ IO Mapping:

The program on the controller can access the resources on the expansion module only through the IO number. The IO number of the EtherCAT bus expansion module is set through the bus command NODE_IO, and the input and output are configured at the same time.

When IO mapping, first check the maximum IO number of the controller itself (including the external IO interface and the interface in the pulse axis), and then use the command to set.

If the extended IO coincides with the IO number of the controller itself, the two will work at the same time, so the mapped number of the IO mapping must not be repeated in the entire control system.

IO mapping syntax:

NODE_IO(slot, node) = iobase

slot: slot number, 0-default

node: device number, starting from 0

iobase : mapping the IO start number, the setting result will only be a multiple of 8

Example:

NODE_IO(0,0)=32 'set the IO start number of slot 0 interface device 0 to 32

If device 0 is EIO16084, after configuration according to the above syntax, the IO numbers corresponding to input IN0-15 are 32-47 in turn, the general input port numbers in the axis interface are 48-55, and the drive alarm inputs of axes AXIS 0-3 are 48-51 respectively. The IO numbers corresponding to the output OUT0-7 are 32-39 in sequence,

the general output port numbers in the axis interface are 40-47, and the drive enable outputs of the axes AXIS 0-3 are 40-43 respectively.

| | | | | | | | |
|---|------|-------|---|---|-----------|-----------|---|
| 0 | 41bh | 1918h | 0 | 4 | 24(32-55) | 16(32-47) | 0 |
|---|------|-------|---|---|-----------|-----------|---|

→ **AXIS Mapping:**

Before using the axis of the expansion module, you need to use the AXIS_ADDRESS command to map the axis number, and the axis mapping also needs to pay attention to the axis number of the entire system cannot be repeated. The mapping syntax of the EIO series extended axis is the same as that of the bus driver.

Axis mapping syntax:

AXIS_ADDRESS(axis number)=(slot number<<16)+driver number+1

Example:

AXIS_ADDRESS(0)=(0<<16)+0+1

'the first drive on the EtherCAT bus, drive number 0, bound as axis 0

AXIS_ADDRESS(1)=(0<<16)+1+1

'the second drive on the EtherCAT bus, drive number 1, bound as axis 1

If the first node is EIO16084, and EIO16084 is connected to drive, then driver 0 here is the first pulse driver connected to EIO16084, otherwise it is the EtherCAT driver.

Chapter V Programming

5.1. Program in RTSys Software


RTSys is a PC-side program development, debugging and diagnostic software for the Zmotion motion controllers. Through it, users can easily edit and configure the controller program, quickly develop applications, diagnose system operating parameters in real time, and debug the running program in real time. What's more, it supports Chinese and English bilingual environments.




In RTSys, there are 4 programming languages for motion control development, Basic, PLC, HMI and C language, they can run multi-tasks among them, especially for Basic, multi-task running can be achieved separately, hybrid programming is also OK with PLC, HMI and C language.



RTSys Downloading Address: https://www.zmotionglobal.com/pro_info_282.html




And related manuals can be found in “Download”:







| Features | Parameters | System Architecture | Download | |
|---|--------------|---------------------|----------|--------------------------|
| Name | Version No | Format | Size | Download |
| RTSys Development Software | V1.2.02 | RAR | 148MB | Download |
| RTSys User Manual V1.2.0 | V1.2.0 | PDF | 5.33MB | Download |
| RTBasic Programming Manual | V1.1.0 | PDF | 18.3MB | Download |
| RTHMI Programming Manual | V1.2.0 | PDF | 7.23MB | Download |
| Quick Start | VQuick Start | ZIP | 16.1MB | Download |
| ZVision Basic Programming Manual V1.3.0 | V1.3.0 | PDF | 10.6MB | Download |
| ZPLC | V1.0 | PDF | 1.7M | Download |

| Step | Operations | Display Interface |
|------|---|--|
| 1 | Switch the Language: “Language” – “English”, then there will pop |  |

| | | |
|---|---|---|
| | up one window, click OK, and restart it. | <p>Language Switch Video Showing:</p> <p>E. How to Switch the Language</p> <p>Find "视图" (the fourth one in the above menu), then find the "语言", choose English, restart RTSys. English RTSys will take effect when opened again.</p>  |
| 2 | <p>New Project:</p> <p>"File" – "New Project", Save as window will pop up, then enter file name, save the project file with suffix ".zpj".</p> |   |

| | | |
|---|---|---|
| 3 | <p>New File: "File"</p> <ul style="list-style-type: none"> – "New File", select file type to build, here select Basic, click "OK". |  |
| 4 | <p>Set Auto Run</p> <p>No.: right click the file, open task number setting window, enter task No., which can be any + value, no priority, but not the same.</p> |  |

| | | |
|---|--|--|
| 5 | <p>Save File: edit the program in program editing window, click "save", new built file will be saved under "zpj." project automatically.</p> <p>"Save all" means all files under this project will be saved.</p> |  |
| 6 | <p>Connection: Click "controller - connect", if no controller, select connect to simulator.</p> |  |
| 6 | <p>Then, "connect to controller" window will pop up, you can select serial port or net port to connect, select matched serial port parameters or net port IP address, then click "connect".</p> |  |
| 7 | <p>Download Program into</p> | <ul style="list-style-type: none"> ● RAM: it will not save when power off. ● ROM: it will save data when power off, and when the program |

| | | |
|---|--|--|
| | <p>Controller: "Ram/Rom" – "download RAM / download ROM", if it is successful, there is print indication, at the same time, program is downloaded into controller and runs automatically.</p> | is connected to controller again, running according to task No. |
| | |    |
| 8 | <p>Debug: "Debug" – "Start/Stop Debug" to call "Task" and "Watch" window, because it was downloaded before, here select "Attach the current".</p> |   |
| 9 | <p>Scope function: Click "View" – "Scope" to open oscilloscope. It can capture needed data, for debugging.</p> |  |

Notes:

- When opening an project, choose to open the zpj file of the project. **If only the Bas file is opened, the program cannot be downloaded to the controller.**
- When the project is not created, only the Bas file **cannot be** downloaded to the controller.
- The number 0 in automatic operation represents the task number, and the program runs with task 0, and the task number has no priority.
- If no task number is set for the files in the entire project, when downloading to the controller, the system prompts the following message **WARN: no program set autorun**

5.2. Upgrade Controller Firmware

Firmware upgrade can be achieved by downloading zfm firmware package in RTSys. zfm file is the firmware upgrade package of controller, please select corresponding firmware because different models are with different packages, please contact manufacturer).

How to update:

- a. Open [ZDevelop](#) / [RTSys](#) software, then click "controller – connect", find PCI/LOCAL method, click "connect". If connected, there will be "Connected to Controller: PCIE464 Version: 4.93 – 20231220." In "output" window.
- b. Click "controller – state the controller", find basic info, then current software version can be checked.
- c. Click "controller – update firmware", current controller model and software version can be viewed.
- d. Click "browse", and select saved firmware file, click "update", then one window will pop up, please click "ok".
- e. After that, "connect to controller" window appears again, and please select "PCI/Local" again, and click "connect".
- f. When connection is successful, "firmware update" interface is shown. Now

system enters ZBIOS state, please click "update" again.

- g. When it is loaded, "firmware update" window disappears, now in output window, it shows "Update firmware to Controller Success".
- h. Do step a and step b again, check whether the firmware is updated or not.

5.3. Program in Host-Computer by PC Languages

The controller supports development under various operating systems such as windows, linux, Mac, Android, and wince, and provides dll libraries in various environments such as vc, c#, vb.net, and labview, as shown in the figure below. PC software programming refers to ["Zmotion PC Function Library Programming Manual"](#).








The program developed using the PC software cannot be downloaded to the controller, and it is connected to the controller through the dll dynamic library. The dll library needs to be added to the header file and declared during development.

- Get PC library file, example: https://www.zmotionglobal.com/download_list_17.html

A screenshot of a website page for downloading software development examples. The page has a navigation bar with links: Hardware Manuals, Software Manuals (highlighted with a red arrow), Tool Software, Products Catalogs, Development Examples (highlighted with a red box), PC Library Files, and Product 3D Model. Below the navigation bar is a list of development examples with download buttons. The examples listed are: Quick Start, Bus INIT BASIC, C Sharp, C PLUS PLUS, LABVIEW, Python, and Linux C Sharp 64 Bit. Each example has a 'Download' button to its right.

The c++ project development process in VS is as follows:

| Step | Operations | Display Interface |
|------|--|--|
| 1 | Open VS, click "File" – "New" – "Project". |  |
| 2 | Select development language as "Visual C++" and the select program type as "MFC application type". |  |
| 3 | Select "Based on basic box", click "next" or "finish" |  |
| 4 | Find C++ function library provided by manufacturer. Routine is below (64-bit library) |  |
| 5 | Copy all DLL related library files under the above path to the newly created project. | |

| | | | |
|---|--|--|---|
| 6 | <p>Add a static library and related header files to the project. Static library: zauxdll.lib, zmotion.lib</p> <p>Related header files: zauxdll2.h, zmotion.h</p> | <p>1) Right-click the header file first, and then select: "Add" → "Existing Item".</p> |   |
| 7 | <p>Declare the relevant header files and define the controller connection handle, so far the project is newly created.</p> | |  |

Chapter VI Operation and Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce the probability of equipment failure.

6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

| Check item | Check content | Inspection standards |
|--------------|--|------------------------|
| power supply | Check whether the voltage is rated | DC 24V (-5%~5%) |
| surroundings | Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature) | -10°C - 55°C |
| | Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity) | 10%-95% non-condensing |
| | Is there direct sunlight | No |
| | With or without droplets of water, oil, chemicals, etc. | No |
| | Whether there is dust, salt, iron filings, dirt | No |
| | Whether there is corrosive gas | No |
| | Whether there are flammable and | No |

| | | |
|--------------------------------|---|--|
| | explosive gases or articles | |
| | Whether the device is subjected to vibration or shock | Should be within the range of vibration resistance and impact resistance |
| | Is the heat dissipation good | Keep good ventilation and heat dissipation |
| Installation and Wiring Status | Whether the basic unit and the expansion unit are installed firmly | The mounting screws should be tightened without loosening |
| | Whether the connecting cables of the basic unit and the expansion unit are fully inserted | The connection cable cannot be loosened |
| | Are the screws of the external wiring loose | Screws should be tightened without loosening |
| | Whether the cable is damaged, aged, cracked | The cable must not have any abnormal appearance |

6.2. Common Problems & Solutions

| Problems | Suggestions |
|------------------------|--|
| Motor does not rotate. | <ol style="list-style-type: none"> 1. Check whether the ATYPE of the controller is correct. 2. Check whether hardware position limit, software position limit, alarm signal work, and whether axis states are normal. 3. Check whether motor is enabled successfully. 4. Confirm whether pulse amount UNITS and speed values are suitable. If there is the encoder feedback, check whether MPOS changes. 5. Check whether pulse mode and pulse mode of drive are matched. 6. Check whether alarm is produced on motion controller station or drive station. 7. Check whether the wiring is correct. 8. Confirm whether controller sends pulses normally. |

| | |
|---|---|
| The position limit signal is invalid. | <ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller. |
| No signal comes to the input. | <ol style="list-style-type: none"> 1. Check whether the limit sensor is working normally, and whether the "input" view can watch the signal change of the limit sensor. 2. Check whether the mapping of the limit switch is correct. 3. Check whether the limit sensor is connected to the common terminal of the controller. |
| The output does not work. | <ol style="list-style-type: none"> 1. Check whether IO power is needed. 2. Check whether the output number matches the ID of the IO board. |
| POWER led is ON, RUN led is OFF. | <ol style="list-style-type: none"> 1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the controller alone, and restart the controller after adjustment. 2. Check whether the ALM light flickers regularly (hardware problem). |
| RUN led is ON, ALM led is ON. | <ol style="list-style-type: none"> 1. Program running error, please check RTSys error code, and check application program. |
| Fail to connect controller to PC through serial port. | <ol style="list-style-type: none"> 1. Check whether the serial port parameters are modified by the running program, you can check all the current serial port configurations through ?*SETCOM. 2. Check whether the serial port parameters of the PC match the controller. 3. Open the device manager and check whether the serial driver of the PC is normal. |
| CAN expansion module cannot be connected. | <ol style="list-style-type: none"> 1. Check the CAN wiring and power supply circuit, whether the 120 ohm resistor is installed at both |

| | |
|--|--|
| | <p>ends.</p> <ol style="list-style-type: none"> 2. Check the master-slave configuration, communication speed configuration, etc. 3. Check the DIP switch to see if there are multiple expansion modules with the same ID. 4. Use twisted-pair cables, ground the shielding layer, and use dual power supplies for severe interference (the main power supply of the expansion module and the IO power supply are separately powered) |
| Fail to connect controller to PC through net port. | <ol style="list-style-type: none"> 1. Check IP address of PC, it needs to be at the same segment with controller IP address. 2. Check controller IP address, it can be checked and captured after connection through serial port. 3. When net port led is off, please check wiring. 4. Check whether controller power led POWER and running indicator led RUN are ON normally. 5. Check whether the cable is good quality, change one better cable to try again. 6. Check whether controller IP conflicts with other devices. 7. Check whether controller net port channel ETH are all occupied by other devices, disconnect to other devices, then try again. 8. When there are multiple net cards, don't use other net cards, or change one computer to connect again. 9. Check PC firewall setting. 10. Use "Packet Internet Groper" tool (Ping), check whether controller can be Ping, if it can't, please check physical interface or net cable. 11. Check IP address and MAC address through arp-a. |